

6. Care & Maintenance Around Water

If the AL Charger Base becomes wet, wipe it dry immediately and do not use it until it is completely dry. Clean the leather top gently with a soft, slightly damp cloth as needed. Avoid using harsh chemicals or prolonged direct sunlight to avoid damaging the Leather on the top surface of the AL Charger Base.

7. FCC Compliance Statement



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

a. FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

AL[®] CHARGER

BASE



User Guide


1. Introduction

Welcome to the **AL Charger Base**. This guide provides instructions for the safe and optimal use of your wireless charger. Please read it carefully before use.

2. Product Overview

The AL Charger Base wirelessly charges your devices and recharges your AL Charger. Key components include:

- **Wireless Transmitter Area:** The top surface of the charger that powers your devices.
- **USB-C Input:** Connect a USB-C cable here to power the AL Charger Base.



3. Specifications

USB-C Port Input Power: 5V/3A, 9V/2A, 12V 1.5A

Wireless Charging Output: 15 W Max

Dimensions: 3.96in x 3.96in x 0.45in (100.5mm x 100.5mm x 11.5mm)

Weight: 0.24 lbs (110 grams)

Operating Temperature: 32°F-104°F (0°C-40°C)

Storage Temperature: 32°F-122°F (0°C-50°C)

4. How to Use Your AL Charger Base


a. Charging Your Devices:

- **For MagSafe-compatible iPhones (iPhone 12 models or later):** Align the MagSafe area on the back of the phone with the Wireless Transmitter Area on the AL Charger Base.
- **For other phones that support wireless charging:** Adjust the position of the phone to align it with the Wireless Transmitter Area of the AL Charger.

Once the phone is in place, the AL Charger Base begins charging automatically. If charging doesn't start, lift the phone and reset it onto the AL Charger Base. When you remove the phone, the AL Charger Base powers off automatically.

Note: It is normal for the AL Charger Base and your device to become warm during charging.

Tip: Phone cases that block wireless charging, such as those that are very thick or contain metal, are not compatible with this charger.



b. Recharging Your AL Charger With The AL Charger Base:

Place the AL Charger on the Wireless Transmitter Area, the AL Charger's LED Status Indicators will indicate the charging status, and the AL Charger will automatically start charging. If the AL Charger does not charge, pick up and replace the AL Charger on the Wireless Transmitter Area.

c. Recharging Multiple AL Chargers:

Place the first AL Charger onto the AL Charger Base, then stack additional AL Chargers directly on top. The built-in magnets ensure proper alignment, allowing all stacked chargers to recharge simultaneously.

Tip: For optimal charging speed, it is recommended stacking no more than 2 AL Chargers at a time. Larger stacks may result in slower charging.

5. Safety Information



- Do not get wet or use the AL Charger Base around water.
- Ensure the charger is used in a well-ventilated area; do not cover with blankets, pillows, or insulating materials.
- If the charger becomes extremely hot, stop charging immediately and let it cool before resuming use.
- Charging speed and efficiency decrease at high temperatures; use below 35°C / 95°F for best performance.
- Do not place any foreign objects between your device and the wireless charger's surface, including magnetic cards, door keys, coins, NFC cards or other metal objects, as they could potentially affect the charging speed, or cause overheating.
- Do not expose the charger to extreme temperatures (below 0°C/32°F or above 45°C/113°F).
- Do not disassemble, crush, or incinerate the charger.
- Keep the charger away from direct sunlight for prolonged periods.
- Keep out of reach of children.
- Avoid dropping or subjecting the AL Charger Base to strong impacts. Though designed for daily use, rough handling could damage the internal components.
- Do not put hot objects on top of the AL Charger Base.
- Do not submerge the AL Charger Base in a liquid.