


WIRELESS CHARGING PAD
+
VALET TRAY



English
User Manual

PRODUCT OVERVIEW



SPECIFICATIONS

Input: 5V/3A, 9V/2A
Output: 15W/10W/7.5W/5W

INSTRUCTIONS

Power the Wireless Charging Pad: Start by inserting the USB-C cable into the USB-C port on the charging pad and connect the USB-A connector to the wall adapter to power the wireless charging pad.
Check Device Compatibility: Ensure that the device you wish to charge is compatible with wireless charging pad.
Place the Device for Charging: Simply place the wireless charging-enabled device on the designated wireless charging area of the charging pad.

PRECAUTIONS

- Avoid exposing the charging pad to moisture or heat sources.
- Do not disassemble the charging pad or expose it to fire or water to prevent short circuits and potential damage.
- Keep the charging pad away from extremely hot, humid, or corrosive environments for optimal performance and durability.
- Refrain from placing magnetic stripe or chip cards too close together to avoid potential card failure and damage to the charging pad.
- Note that some phone cases may obstruct wireless charging. Please ensure the phone case you use allows for wireless charging.
- Ensure accurate placement of the mobile device on the charging area to ensure proper charging.
- This charging pad is not a toy. Ensure children do not play with it to avoid any accidents or mishandling.



Manufactured for &
Distributed by:
HTG Brands, LLC
Bell, CA 90201
MADE IN CHINA

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.