


SMART PROJECTOR


User Manual




MODEL:U1 Pro

QUICK START


1




2




3



4





Must read before using this product, Please read it carefully and keep it properly. This product instruction manual.

Thank you for purchasing and using our products. For the sake of your safety and interests, Please read this product manual carefully before using the product, standardize the operation, and ensure your Personal safety and property safety. Our company will not be responsible for all losses caused by non-standard operation.

Important Notes:

When the projector is working, it is forbidden to block the air inlet or outlet, so as to avoid damage to the internal electronic devices caused by the failure of dissipating heat.

To protect your eyes, do not look at the lens of projector directly.

To avoid damage of the lens, do not use paper, cloth and other cleaning tools to wipe the lens directly, please use a dust-free cloth or wipe it with alcohol gently.

Please ensure that the projector is used in a dry and ventilated environment.

Do not store the projector in an overheated or over-cooled place. High (low) temperature will shorten the service life of electronic devices. The storage and use environment of the projector is allowed to be 0 ~ 40 °C;

Do not put the projector into any heating equipment (such as dryer, microwave oven, etc.) to dry;

Do not drop or hit the product from high altitude to avoid damage to the equipment;

Please use the power adapter equipped with the product for power supply. if the power adapter is damaged, please contact the manufacturer,

If there is any problem with the product, do not disassemble it without permission. Please contact professional after-sales personnel for assistance.

Attention:

If the contents of the manual are inconsistent with the actual product, the actual product shall prevail. If you have any objection to the contents of the manual.

please raise a written objection within seven days after purchase. otherwise you are deemed to have agreed, understood and accepted the whole contents of this manual.

Quick start

1. Power on:

1.1 Connect the power cord correctly.

1.2 Short press the power button on the body or the remote control to turn on the projector.

Note: The remote control needs to be aimed at the remote control receiver of the product

1.3 Focus: Press "⊕" and "⊖" to adjust the image focus

Note: The distance between the projector and screen must not be less than 1.2m, otherwise it cannot be adjusted clearly.

If the auto focus is not accurate enough, you can turn off the auto focus function

Press "⊗" on the remote control to bring up the OSD settings, Auto Focus at Startup: On/Off

2. OSD Projector Settings

2.1 Keystone Correction

A. Set auto correction: Press "⊗" on the remote control to bring up the OSD settings, "Auto Keystone Correction Startup: on/off "

B. Set auto correction: Press "⊗" on the remote control to bring up the OSD settings, settings,"4 - Point Keystone" → "Manual Keystone"

2.2 Auto Focus

Set auto correction: Press "⊗" on the remote control to bring up the OSD settings, "Auto Focus Startup: on/off "

2.3 Auto Obstacle Avoidance

Set auto correction: Press "⊗" on the remote control to bring up the OSD settings, "Auto Obstacle Avoidance Startup: on/off "

2.4 Auto Screen Fit

Set auto correction: Press "⊗" on the remote control to bring up the OSD settings, "Auto Screen Fit Startup: on/off "

2.5 Digital Zoom

Press "⊗" on the remote control to bring up the OSD settings,"Digital zoom " and adjust the screen size.

2.6 Projector ceiling settings

Press "⊗" on the remote control to bring up the OSD settings,"Projection Mode", select the projection mode

2.7 Restore factory settings

Press "⊙" on the remote control to bring up the OSD settings, "Other" → "Factory Reset".

Restore factory settings.

2.8 Other settings

Picture, Sound, Language, Keyboard, Signal Source Advanced Setting, press "⊙" on the remote control to bring up the OSD settings to operate.

3. GTV settings

3.1 Remote control pairing: When the product is turned on for the first time, the remote control pairing screen will appear. Hold the remote control close to the product and press the remote control "←" + "Ⓐ" for 3 seconds. Release it after the interactive effect appears on the screen.

3.2 Set the language

A. OSD menu language setting: Press "⊙" on the remote control to call up OSD settings → "language" and select the language

B. System language setting: "settings" → "language" → select the language

3.3 Connect to WiFi:

"settings" → "Network&Internet" → "WiFi: on/off", turn on WiFi, search and connect to the WiFi network

3.4 Restore factory settings:

"settings" → "System" → "About" → "Reset", restore factory settings

4. External device connection

4.1 Connect external HD devices: Click the remote control "Ⓜ" button, select the HDMI signal source, switch to the HD signal channel, and connect the PC/game console/DVD/TV box, etc. to the HDMI interface of the projector.

4.2 Read the U disk file: Insert the U disk into the USB port, click the remote control "Ⓜ" button, select USB

Common troubleshooting methods:

1. The remote control does not respond

- 1.1 Check if the battery is installed correctly. Check if the battery is charged. The battery must be installed correctly and the battery must be charged.
- 1.2 The remote control of the GTV interface requires Bluetooth pairing. If the remote control is not sensitive, please check if the Bluetooth pairing is normal.
- 1.3 It may be an operation problem. Operate the remote control by pointing the top of the remote control directly at the remote control receiving position on the front of the projector.
- 1.4 If the remote control is lost, you can operate it with the mouse.

2. Automatic shutdown

Check if the air inlet and outlet of the projector are blocked, remove obstacles around the projector, and ensure good heat dissipation and ventilation. Poor heat dissipation will cause the projector to shut down automatically.

3. Unable to turn on

Solution:

- 3.1 First eliminate the operation problem. You can press and hold the power button on the projector body for more than 5s to test the power on.
- 3.2 The battery may be out of power. You need to charge it for a while before turning it on. If it is not used for a long time, please charge it for more than 4 hours to activate the battery.

4. Unable to connect to the network

- 4.1 It may be too far from the wifi and the signal is not good. You can test it close to the wifi router:
- 4.2 It may be that the router does not have extra IP addresses to allocate. Restart the user's router and connect again.
- 4.3 You can turn on the mobile phone hotspot and connect the projector to the mobile phone hotspot to test whether the user's home network is abnormal.

5. Wifi-display is stuck and delayed

You need to be close to the wifi router and the network speed must be fast enough to be smooth enough, because the image is transmitted from the mobile phone to the WiFi router, and then from the router to the projector, not directly from the smartphone to the projector.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.