


★ AI Smart Plush Toy User Manual




Important Notes

- 1.This product uses a built-in non-removable rechargeable 3.7V 1200mAh polymer lithium battery;
- 2.The battery must be charged under adult supervision;
- 3.Please use a certified 5V1A charger that complies with the CCC standard;
- 4.Do not connect more than the recommended number or a power supply with a voltage greater than the recommended voltage;
- 5.Check the wires, plugs, housings and other parts regularly for damage. If any damage is found, stop using the device until it is repaired;
- 6.Do not turn on the device to play while charging.

Company Name: DONGGUAN MILET CULTURAL CREATIVE CO.,LTD
item No.: MLT-AI-S1 Proudct Name:Miiloo AI Smart TOY



Button function description




The left ear button is the M button (M key).
The right ear button is the Conversation button .



Product list



Manual × 1



Charging cable × 1



Miiloo Toy × 1



Product features



Intelligent interaction, daily conversation:

After the device is turned on and connected successfully, long press the right ear button of Miiloo to talk, chat with Miiloo, and let go after talking. Short press the right ear (conversation button) to interrupt Miiloo at any time.



Multi-language conversation:

Support multi-language interaction, learn while playing.
Currently available in Chinese, English, French, Italian, Spanish, Portuguese, Russian, Korean, and more. More languages are constantly being developed, please pay attention to APP updates



Creative roles:

Create unique roles on the App, with a variety of voices to choose from. Miiloo can play different roles and interact with children. Short press Miiloo's left ear to switch roles.



Language games:

Children can play language interactive games with Miiloo, such as co-creating stories, guessing riddles, telling jokes, encyclopedia knowledge questions and answers, etc. For more interesting interactions, please enjoy exploring.



Emotional analysis:

Capture all emotions such as anger, sadness, happiness, etc., generate an analysis curve for children's emotions based on Paul Ekman's emotion analysis theory, and understand children's mood in a timely manner.



Operating Instructions


1. Download the miiloo APP

Scan the QR code to download the software, or search for "Miiloo" directly in the App Store or Google Play

App Store




Google Play






2. Creating an account

After downloading, click on the APP to enter the main page and then click on the email quick registration

You can choose
your favorite language




Click on your email to register quickly



After entering the registration page, fill in your email, verification code and password, click "Register", and you can log in after registration

3.Wechat Mini Program version :

Scan the QR code below to directly enter the homepage




4.To guarantee uninterrupted and efficient performance of the device, it is advised to utilize it exclusively with a home WiFi connection.

2.4GHz 	
Home WiFi	
Enterprise WiFi	
Industrial WiFi	
Public WiFi	
Hotspot WiFi	

5. Connect to MILOO dolls


Step 1

Tear off the Velcro at the back




Step 2

Power On/Off Switch




Step 3

Open the APP and click on "+ Bind"



Step 4

Please make sure Bluetooth and Wi-Fi are both turned on. Click "Search".



Step 5

Bluetooth searches for the device.




Step 6

Enter the "Wi-Fi name" and "Wi-Fi password." then click "Connect to Wi-Fi." Note: The network must be a 2.4GHz Wi-Fi.



After Miiloo say "Network links successfull",let's Start a Conversation!



Binding Successful

Please fill in the basic information

Name

Birthday

Gender ☐ Boy ☐ Girl

Save

Skip Setting



Device Role Settings

Choose a role

Miiloo  Miiloo is a gentle girl from the Dimensional Town, but only cannot...

You want me to help children

Establish the following values

☐ Integrity ☐ Kindness ☐ Bravery ☐ Sincerity

Develop the following good habits

☐ Eat meals well ☐ Don't be picky about food

☐ Sleep well ☐ Keep clean ☐ Reduce mobile phone use

☐ Be curious ☐ Be polite ☐ Be eager to learn

☐ Be diligent in thinking ☐ Be ready to help others

☐ Love reading ☐ Care to try new things

☐ Be brave to explore

Cultivate the following skills


☐ Spoken English ☐ Ancient poetry ☐ Communication skills

You can write down how you want me to chat with the child

Save

You can set the miiloo character profile information. After setting it up, click "Save"

(You can set the basic information of the interlocutor or skip it)



Network Connection Fails

If the device is not working properly. Please check the following steps:

1. Please confirm that the network name and password are correct .
2. Please confirm that the current network is a 2.4G network.
3. Please confirm that the current network is functioning properly and place the device as close to the router as possible.

If all settings are correct , you can try a factory reset :
Press and hold the left ear (M button) for 6-8 seconds , after hearing miiloo say: Factory Mode.

Networking-Autoratically enter the networking mode when using for the first time

Network Reconnection

After changing the WiFi or the WiFi passwords changes, you need to reconnect

Once the device is activated and the doll is successfully connected to the network, as long as the network is working properly, the doll can work continuously on the same WiFi with no need to reconfigure the network via phone. Reconnection is only required when the WiFi changes or the password is updated. new network

How to reconnect :

1: Press the M- button for 3 seconds

2: Press and hold the M button for 6-8 seconds to restore to factory mode

6.Start a conversation

Click the **right ear** to start a conversation



Two modes of conversations:

- (1) : Keep pressing the right ear button while talking to Miiloo, release it and wait for Miiloo to reply.
- (2) : Double-click the right ear quickly to enter the Multi-turn conversation mode .

1: Quickly press the conversation button twice. When you hear the voice prompt "Entered the Multi-turn conversation" you can start talking to miiloo. Press the conversation button once briefly to exit the multi-turn conversation mode, and there will be a prompt tone after exiting.

2: Exit the Multi-turn mode via voice feedback: For example, saying commands with similar semantics like "I don't want to chat anymore" will trigger the exit, followed by a prompt tone.

3: If there is no user interaction for 30 seconds, the system will automatically exit the Multi-turn conversation, accompanied by a prompt tone.



7.Role Switching

*Simply Press the **Left ear** button to switch different roles which were collected

*The device has pre-collected four roles:

American, German, Spanish, and French.

You can check how many roles are collected : Mine-Collections



Click the "Remove" button under the collected roles to uncollect them.

Select your preferred role and click "Collect" to add it to your collection.

8. Default Role List

Step1

Different Languages options



Step2

Choose any language at will




Step3

Save the role file



Step4

Complete the setup



9. Create your own roles

Step1

Click Role→My role



Step2

Click“Create New”




Step3

Name the new role and complete the profile. Don't forget to add the profile picture




Choose the the voice you like at the Voice Store




Step4

After selecting the voice- Confirm



Step5

Press the Create New to save the role



Step6

Suceefully created the new role-OLGA



Step7


Choose OLGA then talk with it !




It has been created

10. The same mobile phone can connect to multiple Miiloo Dolls.

But homepage displays only one doll's status. Select "Exchange" to choose another doll



11. Emotion analysis




Once clicked, you can see a summary of the sentiment analysis, which covers all emotions such as anger, sadness, and happiness




Based on Paul Ekman's emotion analysis theory, generate children's emotion analysis curve to understand children's emotions in time.

12. Volume adjustment

Method 1: Flip the volume wheel to adjust the volume.



Method 2: Highly recommended to set it up in the APP



13.Chatting records

Can see chat logs through the interface of record



App language change



The language of the interface can be changed:

There are Chinese/English/French/Italian/Spanish/Korean/Thai/Portugal





About this product manual

RED: Operation Frequency(Bluetooth):
2402MHz-2480MHz: Max RF output power: 9.18dB-
mOperation Frequency(2.4G
WiFi):2412MHz-2472MHz: Max RF output power:
14.16dBm

Product model: MLT-AI-S1

Hereby, DONGGUAN MILET CULTURAL CRE-
ATIVE CO., LTD declares that the radio equipment
type MLT-AI-S1 is in compliance with Directive
2014/53/EU. The full text of the EU declaration of
conformity is available at following internet address:w-
ww.miiloo.net

“This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.”

“NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technical for help.”

“NOTE: This equipment has been tested and found to comply w“This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.”

FCC Compliance Statements

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Compliance Statements

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Information (SAR)

Specific Absorption Rate (SAR) refers to the rate at which the body absorbs RF energy. This equipment has been tested and meets applicable limits for radio frequency (RF) exposure. During testing, device radios are set to their highest transmission levels and placed in positions that simulate use near the body, with 5 mm separation.

Accessories with metal parts may change the RF performance of the device and use such accessories should be avoided.

The SAR limit is 1.6 W/kg over 1 gram of tissue in US/Canada.

Le débit d'absorption spécifique (DAS) renvoie au débit avec lequel le corps absorbe l'énergie RF. Cet équipement a été testé et est conforme aux limites applicables en termes d'exposition aux radiofréquences (RF). Pendant le test, les appareils radios sont configurés à leur niveau de transmission le plus élevé et placés dans une position Simuler l'utilisation près du corps, avec 5 mm de séparation. Les accessoires possédant des pièces métalliques peuvent modifier la performance RF de l'appareil. L'utilisation de ces accessoires est donc déconseillée.

La limite DAS est de 1.6W/kg pour 1 gramme de tissu aux États-Unis/au Canada.


This equipment complies with Canada radiation exposure limits set forth for uncontrolled environments. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Déclaration d'IC sur l'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux radiations définies par le Canada pour des environnements non contrôlés.

Cet émetteur ne doit pas être installé au même endroit ni utilisé avec une autre antenne ou un autre émetteur.

This toy is only to be connected to equipment bearing either of the following symbols.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The name, address and contact number of the local responsible party in the United States are as follows:

Name:GOTSREVE LLC

Address: 411 EAST HUNTINGTONDRSTE 107-503ARCADIACAUnited States

Contact number: (626)447-8260

CARE AND MAINTENANCE:

This battery is not detachable but can be charged by gently pulling the tear strip on the top of the doll's head.

Keep the product away from direct heat. Do not submerge the product in water. This can damage the electronic assemblies.



This product uses a built-in non-removable rechargeable 3.7V1200mAh polymer lithium battery.

Batteries or battery packs must be removed for recycling and proper disposal. When this

product has reached the end of its useful life, it should not be disposed of with other household waste. EU legislation for Electrical and Electronic Equipment and Batteries, requires these to be separately collected so that they can be treated using the best available recovery and recycling techniques. This will minimize the impact on the environment and human health from soil and water contamination by any hazardous substances, decrease the resources required to make new products and avoid using up landfill space. Please do your part by keeping this product out of the municipal waste stream! The “wheelie bin” symbol means that it should be collected as “waste electrical and electronic equipment”.

You can return an old product to your retailer when you buy a similar new one. For other options, please contact your local council.

SPECIAL LiPo BATTERY INSTRUCTIONS:

Never charge battery unattended. - Charge battery in an isolated area. Keep away from flammable materials.

- Do not expose to direct sunlight. There is a risk of the batteries exploding, overheating, or igniting.
- Do not disassemble, modify, heat, or short circuit the batteries. Do not place them in fires or leave them in hot places.
- Do not drop or subject to strong impacts.
- Do not allow the batteries to get wet.
- Only charge the batteries with the charger supplied.
- Only use the batteries in the device specified.
- Carefully read the instruction guide and use the batteries correctly.
- In the unlikely event of leakage or explosion use sand or a chemical fire extinguisher for the battery.
- Batteries must be recycled or disposed of properly.
- DO NOT incinerate used batteries.
- DO NOT dispose of batteries in fire, as batteries may explode or leak.

PRODUCT BATTERY REMOVAL INSTRUCTIONS:

Internal battery is factory installed and non-replaceable, product disassembly and battery removal must be performed by an adult. Do not puncture, cut, tear, compress or deform product during disassembly. Ensure product is turned off, then use a screwdriver to remove all screws. Separate product body halves to expose internal electronics. When battery is visible in its entirety use scissors to cut a single battery wire, immediately wrap the cut wire end with tape to isolate it, repeat until all battery wires are cut and isolated, and the battery is free from the rest of the product.

Dispose of battery in accordance with your local battery recycling or disposal laws.

- Batteries must be recycled or disposed of properly.
- DO NOT incinerate used batteries.
- DO NOT dispose of batteries in fire, as batteries may explode or leak.

3.Product Warning:

Keep the product away from direct sunlight, open flames or other heat sources.

This product is not waterproof. Do not expose it to damp environments or immerse it in water.

Maintenance: The product contains electronic components and should not be placed in water or in a humid environment. Please wipe it clean regularly with a clean dry cloth. Do not wash it with water.

For the safety of children, do not use the product while it is charging.

When the battery is low, the device will not power on. After charging is complete, the device will power on automatically. It takes approximately 180 minutes to fully charge (based on laboratory data; actual time may vary).

Please read the manual carefully. The manual contains important information and should be kept for future reference.

Special Tips:

* Sleep mode

After ten minutes of standby, the device will automatically enter low-energy sleep mode, without frequent power on and off.

* Wake up

If the device is not used for ten minutes, it will enter sleep mode and play reminder music;

After the device enters sleep mode, you need to press the right ear (conversation button) to wake it up. After waking up, you can continue to talk normally after hearing the prompt tone "network links successful" for 2 to 3 seconds.

*Role Collect

Except for the default roles, other roles need to be collected before they can be manually switched by short pressing the left ear (M button)



After-sales service guide

- The copyright and trademarks of the manual belong to our company and its affiliates. If the contents of the manual are inconsistent with the actual product, the actual product shall prevail. The company reserves the right to interpret and modify the instructions within the scope permitted by law.
- If you have any objection to any content or terms in the manual, please submit a written objection to our company within seven days after purchasing the machine, otherwise it will be deemed that you have agreed, understood and accepted all the contents of the manual.

Special instructions: This product is equipped with the latest AI large model technology, the company will continue to iterate and upgrade according to the development of technology and business, the function and contents of this product are adjusted dynamically. Our company cannot guarantee the timely update of relevant packaging and instructions. Customers are advised to refer to the functions and contents during actual use.



07

After-sales service guide

Dear valued customer:

Thank you very much for your support of our AI plush products!

If you encounter any issues while using the product, or have after-sales needs such as returns, exchanges, repairs, or troubleshooting, please feel free to contact us via email at AISMARTTOY@163.com at any time.

Warranty regulations

If the product performance failure is caused by non-human damage during the warranty period, you can enjoy the following services:

- If the product has any quality problems within 15 days of purchase, consumers can choose to return it or exchange it for a product of the same model and specification.
- If the product has any quality problems within 1 year after purchase, consumers can obtain warranty services such as repair, refurbishment or replacement.

Notice: During the warranty period, the product will be returned and tested by the authorized service provider of this product. After the fault is confirmed, the corresponding service will be provided.

The replaced defective parts will not be returned to the user. For products without any faults, send them back in their original condition. Online purchase users, the purchase date is based on the product receipt date.

Non-warranty regulations

The following situations (including but not limited to) are not within the scope of the "Three Guarantees" service:

- No "Three Guarantees" certificate or missing valid invoice or the "Three Guarantees" service validity period has expired;
 - Damage caused by force majeure;
 - Damage caused by failure to use, maintain, or store the product in accordance with the product manual;
 - Damage caused by repair by unauthorized service personnel;
 - The product model or code on the warranty certificate does not match the actual product;
 - Normal discoloration, wear and tear during product use;
 - The product cannot be used due to the consumer's own network problems;
 - If the returned power supply has obvious hard damage, cracks, broken legs, severe deformation, damaged power cord, broken wires, bare cores, etc., the power supply will not be repaired or replaced.
- In the above situation, you should seek a solution from the responsible party or choose paid services, or purchase new one.

his product contains electronic components and built-in batteries. When cleaning, you may wipe surface stains with a soft dry or damp cloth, or use a professional plush cleaning agent.

Component Name	Hazardous Substances					
	Lead(Pb)	Mercury(Hg)	Cadmium (Cd)	Hexavalent Chromium(Cr[VI])	Polybrominated Biphenyls(PBBs)	Polybrominated Diphenyl Ethers(PBDE)
Circuit Components	O	O	O	O	O	O
Structural Components	O	O	O	O	O	O
Metal Parts	O	O	O	O	O	O
Loudspeaker	O	O	O	O	O	O
Battery Components	O	O	O	O	O	O
Charging Cable	O	O	O	O	O	O

This table is prepared in accordance with the provisions of SJ/T 11364.

O: Indicates that the content of the targeted hazardous substance in all homogeneous materials of this component is below the threshold limits specified in GB/T 26572

exceeds the threshold limits specified in GB/T 26572

X: Indicates that the content of at least one restricted substance in one homogeneous material of this component




Warning:

choking hazard---Contains small parts, not suitable for children under three years old.

Friendly reminder

- The product should be kept away from direct sunlight, open flame or other heat sources.
 - This product is not waterproof. Do not expose it to a humid environment or put it in water.
 - Maintenance: This product contains electronic components and must not be placed in water or in a humid environment. Please wipe it clean with a clean dry cloth regularly. Do not wash it with water. *To ensure the safety of children, do not use this product while charging.
 - Please read the instructions carefully. They contain important information. Please keep them for future use.
- * When the battery is low, the device cannot be turned on. Please charge it in time. A full charge takes about 180 minutes.



Hug me, ask me, love me-the
plush that understands you!