多功能指环遥控器

K06使用说明书

按键功能：

*同时长按4键和5键，切换相机模式和娱乐模式

1:长按3秒开关机；单击抖音暂停/播放；双击点赞.
在相机模式下：短按拍照；双击连拍.

2:单击上翻页；长按音量加.
在相机模式下：短按放大焦距；长按连续放大焦距.

3:单击下翻页；双击暂停播放音乐；长按音量减.
在相机模式下：短按缩小焦距；长按连续缩小焦距.

4:单击左翻页；双击播放上一曲；长按返回首页.
在相机模式下：单击左滑.

5:单击右翻页；双击播放下一曲；长按锁屏.
在相机模式下：单击右滑.

6:指示灯

使用说明：

长按3秒开关键开机，指示灯闪烁蓝色，在手机蓝牙中搜索蓝牙设备名称“K06”并配对；与手机蓝牙配对成功后，就可以使用遥控器控制使用手机刷视频/阅读/自拍等操作。

特别说明：

1.苹果IOS13.4以上设置方法：
①.打开iPhone/iPad的辅助触控进行悬浮球操控（设置-辅助功能-触控-辅助触控-打开）.
②.搜索蓝牙设备“K06”进行配对，配对成功即可使用（戒指再次激活后，将自动连接上次设备）.
③.IOS15以上系统首次使用连上即可使用，如有调过跟踪灵敏度需将圆点移回初始默认位置即可.

2.安卓、鸿蒙系统无需设置，蓝牙连接成功即可使用，如有不能连接的或连接成功但使用不正常的，先删除（忽略此设备），关机重开遥控器，重新匹配连接即可（戒指再次激活后，将自动连接上次设备）.

3.戒指5分钟未操作自动休眠，随意按压按键，戒指再次激活，自动连接上次设备，戒指放进充电盒后蓝牙断开,休眠，取出自动回连上一次连接设备.

4.充电
①.戒指放入充电盒充电时，戒指红灯常亮，充电盒蓝灯常亮，充满灯灭.
②.充电盒单独充电时，红灯常亮，充满灯灭.
③.戒指和充电盒同时充电时，戒指红灯常亮，充电盒蓝灯和红灯常亮，充满灯灭.

*电量不足提示：

无操作时，蓝灯快闪，提示电量不足，请及时充电.

苹果手机的连接方式：

设置 → 辅助功能 → 缩放 → 打开

打开后用三指连续点两下屏幕就能回到正常屏幕，然后再打开蓝牙，连接K06配对

苹果手机的连接方式：

苹果手机的连接方式：

注意：
1.启用打开缩放
2.使用食指/中指和无名指双击屏幕，使屏幕恢复原比例

产品合格证

Product Qualification Certificate

产品名称：多功能指环遥控器
Product Name　Multi-functional finger ring remote control

规格型号：K06
Specification model

检测员：
Inspector:

QC PASSED 01

本产品经检验符合规定的质量标准，准予出厂。
This product has been inspected and meets the specified quality standards, and is allowed to leave the factory.

K06 Ring Remote Control

Instruction manual

Button Function

*Press and hold the 4 and 5 keys simultaneously to switch between camera mode and entertainment mode

1: Press and hold for 3 seconds to turn on and off; Click Tiktok to pause/play; Double click like,
In camera mode: short press to take a photo; Double click on continuous shooting.
2: Click on page up; Long press to increase the volume,
In camera mode: short press to zoom in on the focal length; Press and hold continuously to zoom in on the focal length.
3: Click to page down; Double click to pause music playback; Long press to decrease the volume,
In camera mode: short press to reduce the focal length; Press and hold continuously to reduce the focal length.
4: Click to turn left page; Double click to play the previous song; Long press to return to the homepage,
In camera mode: Click left swipe.
5: Right click to page; Double click to play the next song; Long press to lock the screen,
In camera mode: right-click and swipe.
6: indicator light.

Instructions for use:

Press and hold the power button for 3 seconds to turn on the device, the indicator light will flash blue, and search for Bluetooth in the phone's Bluetooth Device name "K06" and pairing; After successfully pairing with the phone's Bluetooth, you can use it The remote control controls the use of mobile phones for video browsing, reading, selfies, and other operations.

Special note:

1. Setting up Apple iOS 13.4 and above:
①. Turn on the auxiliary touch control of iPhone/iPad for floating ball control (Settings - Accessibility-Touch-Assist Touch-Open).
②. Search for Bluetooth device "**K06**" for pairing, and once paired successfully, it can be used.(After activation, it will automatically connect to the last device).
③. IOS 15 and above systems can be used for the first time by connecting them. If the tracking sensitivity has been adjusted, it can be used immediately Simply move the dot back to its initial default position.
2. Android and HarmonyOS systems do not require settings, and can be used after a successful Bluetooth connection. If there is any issue, it cannot be resolved If the connection is successful but not functioning properly, delete it first (ignore this device), Turn off the device, restart the remote control, and reconnect it (the ring will automatically activate after being reactivated Connect the last device).
3. If the ring is not operated for 5 minutes, it will automatically sleep. Press the button at will, and the ring will activate again, automatically connect the last device. After placing the ring in the charging case, the Bluetooth will disconnect, enter sleep mode, and automatically reconnect upon removal last time the device was connected.
4. Charging
①. When the ring is put into the charging case for charging, the red light of the ring is always on, and the blue light of the charging case is always on, full of lights off.
②. When the charging case is charged separately, the red light is always on and the fully charged light is off.
③. When the ring and charging case are charged simultaneously, the red light of the ring is always on, and the blue and red lights of the charging case are on always on, full of lights off.

*Low battery prompt:
When there is no operation, the blue light flashes rapidly, indicating low battery. Please charge it in a timely manner.

Settings Needed Before Use If

Settings → Accessibility → Zoom → On

After opening, use three fingers to tap the screen twice in a row to return to the normal screen, Then turn on Bluetooth and Connect to **K06** for pairing



Settings Needed Before Use If



Settings Needed Before Use If

Notice:
1. Enable enabling zoom on
2. Double click the screen with the index/middle and ring fingers, Restore the screen to its original proportion



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause ndesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

说明书：
材质：128g铜版纸
展开尺寸：350*70mm 成品尺寸：50*70mm
四色双面印刷 风琴折