

WARRANTY

FCC Statement
This device complies with part 15 and part 18 of the FCC Rules. Operation is Subject To the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.
Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 and part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected. This device complies with Part 18 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Increase the separation between the equipment and any other radio device.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.


SHARPER IMAGE®
POWER LED 360



USER MANUAL

This is a 3-in-1 fast wireless charger that supports a mobile phone, watch and earbuds with a charging case. In addition to the foldable and portable design, this product also has a full color atmospheric light show. This product adopts a folding design which makes it easy to store and carry. Simply place the equipment in the charging area to wirelessly charge your device. You can put your mobile phone vertically or horizontally without affecting the charging of your phone. You can video chat or watch your favorite film and television while charging.

Includes:
Power LED 360, Type-C USB Cable, User Manual



- 1. Mobile Device Charging Area
- 2. Earbuds with Charging Case Charging Area
- 3. iWatch Charging Area
- 4. RGB Light Touch Switch
- 5. RGB Light Show
- 6. Type-C Charging Port

SPECS

Material: ABS + Acrylic
Interface: USB Type-C
Input Current: 5V-3A, 9V-3A

Mobile Phone Output: 15W / 10W / 7.5W/5W
Earbud Output: 5W
iWatch Output: 2.5W

CHARGING

OPERATION STEPS

- Please power the product first through the charging port with included USB Type-C cable. After inserting the cable, the atmospheric light will turn on. The purple lights indicate a standby state.
- The standby and charging process can control the display status of the colorful atmosphere light through the power button (note: three different states - slow, flash, and turn off).

TOMORROW'S.MORROW™

WARNING

- It is forbidden to immerse the product into the water to avoid short circuit in the internal circuit!
- It is forbidden to disassemble or beat products by yourself, so as not to cause product damage!
- Please place the product away from flammable and explosive liquid, gas or explosive products!
- Please do not place magnetic cards, magnetic strips and precision machinery too close to this product!
- Charging warning:** When the display light flashes continuously during the charging process, it means "charging warning". At this time, check whether there are metal foreign bodies in the wireless charging area. After taking out any foreign bodies, you can charge normally.

This device is not a toy and should be kept away from children. The product must not be dropped or subjected to intentional impact. Do not use the device in humid environments or in extremely hot / cold temperatures. Do not use chemicals or abrasive detergents to clean the product. Please return for repairs if the product is defective. The warranty is invalid if the product has metal rust, water damage, or other natural oxidation.