





52 mm

103 mm



### Anti Spy Detector User Guide



or

Hello friend ,  
Thanks for using this anti-spy detector,  
we are honored that your choose this  
product finally.  
In order to give you a brief introduction  
of the detector and make it more  
convenient for your life, we have  
specially configured this instruction  
manual for you. Content includes  
product schematics and functions,  
basic parameters, operation methods,  
common questions and answers,  
applicable people,  
package, warranty,etc.

1

#### 1.Product schematics and functions



| Number | Function               | Indication                                 |
|--------|------------------------|--------------------------------------------|
| 1      | ON/OFF                 | Power switch                               |
| 2      | LED lights             | Reflect the camera via a bright spot       |
| 3      | Infrared lens finder   | Scan to find hidden lens                   |
| 4      | Sensitivity display    | Check Wireless signal strength             |
| 5      | Mode button            | Switch to the mode you need                |
| 6      | Sensitivity adjustment | Adjust signal strength to the proper level |
| 7      | Voice button           | Change to alarm or vibration mode          |
| 8      | Charging               | TYPE-C Charging Port                       |
| 9      | Lights                 | Flashlight                                 |

2

#### 2.Basic Specifications

|                           |                                                     |
|---------------------------|-----------------------------------------------------|
| Volume                    | 16*21*88 MM                                         |
| Weight                    | 24g                                                 |
| Charging interface        | Type-C                                              |
| Working hours             | 25 hours                                            |
| Antenna gain              | >73DB                                               |
| Power plug                | DC5V/1A                                             |
| Battery                   | 800mAh                                              |
| Sensitivity               | 5 levels adjustable                                 |
| Receiving frequency range | 100M Hz-8G Hz                                       |
| Signal detection range    | 2.4G:10mw;1.2G:10mw;<br>2G: 3G: 4G:15 square meters |
| Laser detection distance  |                                                     |
| Material                  | PC+ABS                                              |
| Charging time             | 2.5 hours                                           |


3

#### 3. Operation methods

**a. Detection of radio waves**  
(wireless cameras /eavesdroppers, etc.)  
(1) Push the power switch to “ON”, after hearing the "Di-" sound, release your finger, blue indicator and flashlight will flash and off, strength sensitivity will be on the 1st level, wireless signal detection mode will start automatically.  
(2)If there is a voice prompt, it means there is an emission source. The more blue signal indicators appear, the stronger the signal is.  
(3)Click the signal sensitivity adjustment button to adjust sensitivity, the more blue signal indicators are, the higher the sensitivity is , which can expand the search range.  
(4)Cyclic adjustment: Adjust the signal sensitivity adjustment button to reduce the number of blue lights, reducing sensitivity, reducing detection range, to find the emission source accurately.  
(5)You can also turn on vibration mode, pressing the voice switch button,then it will be.

**b. Detect hidden cameras**  
(recommended to turn off the room lights )  
(1)Short press "mode button" , 3 infrared lights at the back will light up, short press the sensitivity adjustment button to control the flashing speed of infrared lights. Once you press the sensitivity button, flashing frequency will increase. Cycle adjustment can be adapted to the preferences of all kinds of people.

4



(2)Hold on the anti-spy detector in hand, and move it up, down, left and right to scan the surrounding environment via the laser (shielding the light in the house), and observe through the red filter on the detector. If there is a camera lens in front of you, you will find a very suspicious red bright reflective spot.

#### c. GPS magnetic field detection

Press the mode button twice to get the green light on, green signal indicator of this mode will be on the 1st level. Move the detector to the place you want to detect, once the blue lights are on, buzzer alarm is about to work, indicating that there is a magnetic field or suspicious objects with strong magnetic nearby. You can also press voice button to switch to the vibration mode.

#### d. Auxiliary lighting by flashlight

Press the "mode button" 3 times to switch the flashlight mode, top light up. With flashlight function on, when you detect suspicious devices, you can turn on this function to find it out. You can also use it as lighting in the dark.

5

#### 4. Common questions and answers

##### a. Why the silent sleep tracker can not be detected?

Answer: The commonly used sleep locator works once a day, and only works for 5-7 minutes at a time, so when the detector is detecting wireless signals, the locator may not send a signal.

##### b. Why the position of the real-time locator can not be accurately detected?

Answer: The real-time locator generally sends a signal every 10 seconds. Please do not move back and forth during detection. It is best to fix it in one position for more than 5 minutes, then change to other positions to continue detection.

##### c. Why does the detector terminal beep "DiDi"?

Answer: Signals are everywhere, and there are too many sources of interference signals. It is recommended to turn off your own known signal sources, such as mobile phones, WIFI routers, etc., during detection, and then decrease the sensitivity appropriately.

##### d. Why do the detectors near the windows of the house make such a loud noise?

Answer: The window is made of aluminum alloy, which forms a loop antenna, and the signal reception is particularly good.

##### e. Why the camera can not be detected?

Answer: It is possible that the camera is not working, or the camera is a wired one, not using WIFI signal.

6

#### 5. Applicable people

1. People who often use bank cards.
2. People who often stay in hotels on business trips.
3. Pretty ladies who are easy to be photographed.
4. People who often go to public entertainment occupancy.
5. People who often go to shopping malls for fitting.
6. People who respect their own privacy and others' privacy.
7. People who have access to and keep commercial secrets.
8. Security personnel in places where business secrets and technical secrets are kept.
9. Professionals who are capable of counter sneak shot and eavesdropping.
10. Whether the drone camera is quietly staring at your window.
11. Mortgage cars, used cars, guarantee companies, information finance companies.

7

#### 6.Package

- anti spy detector \* 1  
Type C charging cable \* 1  
User manual \* 1

8

#### FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.