

IR Module Camera

Model:MD200FHDW-IR

Quick Installation Guide

Product instructions

- 1、TF card: Maximum support is 128G
- 2、TYPE-C:DC5V/2A
- 3、WIFI:Support 2.4G wifi
- 4、Button :
 - 1)Press and hold the button for 5-8 seconds to start recording and automatically turn on Wi-Fi.
 - 2)Press and hold the button for 10-15 seconds to turn off the device and disable Wi-Fi.
 - 3)Press and hold the button for 20 seconds to reset the device.
 - 4)The data cable can be connected to a computer to read data.

1、 Main Function Description

- 1.1、 HD camera
- 1.2、 SD card storage
- 1.3、 Voice intercom
- 1.4、 Connect the computer
- 1.5、 Connect the wifi
- 1.6、 Alarm push
- 2、 Download for App
search for "YSEE"app in App Store/App Market,or scan the QR code below to download.



3、 Search for a device WiFi hotspot

- 3.1、 Please charge the machine before use


3.2、 Turn on the product

3.3、 Open the phone Settings,Click “WLAN”

,Find the WiFi hotspot

With “IPC

XXXX” to connect,The WiFi hotspot password:88886666



4、 Add Device

4.1、 Click "+" in the upper right corner to add the camera

5、 Select a connected network

6、 Select "LAN Search"

7、 LAN Search

8、 Successful connection

8.1、 Click on the play button to view the screen

Function introduction

Preview interface

1、 Set up

2、 HD/SD

3、 Video encryption

4、 Playback

- 5、 Digital zoom
- 6、 Full Screen
- 7、 Picture
- 8、 Sound
- 9、 Voice radio
- 10、 Photo album
- 11、 Microphone

After-sale instructions

- 1、 Please refer to the real product,the manual is for reference only.
 - 2、 The product is updated in real time,it shall upgrade without prior notice,please go to the official website for query.
 - 3、 The manual contains the basic function description of the product,please check the operation.
 - 4、 If there is any problem when using the camera,please contact the supplier or company in time.
 - 5、 We have tried our best to ensure the comprehensive and accurate manual content.But there may still be deviation from the actual situation,If there are any questions or disputes,please refer to the final interpretation of the company.
 - 6、 If you do not follow the instruction manual,any loss caused by it will be borne by yourself.
- This manual is suitable for consumer products.

Product warranty card

Product name		Model	
Date of purchase		Distributor	
Shopping mall			
Customer name		Occupation	
Telephone		Zip code	
Work unit			
Contact address			

Warranty period:A year.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with a minimum distance of 20mm between the radiator and your body.