



Wireless Charger
(BW-MWLC01) User Manual



Specification:	
Material	ABS
Interface	Type C
Input	5V 3A , 9V 2.2A
Output	15W (MAX)
Distance	≤8mm
Efficiency	≥75%
Product Size	6.4x6.4x0.8cm

Packing List
Magnetic wireless Charger x1
User manual x1

- How to Charge**
- 1 . Connect with Power Adapter
- 
- 2 . Put the Card Finder on Magnetic Wireless Charger

Note:The wireless charging icon on the card should be facing themiddle of the wireless charger



- Tip:**
1. It is recommended to use PD or QC 3.0 adapter.
 2. Do not disassemble this product at will.
 3. Do not use this product in a high temperature, humid environment.please stay away from fire and water.
 4. When using the power adapter, please make sure that the cable isfully inserted into the power adapter before plugging the adapter intothe power outlet.
 5. When using this product, please do not place metal foreign objects(such as keys, coins, batteries or jewelry)on it, other wise it willcause abnormal charging or hotness.

CE FC RoHS Recycle No Fire

Assembled in China

FCC Warning Statement
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment must be installed and operated with a minimum distance of 20 cm between the radiator and user body.