

REMOTE CONTROL

Operating Instructions



CZ01

PREDATOR GAME CALL REMOTE CONTROL

Setup & Operation Instructions (remote)

1. Add Batteries

Open battery panel on the device, place 1 new 23A 12V **battery(not included)** as indicated below, then close panel.
Tips: This battery may not be readily available at small supermarkets, but we ultimately chose it for the remote's performance. You can ask the supermarket staff in advance if they have "23A 12V Alkaline Batteries" available. Alternatively, you can search for "23A 12V Battery" on Amazon to purchase this battery. Thank you for your understanding!

2.Turn Power Switch On


Pull out antenna on the top of remote. Slide switch to ON to activate Remote

3. Sound Overlay Logic

Press 1 then 2. Sounds 1 and 2 will play simultaneously.
Press 3 again. Sounds 2 and 3 will play simultaneously, excluding sound 1.
Press 4 again. Sounds 3 and 4 will play simultaneously, excluding sound 2.
And so on, the next two sounds will play simultaneously, up to two sounds can be played simultaneously.

If two sounds are playing simultaneously, press the Pause button to pause them. Press the Pause button again to resume playing the two sounds.

If two sounds are playing simultaneously, press the Stop button to stop them.
If you only want one sound. Press sound 1 play sound 1, press the Stop button, then press sound 2 play sound 2.



Sound Model A

Coyote Female Invite
Coyote Female Howl
Coyote Male Invite
Coyote Male Howl
Coyote Pup Howl
Coyote Duet
Coyote Group Howl
Coyote Pup Frenzy
Coyote Whines
Coyote Distress
Coyote Fight 1
Coyote Fight 2
Coyote Pup Fight
Coyote Pup Distress 1
Coyote Pup Distress 2

Sound Model B

Cottontail Distress 1
Cottontail Distress 2
Baby Cottontail Distress
Jack Rabbit Distress
Hare Distress
Woodpecker Distress
Flicker Distress
Baby Squirrel Distress
Fawn Distress 1
Fawn Distress 2
Red Fox Distress
Groundhog Distress
Mouse Distress
Raccoon Distress
Raccoon Fight

FCC STATEMENT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WARRANTIES OR REPAIRS

This device comes with a 12 mouths warranty. If there are any problems with the product, please feel free to contact us and our team is always ready to help.

Please note this warranty does not cover damages caused by misuse, improper handling or improper repairs performed by someone other than an authorized service contractor. The warranty does not include shipping costs, which will be borne by you.

NOTE

- 1.The product is not waterproof. Please do not place it in water or use it in rainy days.
- 2.The remote control backlight consumes a lot of power. We recommend that you turn it on when in use and turn it off immediately when not in use.
- 3.When using Bluetooth mode, we recommend that the Predator Caller and phone be no more than 10 yards apart when connecting. Once connected, it can achieve about a 30 yards bluetooth range.

For Any Technical Questions, Please Feel Free To Contact Us. We Will Provide You 24-Hour Online Customer Service.