

USER MANUAL

Product Name: *RECYCLEFARM SMART TUMBLER*

PRODUCT SPECIFICATION

Model	RF-ST-FL-001
Material	Stainless steel, PC, Rubber (Silicone)
Operation	Lid opening/closing, Water intake measurement
Operation Days	3.5 Days
Size	70 x 70 x 285 (mm) / 33 x 58.5 x 46.5 (mm)
Power	Battery Model: 801225 / 3.7V 180mAh 0.666Wh

CAUTIONS FOR HANDLING

- - Do not use for any purpose other than intended.
- - Be careful when containing hot liquids as there is a risk of burns.
- - Since this is an electronic device with smart sensors, do not fully submerge it in water.
- - Charge using a USB Type-A cable. Do not use the product while charging.
- - Prolonged continuous use may cause overheating. Please take breaks between uses.
- - This is not a toy. Keep out of reach of children.

Feature

Opening the lid	White LED blinks, 1 vibration
Closing the lid	White LED blinks, 2 vibrations. After leveling (white dimming), water intake is measured (green dimming).
BLE connection	White and green blinking.

Smartphone connection

- - Please install the RECYCLEFARM app from Google Play and the App Store.
- - 1. To connect the tumbler, please turn on Bluetooth > open the RECYCLEFARM app > go to Devices > and tap Connect.
- - 2. Tap the tumbler from the scan list. Once connected, the green light on the cap will blink, and you will be taken to the connection screen.
- - 3. Once the tumbler is connected, tap the cap three times to register it on the ECO-DePIN blockchain. The LEDs will light up green, purple, blue, and then rainbow to confirm registration.

REFUND OR EXCHANGE POLICY

※ Please make sure to read the following before placing your order.

01. Exchange and Refund

- - Images shown are for illustration purposes only and may differ from the actual product color.
- - You must contact customer service before proceeding with any exchange or return.
- - When returning/exchanging a product, you must use the courier service that delivered the product. Additional costs due to using a different courier will be borne by the customer.

02. Other Notes

Exchange or refund is not possible in the following cases:

- - If 10 days have passed since the product was shipped.
- - If the product is damaged due to signs of use.
- - If the packaging is damaged, tags are removed, or there is contamination that prevents resale.

03. Customer Service

- - Contact: 070-4405-2111
- - Warranty: 3 months from the date of purchase (receipt required)
- - Closed on Saturdays, Sundays, and public holidays.

Guide of FCC Rules

a. Rule Part 15.19(a)(3): This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

b. Rule Part 15.21: The user manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help