

黑白印刷

尺寸: 207mm * 87mm


材质:105G哑粉纸双面,风琴折

87mm

69mm

69mm

69mm



III. Headset Pairing

1. After the two headsets are taken out of the charging box or turned on, the left and right headset will pair automatically and enter the connection mode with the device.
2. Turn on Wireless of the phone and search for wireless devices.
3. Find the wireless device: Elshell A2 and connect it, and there will be a prompt tone after the successful connection. (Note: If Elshell A2 cannot be found, please confirm whether the headset is turned on or you can turn off the Wireless of the mobilephone and then turn it on again.)

IV. Function Introduction

Pick up / hang up the phone	Press the multifunction button
Decline a call	Long press the multifunction button for 2 seconds
Music play / pause	Press the multifunction button
Last song	Double click the left headset multifunction button
Next song	Double click the right headset multifunction button
Lower the volume	Long press the left headset multifunction button
Increase the volume	Long press the right headset multifunction button
Siri or voice assistant	Three click the multifunction button

V. Product Parameters

Product name: Eleshell A2
Wireless distance: ≥10m (in barrier-free environment)
Input voltage: DC5V
Headset battery: 30mAh
Battery of charging box: 350mAh
Usage time: about 4.5H
Charging time of charging box: about 1-2H

Attention

- 1) Please use in a room without wall-like barriers; otherwise it may cause sound stuck / interruption.
- 2) The distance between the headset and the device should not be too far; otherwise the sound may be stuck / interrupted.
- 3) If there are a lot of WiFi and 4G signals around or other high-power electrical appliances when using, it is easy to cause sound stuck / interruption.

FQA

1. Q: How to solve the problem that only one headset can listen to music?
A: Put the two headsets back into the charging box and close the cover, take them out again to check whether the binaural mode is restored, if the earphones have not recovered, you can clear the pairing information to solve the problem.
2. Q: What should I do if the phone says "cannot connect"?
A: Delete the pairing record on the phone, then search and connect again to solve it.

Thanks

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.