

Instructions for Use

Design for extending service life

To extend the lifespan of this lamp, it is designed to automatically shut off after 5 hours of use. This is not a malfunction.

Remote control usage

Like many products that use infrared remote controls, please place the lamp at an appropriate distance and ensure that the light is not blocked by other objects. If the remote control is not responsive, try adjusting the angle of the remote or repositioning the lamp.

Rotating lens notice

The lighting effect of this product is created by a rotating optical lens. Due to the rotation mechanism, you may hear a faint sound if the lamp is shaken by hand, this is normal and not a defect.

Safe placement

Always place the lamp in a stable and secure location. Avoid placing it in areas where it may fall from a height, as this could cause damage.

Remote Battery care

If the remote control will not be used for an extended period, we recommend reinserting the insulation tab into the battery compartment to prolong battery life. To replace the battery please refer to the user manual for detailed instructions.

About motor speed

The motor's rotation speed is affected by the ambient temperature; the lower the temperature, the slower the speed. You can use the remote control to adjust the Nebula's rotation speed.



Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Shall include the statements:

- a) The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate."
- b) The statement "Even used batteries may cause severe injury or death."
- c) The statement "Call a local poison control center for treatment information."
- d) A statement indicating the compatible battery type (e.g., CR2025).
- e) A statement indicating the nominal battery voltage (e.g., 3.0 V).
- f) The statement "Non-rechargeable batteries are not to be recharged."
- g) The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns."


For products with replaceable button/coin cell batteries shall additionally include:

- a) The statement "Ensure the batteries are installed correctly according to polarity (+ and -)."
- b) The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries."
- c) The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations."
- d) The statement "Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children."

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**
- **KEEP** new and used batteries **OUT OF REACH** of **CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

USER MANUAL



Packing list




Caution

1. Please do not look directly at the light source output hole of the projector light while using it, otherwise it may cause eyes discomfort.
2. This product is suitable for dry environments, and please avoid using it in humid, overheated, and dusty environments. Good heat dissipation around the product, away from flammable objects or liquids.


Product Parameters

- Nebula color: Red/Green/Blue
- Starlight color: Green
- Light Source: LED
- Adapter: DC5V 1A (min)
- Power input: USB Type-C
- Product Size: 84x73x76mm
- Product Weight: 0.13KG
- Package Dimensions: 115mm*102mm*95mm

Panel introduction




Button description




To avoid strong light radiation, please do not disassemble the panel.

- Select scene effect**
- Power on/off**
- Aurora brightness adjustment**
- Select nebula color**
- Sleep aid mode**

How to use the Base ?



1. Insert the fixed plug of the base into the installation socket. (Figure 1)



2. Adjust different angles as needed. (Figure 2)

Remote control introduction



Replacing Battery (please follow steps as photo shows below):

- ① Remove the fixing screw and pull the battery tray out of the battery compartment;
- ② Place the new CR2025 button cell battery in the tray slot correctly based on the indicated cell polarity;
- ③ Push back the battery tray and fix the battery compartment with screw.

