

D23-说明书

尺寸：100*68mm

68 mm

100 mm

Kids' Video Talkie Instruction manual




Thank you for your purchasing Kids' Video Talkiev,
Please carefully read the manual before the using .



1. Appearance and Function Description

1. Volume Up
2. Volume Down
3. Power Switch
4. Antenna
5. Camera
6. Microphone
7. Display Screen
8. Video Switch Key & Voice change Button
9. Intercom Key
10. Charging Port
11. Lanyard Hole



2. Product Specification

Display Screen	2.0 Inch IPS
Camera	SP0A39
Battery Capacity	3.7V 500mAh
Language	English
Charging port	Type-c

1


Operate TEMP	-20 ℃ ~60 ℃
Storage TEMP	-30 ℃ ~70 ℃
Charging Power	5V=1A
Product Size	137x48x235mm

3. Function Operations

1. Turn the power switch to the "ON" status, the machine will automatically turn on and display our own camera. When the other party's walkie talkie is turned on, both parties will automatically connect and display each other's image.

2. Press and hold key 9 for voice intercom. This device features single-channel transmission, meaning the receiving party can only press and hold the talk key to transmit after the speaking party has finished and released the talk key.

3. Change the Image Display by pressing "M" video Switch Key . This unit has 4 screen display modes.



4. Voice Changer Function: Press and hold "M" key 8 for 2 seconds, then release to switch voice modes. When the device is turned off, the voice change mode resets to the original voice mode.

2

5. Volume Adjustment:

5.1. Short press the "5" key to increase the volume; press and hold it for pairing scan mode.

5.2. Short press the "6" key to decrease the volume; press and hold it to display the pairing QR code.

6. This product adopts a WiFi 2.4G transmission and connection mode. Each package contains two pre-paired walkie talkie, which cannot be connected to other devices for use. If multiple sets of the product are purchased, they can only be paired and connected one-to-one by set, and cannot be used interchangeably. Pairing Instructions (1) On one unit, press and hold the Volume Up key to enter pairing mode (camera scanning side); (2) On the other unit, press and hold the Volume Down key to display its QR code (for pairing).

7. Precautions:

7.1. This product is suitable for outdoor use.

7.2. This machine is not waterproof.

7.3. The indoor distance of the product shall be based on the.

3



Caveat

This product contains small parts that children can use under parental support;

Do not swallow parts lanyards need to be installed by adults;

Do not bend, pull or fold the parts;

Do not throw parts at people or other objects;

The package contains important information that must be retained;

Warning! This toy contains batteries that are non-replaceable.

Product name: Kids' Video Talkie
Product model: D23
Made in china



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.