

4. Input Audio

Insert audio cable (also) to audio input (No.15), you can enjoy music by your multimedia devices. The volume levelalso is controlled by your multimedia devices. (This function can be worked without the battery supply, we suggestingturn off the radio while using this function.)

5. Functions

Cushion blocking is soft and comfortable, while simultaneously sealing out sound.

Clearly shows radio frequency and indicates when the battery power is low on the digital display.

30dB SNR attenuation, you will in a quiet environment hearing music or radio.

Use 3 pieces 1 . 5V AAA batteries (charging battery pack also avaiable if you have purchased).

Comply with USA EPA regulation (Environment Protection Agency).

Support input equipment (smart phone, MP3 etc.) with stereo 3.5mm input jack.


R6 RADIO
HEARING
PROTECTOR



MODEL: R6-YB-BT
USER MANUAL

- The R6 is a perfect hearing protector with digital AM / FM stereo radio.
- The noise-cancellation is highly effective in noisy environment.
- The special design to protect hearing when you working in noisy conditions and Create a suitable working atmosphere by listening to the radio or your multimedia devices.

COMPONENTS



- | | |
|---------------------------------|--|
| 1 Headband with soft pad | 9 Board cover |
| 2 Cable connecting for both cup | 10 Digital display screen |
| 3 Stainless steel wires | 11 Mode button (AM / FM) |
| 4 Battery cover | 12 Increase band button |
| 5 Left side cup | 13 Decrease band button |
| 6 Earmuffs | 14 Function button |
| 7 Antenna | 15 Radio on/off with volume control knob |
| 8 Right side cup | 16 Audio input |

INSTRUCTIONS FOR USE

1. Radio On/Off

Turn the radio on/off through the knob (NO.13), keep turning can judge the level of the volume.

2. Display Screen

When turn on the radio, display screen showing battery power status, AM or FM mode switch by the mode button (NO.10).

3. Op

Single Click Mode Button: Swich Mode between AM/FM/BT (optional)

Click and hold Mode Button: The radio will searching for all avaiable channels and listing it from 1-19 (max).

Single Click Increase/Decrease Button: Increase/Decrease frequency band by 10Hz.

Click and Hold Increase/Decrease Button: The radio will automatical-ly searching upward or backward (depend on which button you pressed) until it gets a avaiable station.

Single Click FUC: Swich the channels one by one from the listing.

Click and Hold FUC: Delete the channel from listing. (only for the current channel already in the listing).

Store the current channel to the end of the listing. (only for the current channel NOT in the listing).

Tips: Use FUC button to programme your favourite listing.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2BROZ-R6-YB-BT