BASKETBALL SPEAKER

USER BOOK

Product name: Basketball speaker
BATTERY: 600mAh
Rating power:5W
Input:5V0.6A
Play time:2-3hours
Charge time1-2hours
Speaker: 4Ω5W
SNR: ≥85db
Frequency:80HZ--20KHZ

FCC Warning:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received,
including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device,
pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,
may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on,
the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.
RF exposure:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Vision- Not Support TF card
Long press 3 seconds switch to power on.
Long press - to down sounds volume,short press to previous sounds
Long press + to increase sounds volume,short press to next sounds.
MODE CHANGE: Double click the switch to change the mode (BT/FM)
TWS: Double click the - change to TWS mode(Two ball speaker power on ,anyone double click - to connect the TWS).

Vision- Support TF card
Long press 3 seconds switch to power on.
Long press - to down sounds volume,short press to previous sounds.
Long press + to increase sounds volume,short press to next sounds.
MODE CHANGE: Double click the switch to change the mode (BT/FM/TF).
TWS: Double click the - change to TWS mode(Two ball speaker power on ,anyone double click - to connect the TWS).
Use TPC cable to download Mp3 format Files to the ball speaker.



MADE IN CHINA