

User ' s manual

Mini PC

Precautions before use

Product precautions

1. This low-power RF motor is a certified product. Without permission, companies, merchants, or individuals are not allowed to change the frequency, increase power, or alter the characteristics and functions of the design.
2. Low frequency RF motors shall not affect flight safety or interfere with legitimate communication. If any interference is detected, it should be stopped immediately and can only be restored after the interference is resolved. Legitimate communication refers to wireless communication conducted in accordance with the law. Low frequency radio frequency motors shall not interfere with legitimate communication or industrial, scientific, and medical radio frequency equipment.
3. The product includes a CMOS sensor on the motherboard that uses a miniature battery. Please do not replace it yourself; If consumers replace batteries with the wrong model, it may pose a danger. Please handle the replaced battery correctly.

Product precautions

The company is not responsible for data loss or deletion caused by unconventional manual operations, maintenance, or other unexpected situations, nor is it responsible for any losses resulting from this.

1. Please regularly backup important data to avoid loss.
2. Do not disassemble the device by yourself; Otherwise, the warranty right will be lost.
3. The product manual and related software are regularly updated without prior notice. In case of any discrepancies with the product manual, please refer to the actual product.
4. Using the wrong type of charger may pose an explosion hazard; Always use the original charger.
5. This product is suitable for use in areas below an altitude of 2000 meters and is only suitable for non tropical areas.
6. In case of abnormal exit or unexpected power outage of the mini host system, a disk scan should be performed to promptly correct the errors.
7. If the mini host will not be used for a long time, please turn off the main power switch.
8. The ideal working temperature for mini hosts is 10 to 35 degrees Celsius, with a relative humidity of 30% to 80%
9. Do not frequently turn on or off the mini host; The interval between two power ups should be at least 10 seconds, preferably no less than 60 seconds.
10. Do not spill water, food, or other liquids on the mini console, and do not forcefully pull the HDMI or power cord.
11. Take dust-proof measures, avoid direct sunlight on the mini host, and stay away from strong magnetic fields.

Friendly Reminder

How to avoid the trouble caused by "rogue software" when browsing the Internet?

1. Be cautious when installing certain software, especially regarding additional plugins; If not needed, do not choose them for installation. When browsing certain websites, you may encounter a pop-up dialog box asking "Would you like to install XXX? " If you are unsure about the source of the software being installed, it is best to click 'No'. If you are unsure whether to install the software, it is best to click 'No'.

Ensure your online transactions are smooth and secure:

1. In order to effectively reduce the risk in the online payment process, it is recommended to ensure that the real anti-virus software and Microsoft Internet Firewall have been installed and enabled. It is very important to regularly check whether these programs are updated to the latest version.

2. Update the Windows operating system and install patches to protect system vulnerabilities. Regularly perform system updates or install patches in a timely manner.

3. Install genuine antivirus software and ensure regular updates.

4. Log in to a legitimate website, pay attention to the URL, and avoid logging into cloned websites.

5. Install authentication certificates, set long passwords, and recommend using various installation tools provided by the bank.

Prevent thunderstorms from causing damage to your computer:

During thunderstorms or rain, not turning off the computer and unplugging power cords, network cables, etc. may cause damage to components such as the motherboard and network card. In severe cases, it may result in burnt computer components, causing greater losses; D - During thunderstorms or typhoons, for safety reasons, try not to use computers or other electronic devices.

The power adapter is optional. The manual stipulates that if consumers use power adapters, they should purchase compatible adapters that have obtained CE certification and meet standard requirements.

Compliance FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure com

[Keys and interfaces]



1. USB port

2. Power button

3. Power connector

4. HDMI connector


5. Network

6. TYPE-C connector

7. 3.5 Earphone jack

[Quick Install Guide]

1. Connect the display device through a high-definition cable
2. Connect the Type-C power cord to the power supply
3. Connect keyboard and mouse via USB port or Bluetooth (own)
4. Connect to the network or WIFI. Attention: To turn on WIFI, you need to set it up later.



[How to change your audio playback device in the Windows operating system]

To connect speakers, headphones, built-in micro camera cameras, Bluetooth headphones, or other audio devices to a Windows computer, you need to select the device that Windows actually uses.



Seven day rule: Starting from the second day you receive the product (extended according to statutory holidays, including weekends)

★Within seven days, if there is a performance malfunction, consumers can choose to return, exchange, or repair it.