


60 × 90mm

VINTAGE CELLULAR PHONE-SHAPED
BLUETOOTH SPEAKER
MANUAL



MarTUBE®

Operating Instruction



Power on / off

- Press and hold on to the central power button on the device for 2 seconds to power it on; then, it will play a prompt tone for startup.
- As the speaker is on, press and hold on to the central power button for 2 seconds to power off the device; then, it will play a prompt tone of shutdown.

Play and pause / switch to another song when a song is being play

- Click the button Power source once to pause the song.
- Click the button Power source once again to resume the song.
- Click the button Power source twice to switch to another song.

Product Introduction

Product Name: Vintage Cellular Phone-shaped Bluetooth Speaker
Product Style:Pingu® Vintage Cellular Phone-shaped Bluetooth Speaker
Product Model: MG25-02
Product Dimensions: 55 × 55 × 150 mm
Package Size: 88 × 70 × 250 mm
Net Weight: About 190 g
Gross Weight: About 267 g
Battery Capacity: 2200 mAh
Service Duration: About 4-6h
Charge Duration: About 1.5-2.5h
Rated Input: 5V=1A
Rated Operation Power: 5 W
Bluetooth Connection Distance: 10 m
Bluetooth Version: 5.3
Product Materials: ABS+PVC+PC
Battery Category: Lithium-ion battery
Quality Inspection Certificate: Qualified
Execution Standards: GB 4943.1-2022and GB/T 9554-2021
CMIIT ID: 24446728007
Brand Owner: Shenzhen Martube Gift Culture Technology Co., Ltd.
Address: 2nd and 3rd floor, Building Q, 2nd and 3rd floor, Building M, Shasi High-tech Park, Shasi Community,

Operating Instruction

Bluetooth Connection

- will be on automatically after the product is turned on. Please pair the product with mobile device
- Bluetooth Name: Pingu Ring Ring

Bluetooth Reset Function

- Press and hold onto the button left function for 2 seconds to reset Bluetooth; then, it will play a "Bluetooth disconnection sound".
- If Bluetooth is connected successfully, it will play a "Successful Bluetooth connection sound".
- Bluetooth connection and playing music: the indicator light is always blue.

Indicator Description

- Bluetooth fails in connection: The blue indicator blinks quickly.
- Bluetooth succeeds in connection: The blue indicator is always on after the successful pairing; the prompt tone for Bluetooth connection will be played.
- Bluetooth is connected and music is being played: The blue indicator blinks slowly.
- When the electric quantity is lower than 15%, the red indicator blinks, and the speaker gives "A prompt tone for low power".
- Charging: The red indicator will be always on as the speaker is being charged; the green light will be always on as the speaker is fully charged.

Recording Function

- After powering on, press the Right Function Button once to enter recording mode and start recording.
- Press the Right Function Button again to stop recording and exit recording mode. (maximum recording time is 60 seconds;

Product Introduction

Shajing Street, Bao'an District, Shenzhen,Guang-dong,China
Contact Number: 0755-36637399
Entrusting Party: Shenzhen Martube Gift Network Technology Co., Ltd.
Manufacturer: Shenzhen Martube Gift Culture Technology Co., Ltd.
Address: 401A, Building 4, North Zone of Qianhai Shenzhen-Hong Kong Youth Innovation and Entrepreneur Hub, No. 5188, Mengzhi Avenue, Nanshan Street, Qianhai Shenzhen-Hong Kong Cooperation Zone, Shenzhen City, Guangdong Province

Operating Instruction

- new recordings will overwrite previous ones).
- To play the recording, press and hold the Right Function Button for 2 seconds while powered on to enter playback mode and start playing the most recent recording.
- In playback mode, pressing the Right Function Button once will restart the recording from the beginning. Pressing and holding the Right Function Button for 2 seconds again will exit playback mode.

Volume Adjustment

- Click the upper button on the right side to increase the volume gradually. When the speaker reaches its maximum volume, the prompt tone of the loudest volume will be played.
- Click the lower button on the right side to reduce the volume gradually.

Phone Call Function

- As Bluetooth is connected, click the left button to answer a phone call.
- During a phone call, click the left button to hang up the phone.
- When a phone call comes in, click the left button twice to reject the phone call.

Product List

Including:
Speaker×1,Button sticker×1, Greeting card×1,Type-C charging cable×1,Phone strap ×1,User manual×1



Pingu™

©2026 JOKER.

Attentions

- This product contains a built-in battery. Do not place it close to fire or into either fire or water.
- Do not squeeze or collide the product.
- Do not disassemble,assemble or transform the product yourself.
- Children under 14 shall be well attended in case that they play the product as toy and result in unnecessary accidents.
- Please stop using the product immediately if any abnormality is detected during the product utilization process.
- Please adopt the officially equipped Type-C charging cable.
- If power adapter is adopted for power supply, a power adapter with 3C certification and compliant with standards shall be purchased. The output power of such adapters shall not exceed 15 W.



Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Attentions

FCC Statement:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Substance Content of Harmful Substances in the Product

To comply with the relevant laws, regulations, and other requirements regarding the restriction of hazardous substances in electronic and electrical products in China, the declaration of harmful substances in this product is provided below, classified by components.

Component Name	Harmful Substance					
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
Printed Circuit Board and Components*	×	0	0	0	0	0
Metal Parts	0	0	0	0	0	0
Others	0	0	0	0	0	0

Component Name	Harmful Substance			
	(DEP)	(DEP)	(BBP)	(DEHP)
Printed Circuit Board and Components*	0	0	0	0
Metal Parts	0	0	0	0
Others	0	0	0	0

This table is prepared in accordance with the requirements of SJ/T11364. Some models of the product may not contain certain components listed in the table.
0: Indicates that the content of the harmful substance is not homogeneous materials of the components within the limit requirements specified in GB/T18762.
x: Indicates that the content of the harmful substance is at least one homogeneous material of the components exceeds the limit requirements specified in GB/T18762. Components marked with "x" are unable to substitute the harmful substances due to technological limitations and fields.
*Printed circuit board components include printed boards and their parts, capacitors, connectors, etc.

Electronic information products sold within the territory of the People's Republic of China must bear this symbol. The number inside the circle represents the environmentally friendly service life of the product under normal usage conditions.

Attentions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Product Warranty Instructions

The after-sales service of this product strictly follows the "Consumer Rights Protection Law of the People's Republic of China" and the "Product Quality Law of the People's Republic of China." The service includes the following:

- Within seven days from the day after you receive the product, if the product has a performance failure under normal use, you can enjoy free return or exchange service.
- From the eighth day to the fifteenth day from the day after you receive the product, if the product has a performance failure under normal use, you can enjoy free exchange or repair service.
- Within six months from the day after you receive the product, if the product has a performance failure under normal use, you can enjoy free repair service.

Non-warranty provisions

- Unauthorized repairs, misuse, defects, abuse, liquid damage, accidents, modifications, and improper use of non-original product accessories.
- Unable to provide a valid warranty card or the warranty period has expired.
- Damages caused by force majeure.
- Performance failure of the product and its accessories caused by human factors.

Warning

Do not store and use this speaker in a thermal environment.
The battery may explode if it is placed into fire or subjected to serious impact.
Please do not disassemble or assemble the battery on your own.
If the battery needs to be replaced, please deliver the speaker back to its manufacturer for replacement.

Battery Disposal
1. Battery must be removed from the product before obsolescing.
2. The product must be powered off before the battery is removed out.
3. Battery shall be treated safely. Please dispose it separately from domestic waste and place it into a designated recycling location or hand it over to an environmental protection recycling department for disposal.

Battery Removal Procedures
1. Remove product enclosure by tool.
2. Unplug the battery socket on the circuit board of the product and remove the battery.

Certificate of Compliance

Product Name: Vintage Cellular Phone-Shaped Bluetooth Speaker
Inspection Conclusion: **Qualified**
Production Date: _____

WARRANTY CARD

User Name	Date of Product Purchase	Y	M	D
Contact Phone Number				
Mailing Address				
Dealer Address				

(Please cut this form along the dotted line and return it with the goods.)