



Super dual latch deadbolt lock manual


Tuya Smart Bluetooth system & keypad setting operation



★ Door lock Left or Right open install guides



★ Installation diagram



Material	aluminum	Part number	
Door thickness	35mm-50mm	Code length	4-10 digits
Working temperature	-20°C~70°C	Working temperature	20%~80%relative humidity
Working power consumption	200mAh	Static power consumption	80uAh
Power supply	2500mA Lithium battery		
Unlock ways	Application, fingerprint, card, password, key		
user	1 Admin		
	Fingerprint50, card50, password50,		
	Application temporary password		
Product dimensions	Front	64(L)x144(H)x17(W)MM	
	Rear	73(L)x161(H) x48(W)MM	

★All specifications are subject to change without notice. All rights reserved

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.