

说明书94*62mm 157g双面铜版纸切圆角

ROSESELSA

Model: RS-09

ROSEZircon

User manual

Please read this manual carefully before using the product and keep it properly

First Connection

1. When using the device for the first time, open the earbud case and wait for the indicator light to turn on. The earbuds will automatically enter Bluetooth pairing mode.

2. Go to the Bluetooth settings on your device, search for the Bluetooth pairing name of this product, select and pair to connect (ROSE Zircon).
- Bluetooth

Device

RS-09

How to Wear

1. Identify the left (L) and right (R) earbuds, please wear them as shown in the diagram, or identify by the L/R markings on the earbuds.

2. Adjust the angle for proper wearing to prevent sound imbalance or leakage.
- Left Position

Right Position



ROSELINK APP

- You can search for "ROSELINK" in your phone's app store and download the app or scan the QR code on the left to download.

ROSELINK

Power Off Instructions

1. After use, place the earbuds in the earbud case. The device will automatically power off when the case lid is closed.

2. If the single earbud in use remains within the phone's signal range within 3 minutes, it will reconnect to the phone. Otherwise, it will automatically power off.
- Bluetooth

Device

RS-09

Power On Instructions

The earbuds will power on automatically after opening the earbud case.

Restore factory settings

*Use when switching between connected devices

- 1.1. When the case is open, hold the charging case button for 10s. The indicator light will flash red and white alternately 5 times.

2.2. After clearing the pairing, the earbud information can be found in the Bluetooth settings of the new device.
- Bluetooth

Device

RS-09

Charging

*Use a power adapter with CCC certification that meets all applicable standards.

Earbud Charging

Connect the USB-C cable to the case's charging port and plug the other end into the charging adapter to begin charging.

*This product is compatible with the standard 5V/1A charging rate from fast-charging devices. However, we do not recommend using high-power adapters or adapters that only support fast charging.

Charging Light Description

1. During charging, the charging light remains off. Press the button on the charging case to check the current battery level.

2. Battery Indicator: Press the button on the charging case to activate the light effect

• Red light for 3s: battery below 30%

• White light for 3s: battery below 70%

• Green light for 3s: battery above 70%

When charging is complete, the green light will flash 3 times.
- Bluetooth

Device

RS-09



Touch Features

Features	Left Earbud (L)	Right Earbud (R)
Power On	Power Off	Power Off
Power Off	Power On	Power On
Play/Pause	**	**
Next Song	/	***

Touch Features

Features	Left Earbud (L)	Right Earbud (R)
Previous Song	***	/
Volume +	*	/
Volume -	/	*
Game/Music Mode	Connected status	Connected status
ANC Mode Switching	/	Connected status
Voice Assistant	Turn voice assistant on/off when connected	/
Answer Call	During incoming calls	During incoming calls
End Call	During a Call	During a Call
Decline Call	Incoming call	Incoming call

Parameter Information

Bluetooth:	Bluetooth Version: 6.0	Effective Range: >10m
Charging Case:	Battery Capacity: 400mAh	Charging Time: <1H
	Input: 5V = 1A	Output: 5V = 0.1A
		Standard Voltage: 3.7V
		Full Charge Voltage: 4.2V
		Charging current: 800mA ± 10mA
Earbuds:	Battery Capacity: 46mAh	Charging Time: 1.5H (approx.)
	Input: 5V = 0.05A	Standard Voltage: 3.85V
		Full Charge Voltage: 4.4V
		Charging Current: ≤46mA

Safety Information

Before using or operating the device, please read and follow the instructions below to avoid dangerous or illegal situations.

Note

1. In areas where wireless devices are prohibited, please comply with local regulations and turn off the device.

2. When using this device, keep a minimum distance of at least 15 cm from implanted medical devices (such as pacemakers).

3. When using the device to listen to music or make calls, it is recommended to use the minimum volume necessary to avoid hearing damage. Prolonged exposure to high volume may cause distraction and lead to accidents.

4. Please use and store the device and its accessories within a temperature range of -10°C to 45°C. Extreme high or low temperatures may cause device malfunction.

5. Keep the device and its accessories in a well-ventilated, cool place away from direct sunlight.

6. Keep the device and its accessories out of children's reach. Children may accidentally damage the device and its accessories, or swallow small parts causing choking or other hazards.

7. This device is not a toy. Children should use it under adult supervision.

Warning

1. Please comply with local laws and regulations. Do not use the device while driving, operating machinery, or engaging in work that requires attention to surrounding sounds.

2. Do not use the device during thunderstorms. Lightning may cause malfunction or electric shock.

3. Do not expose the device to direct sunlight, such as on a car dashboard or windowsill.

4. Keep the device away from heat sources and exposed flames.

5. Do not use heating tools (such as hair dryers, microwave ovens, etc.) to dry the device.

6. Do not disassemble or modify the device or its accessories. Unauthorized disassembly or modification will not be covered by our warranty.

7. Do not subject the device and its accessories to strong impact or vibration.

8. Using unapproved or incompatible power sources or chargers may cause malfunction, fire, explosion or other hazards.

9. Stop using the device before cleaning and maintenance. Do not use strong chemicals, cleaning agents or strong detergents to clean the device. Please use a clean, dry soft cloth to wipe it instead.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.