


材质：128G双铜，正反面单色印刷，折页

USER MANUAL

Thank you for your purchase!!
We love our customer and appreciate your feedback.
If there are any questions or concerns,
please contact us at **support@shopayil.com**



A: SoundFit Mini Speaker B: USB-C Charging Cable
C: User Manual D: Lifetime warranty
E: 100% Customer Satisfaction Guarantee



A detailed line drawing of the front panel of the device. At the top is a large circular speaker grille with a complex, maze-like pattern. Below the grille is a small rectangular display screen showing the time '09:25'. Below the screen is a circular power button with a power symbol. On either side of the power button are two arrow-shaped buttons pointing outwards. At the very bottom is a small, horizontal rectangular button. Numbered callouts point to the following components: 1 points to the left arrow button, 2 points to the right arrow button, 3 points to the bottom rectangular button, 4 points to the display screen, and 5 points to the speaker grille.

- ① Volume - / Previous track
- ② Volume + / Next track
- ③ Power on / Power off / Play / Pause / Siri voice assistant / Call / Time setting / Pairing disconnected
- ① ② Alarm setting / Factory reset
- ④ Display
- ⑤ Microphone

AYL
Power on: press and hold for 2s

AYL flashing

09:25

My Device
SoundFit Mini

Clock is displayed after pairing succeeds

OFF
Power off: press and hold for 2s

Display off

03

	Answer incoming call
	Ending call
	Siri voice assistant

06

	Clock setting
	Time setting
	Confirm

	Alarm 01/02 setting
	Off/on setting
	Time setting

AYL

Tap x4

Tapx4 again AYL flashing to reconnect

Disconnected

Factory Reset

Press and hold both left and right buttons for 5s

Restore factory settings

Important Tips

- Do not use power adapters without safety certification.
- For charging, it is recommended to use a 5V/1A certified power adapter.
- When you hear the low-battery alert, charge the speaker as soon as possible.
- During charging, the display will blink "----". When fully charged, the display will remain solid "----".

The diagrams illustrate the following wear methods:

- Top Left:** The device is worn on a wrist, secured by a strap with a buckle.
- Top Right:** The device is worn on a finger, secured by a ring.
- Bottom Left:** The device is worn around the neck, attached to a cord.
- Bottom Right:** The device is worn on a belt, secured by a buckle.

Product Model	SoundFit Mini
Wireless Version	5.3
Battery Capacity:	3.7V/600mAh
Playback Time	8-10 hours (50% volume)
Charging Time	Approximately 2.5 hours
Charging Input	5V=0.3A
Speaker Unit	2W
Product Size	2.78" x 1.72" x 1.30"
Product Weight	2.01oz±0.18oz

Q1: What kind of charger should I use for the speaker?
A: You can use any standard USB-C 5V charger. For best performance, a 5V/1A charger is recommended.

Q2: What if there is noise or interruptions during playback?
A: The speaker works normally within 10 meters of the phone in an unobstructed environment. Beyond 10 meters, or if there are obstacles, noise or interruptions may occur.

Q3: Why does the speaker automatically shut down when powered on but not in use?
A: To reduce power consumption, the speaker will automatically shut down if there is no operation within 10 minutes.

Q4: Why can't the speaker connect to a previously paired phone?
A: If connection fails, delete the speaker from your phone's Bluetooth device list. Then turn Bluetooth on again, search for the speaker's name (SoundFit Mini), and manually re-pair.

Q5: Why won't the speaker power on, or why is it frozen?
A: If the speaker does not turn on by pressing the power button for 2 seconds, plug in the charger and try again after 30 minutes. Alternatively, press and hold the power button for 8–20 seconds after charging to reset the speaker.

Q6: Why can't the speaker synchronize and calibrate the time when connected to a mobile phone?
A: When connecting an Android device, please allow the speaker to "access, retrieve, insert, send, and delete SMS messages." Note: Some Android devices may not support time synchronization. If this happens, try connecting with an iOS device instead.

Precautions for Use:

1. Please read this instruction manual carefully before use and keep it for future reference.
2. It is recommended to use the included charging cable to charge the speaker.
3. Fully charge the product before first use.
4. Use only certified adapters that have passed national safety certification.
5. If the product will not be used for a long time, charge it at least once a month to maintain performance.
6. Do not use this product in extremely cold or hot environments (outside the range of 41°F~95°F). If used beyond this range, the product may automatically shut down to protect the internal circuit.
7. When charging in a high-temperature environment, the product may automatically stop charging to protect the battery.
8. Storage Temperature: 23°F~95°F, RH < 70% (recommended 77°F±41°F).

Important Safety Instructions:

1. Do not disassemble or attempt to repair this speaker yourself, as it may cause product damage or personal injury.
2. Do not use the speaker in dusty, humid, excessively dry, or high-temperature environments.
3. Keep the product away from heat sources, direct sunlight, excessive dust, and strong mechanical vibrations.
4. To reduce the risk of fire, do not cover the product with newspapers, tablecloths, curtains, or similar materials while charging.
5. This speaker is rated IPX6 waterproof, meaning it can withstand heavy splashes and rain. However, do not submerge the speaker in water or use it while swimming or diving.
6. If the product is damaged (e.g., power cord or plug damaged, liquid ingress, foreign objects inside the device, or malfunction), please contact us at support@shopayl.com for assistance or replacement.
7. The speaker includes overcharge protection; however, it is recommended to unplug the charging cable once the speaker is fully charged.
8. The maximum ambient operating temperature should not exceed 104°F.

*Wireless connection enabled devices such as mobile phones, tablets, etc., can all be used, while this "User Manual" uses "mobile phones" for illustration.

15

subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide Reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Warning:** Changes or modifications made to this device not expressly approved by **Accessorisr Corp.** may void the FCC authorization to operate this device.
- Note:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.
- RF exposure statement:**
- This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.

RF exposure statement:
This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.

17