


MeWaz?

SOUND MACHINE
MEW!!



Lighthouse

Sound Machine & Night Light

User Manual

Quick Start



1. Connect Power:

Plug the included Type-C cable into the device and connect to a power adapter.



2. Turn On:

Press and hold the power button (bottom right) for 2 seconds.



3. Choose a Sound:

Press the play button and use the next/previous buttons to find a soothing sound.



4. Adjust Light:

Press the light mode button to select a sleep-friendly color. Warm colors recommended for bedtime.



5. Set Volume & Brightness:

Use the volume and brightness buttons to find comfortable levels.




6. Display Screen On/Off:


Press and hold the Snooze and Favorites touch zones together for 3 seconds to turn the display screen off or back on.

Quick Reference


Model: MEDO000LIW1817016-A



Front



Back



Bottom

Control Buttons

No.	Component	Instruction
①	LED Display Screen	- Supports 12/24-hour time formats, adjustable brightness with percentage display, and time display. - When the alarm is active or snoozing, the time on the LED panel flashes. Low battery condition displays "LO" on the panel.
②	Snooz	- Press the snooze button briefly to pause the alarm; it will ring again after 10 minutes, and the time display will flash. - Press and hold the snooze button to turn off the alarm; the time display will return to normal.
③	Favorites	- Short press to play the default ambiance. Long press to cancel. - Customize favorites via the Smart Life app.
④	Rightness Decrease	- Press to decrease night light brightness.
⑤	Light Color	- Press to cycle colors.
⑥	Brightness Increase	- Press to increase brightness.
⑦	Volume Down	- Press to decrease volume.
⑧	Previous Track	- Press to play the previous sleep aid sound.
⑨	Play / Pause	- Press to play/pause sleep aid sounds.
⑩	Next Track	- Press to play the ext sleep aid sound.
⑪	Volume Up	- Press to increase volume.
⑫	Charging Port	- Supports only Type-C charging cables.
⑬	Power	- Long press 3s to turn on/off.
⑭	Child Lock	- Long press 3s to enable/disable the child lock.

Network Configuration

Setting Up Your App (For Enhanced Features)

1. Download the Smart Life app from the App Store or Google Play.
2. Connect your device to 2.4GHz WiFi (not 5GHz).
3. Long press the Light Color button  and the Play/Pause button  until the WiFi icon flashes on the display.
4. Follow the in-app instructions to complete setup.



App Compatibility

- Requires iOS 13.0 or later
- Requires Android 6.0 or later

What You Can Do With The App

- Control your device remotely (great for checking on your child).
- Configure cry detection notification and auto soother.
- Create custom combinations of sounds and lights.
- Set timers to automatically turn off sounds and lights.
- Set schedules for bedtime and wake-up.
- Configure the perfect wake-up routine.
- Access all 360 colors in the RGB spectrum.

Best Practices

Creating Bedtime Routines (Tips from Parents)

1. 30 Minutes Before Bed: Switch to a warm amber light and play gentle music
2. 15 Minutes Before Bed: Dim the light to a soft red, switch to white noise or womb sounds

3. Bedtime: Keep soothing sounds on at a low volume with minimal red light or no light
4. Morning: Set the sunrise alarm with bird sounds for a gentle, natural wake-up

Recommended Sound and Light Combinations

- For Deep Sleep: Brown noise + dim red light
- For Anxious Children: Heartbeat or womb sounds + soft amber light
- For Stormy Nights: Rain sounds + warm orange light
- For Morning Wake-Up: Birds singing + gradually brightening green or blue light

Safety & Care

ROOM PLACEMENT

- For optimal sound, place the MeWaii Sound Machine away from your bed to fill the room. If external noise is an issue, position it between your bed and the noise source to reduce disturbance.

SOUND VOLUME ADVISORY

- To protect hearing, especially for children, keep volume low, maximize distance from the device, and limit usage time. Never place the device directly next to anyone's ears, including infants, in any setting.

BEFORE USE

- Do not disassemble or repair the product yourself. Keep it away from water, heat sources, and fire. Avoid using corrosive detergents; clean only with a damp cloth or alcohol wipe.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use. Use only the provided charging cable. Avoid placing the speaker near ears to prevent hearing damage.
- Do not place or store near water or damp areas, and avoid falls or immersion in liquids. Keep out of children's reach; intended for adult use only.
- Do not repair or modify the device. Avoid covering it during use to prevent overheating, fire, or injury. Stop use if the product or cord is damaged. Keep away from heat and do not lift or pull by the cord.
- Ensure proper ventilation by not blocking vents or placing on soft surfaces. Never insert objects into the device or spill liquids on it.

Troubleshooting

Q: Device won't turn on?

A: Make sure the power cable is properly connected

Q: Can't connect to app?

A: Ensure your phone is on a 2.4GHz WiFi network and try resetting the device

Q: Alarm not working?

A: Check if the alarm disable function is activated (white indicator light will be on)

Q: Display issues?

A: Short press the child lock button to turn display on/off

Care Instructions

- ☒ Clean with soft, slightly damp cloth
- ☒ Keep away from water and heat sources
- ☒ Do not use harsh cleaning products

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. **If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.