


Vero

Product Specifications

Name	Massager	Charging Voltage	5V
Mode	Vero	Charging Current	1.4A
Connection Method	Bluetooth and 2.4G	Noise	36–45db
Weight	1280g	Battery Capacity	900mAh
Dimensions	256 × 109 × 89mm	Operating Voltage	14.8V
Run Time	45–90 min	Material	ABS+Silicone
Charging Time	240 min	Waterproof Rating	IPX4
Charging Method	USB Type–C		

Redefine Intimacy, No Matter the Distance.

Instructions



Offline Mode

- Power Button** Press and hold this button for 1.5 seconds to turn the device on or off. Press it again to start or pause the thrusting function.
- Function Button** Press to switch between modes.
- + Button** Short press to increase the thrusting length. Long press to increase the thrusting speed.
- Button** Short press to decrease the thrusting length. Long press to decrease the thrusting speed.

App Control Mode

- Power Button** Press and hold this button for 1.5 seconds to turn the device on or off. Press it again to start or pause the thrusting function.
- Function Button** Press to switch between interaction modes.
- + Button** Short press to increase the thrusting range. Long press to increase the thrusting speed.
- Button** Short press to increase the thrusting range.

Instructions for Assembling the Soft Stroker

► **Step 1**
Ensure the device is turned off before disassembling the soft stroker. Gently pull the soft stroker out from the device main body.

► **Step 2**
Before assembly, inspect the replacement soft stroker to ensure it is clean and free of oil, water, or any other conductive liquid. Keep the clitoral-shaped side facing upwards. Insert the soft stroker into the main body, then turn on the device to enjoy.

Instructions for Cleaning

► The charging port is not waterproof. Do not allow any liquid to enter it.


► The main body can be cleaned by wiping with a wet tissue or towel. Do not rinse or submerge in water.

► The interior of the device opening is not waterproof. Clean only with a dry tissue or towel.

► The inner soft stroker accessory is fully waterproof and can be washed with water. Ensure it is completely dry before placing it back into the main device.

Precautions

- **Precautions**
- This device is intended for adults only. It is not a contraceptive device. Please keep it out of the reach of children.
 - During use, avoid applying excessive force and exercise caution to prevent injury.
 - Do not share this product with others. Should you experience any discomfort during use, discontinue use immediately.
 - Regularly inspect the product for damage. If any damage is found, discontinue use immediately.
 - This is the flexible sensor area. Please handle with care for best performance: Be gentle! Avoid sharp objects and don't poke or twist the surface. Keep it dry. Contact with water other liquids can damage the sensors.



Bluetooth Connection Instructions

To connect, press and hold the power button for 3 seconds to turn on the device. Then, open the app, enable Bluetooth, and tap the "+" in the top right to pair. You can start controlling the device once the connection is successful.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.