

Quick instructions

1. Activate the Locator Tag and prepare to pair

To press the round button for 3 seconds around, then release it after hearing “beep”. (If it is failure to pair in 2 minutes, please try it again.)

2. Device Pairing

- ①Open the pre-installed App “Find My” in your Apple device.
- ②Close the Locator Tag to your Apple device, tap the “Items”, select “+”, and click “Add Other Item” .
- ③Find the device named “WSL-1”, and click “Connect”.
- ④Fill in “Name Item” to name your device and choose an emoji for it.
- ⑤Agree to register the “WSL-1” with your Apple ID.
- ⑥Click “Finish” to complete the pairing.

3. Enable lost mode

- ① Open Apple's self built-in "Find My" app, click on "Items" at the bottom of the screen, click on the item's name;
- ② Under "Lost Mode", click "Enable";
- ③ Follow the instructions on the screen and click "Continue" to enter the contact phone or email settings.
- ④After clicking "Next" to check the information, please click "Enable" again to complete the setting.

4. Erase your device

- 1 Open Apple's self built-in "Find My" app, click on "Items" at the bottom of the screen, and then click on the item's name;
- 2 Find "Remove Item" at the bottom of the list and tap "Remove" to complete the operation.

Main Functions

1. Locate your item

When the device and the iphone are beyond the Bluetooth distance, the device cannot be linked in the "Find My" app. Available options: Lost Mode, select Enabled. Enter your contact number etc. If the device is disconnected from your iphone for an extended period of time and there are other iPhones nearby, you will receive notifications and the latest location in your "Find My"app.

2. Play Sound

The iphone and the device are within the Bluetooth range (usually about 20 meters), in the " Find My" APP,click " Play Sound", and the device will make a sound to help you quickly find nearby items.

Instructions for device button

1.Turn On

After installing the battery, press the button on the product briefly and then lift your finger. Release the button once you hear a “beep” prompt tone. [The product enters pairing mode. If no pairing and binding is completed within 2 minutes, it will time out.]

2.Open pairing broadcast

Press and hold the button briefly, then release it after hearing a "beep" prompt tone. [Enter pairing mode. If no pairing and binding is completed within 2 minutes, it will time out.]

3.Device re-enters pairing state

Press the button briefly and then release it. After hearing one "beep" prompt tone, the device will exit the shutdown state and re-enter the broadcast pairing mode.

4.Restore factory setting

Click the button 3 times consecutively, then long press at the 4th clicking. Then you will hear a long “beep” sound. Your Locator Tag is successfully restored to the factory setting, and you can pair it again.

5.Turn off the Locator Tag

Press the button for approximately 5 seconds until you hear three beeps, then release the button. The device will be turned off.

FAQ

1.When can the device be located by other iPhone?

When the device is disconnected from the owner's iPhone for a period of time, the device can start to be located by other iPhones, and the owner can start to obtain the location of the device. Our stick holders are official authorized by the Apple MFi certification. Therefore, they work exactly the same as the Apple AirTag. Just for your reference.

2.How to prevent the device from being used for malicious tracking?

When someone malicious attach the tracking holder to your cane or stick for getting your location, you will be notified by below 2 ways


- ① If you have an Apple device such as iPhone, iPad, or iPod touch, you will get a reminder on the Apple device; this function is available on Apple devices with iOS or iPadOS 14.5 and later.
- ②If someone attach his/her holder on your walking equipment (cane or stick) for getting your location illegally, even if you don't have an Apple device to receive the notification, the holder will make sounds to remind you, when it leaves far away from the Apple ID registered devices.

3.How to protect my privacy?

Only you and the person you shared the location can see where your Locator Tag is. Your location data and history are never stored on the Locator Tag itself. Devices that relay the location of your Locator Tag also stay anonymous, and that location data is encrypted every step of the way. So not even Apple knows the location of your Locator Tag or the identity of the device that helps find it.


4.How do I replace the battery ?

- ① Gently peel off the silicone sticker attached to the back battery cover to expose the screw slots underneath.
- ② Insert a Phillips screwdriver into the four screw slots on the battery cover, then twist to remove the screws and open the cover.
- ③Use a flat-head tool to pry open the battery cover (a small amount of force is required).
- ④ Remove the old battery and insert a new button cell battery with the positive (+) terminal facing up (standard battery, available at supermarkets).
- ⑤ Close the battery cover and use a Phillips screwdriver to sequentially screw the four small screws into the screw slots.
- ⑥ Completion.



5.What is the Find My network? And how does it work?

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, Mac, or the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or MOYAGOA , can view its location.



常见问题

1、设备什么时候可以被别的苹果手机定位？

当设备与主人的苹果手机断开一段时间后，设备可以开始被别的苹果手机定位，主人可以开始获得设备的位置。

2、如何防止设备被用于恶意跟踪？

当别人的设备混入您的随身物品时，并跟踪超过一段时间，您会通过以下两种方式被提醒：


- ① 如果您有 iPhone, iPad, 或者 iPod touch 等苹果设备，您会在苹果设备上获得提醒；此功能在 iOS 或 iPadOS 14.5 及以后版本的苹果设备上有。
- ② 如果您没有苹果设备，如果别人的 Locator Tag 离开了自己的主人，并跟踪了您一段时间，当它移动时，它会发出音乐，以提醒您。当然，如果碰巧您身边的朋友正带着设备，或者您搭乘的地铁上很多人都有这个设备，也不必担心。因为只要设备没离开主人身边，就不会触发这样的提醒。

3、如何保护我的隐私？

您的设备在哪里，只有您自己能看到。您的位置数据和历史记录绝不会存储在苹果和 MOYAGOA 的服务器中。传递您设备位置数据的设备也始终保持匿名，而且位置数据在查找的每一步都有加密保护。因此，苹果和 MOYAGOA 都不知道您的设备的位置，以及帮忙找到它的设备是何身份。

4、如何给设备更换电池？

- ①把贴在背面电池盖上的硅胶贴轻轻撕开，露出里面的螺丝旋转槽
- ②使用十字螺丝刀插入电池盖的4个螺丝旋转槽，旋转并打开电池盖
- ③使用平头的工具把电池盖子撬开 (需要用一点力气)
- ④取出旧电池,并装入新的纽扣电池,电池正极朝上 (标准电池,可在超市购买)。
- ⑤合上电池盖板,使用十字螺丝刀把4个小螺丝依次旋入螺丝旋转槽中
- ⑥完成



5、“查找”网络是什么？如何工作？

Apple Find My 网络提供了一种简单、安全的方式，可以使用 iPhone、iPad、iPod touch、Mac 上的 Find My 应用程序或 AppleWatch 上的 Find Items 应用程序在地图上查找兼容的个人物品。只需将您的兼容产品与 Apple Find My app 配对，即可与您的 Apple 设备一起查看。如果您的物品丢失了，您可以将其置于丢失模式以向可能找到它的任何人显示消息和联系信息。Find My 网络是加密和匿名的，因此没有其他人，甚至 Apple 或 MOYAGOA 都无法查看其位置。

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Watch, iPad, iPadOS, macOS, and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Important tips

When pairing a device with Findmy app, the Apple devices will link to the Apple server. Pairing may fail because of network problems. The following actions are recommended:

- ① Change the Apple devices’ s network, such as switching between WiFi and mobile network;
- ② Factory reset of the equipment: Click the button 3 times consecutively, then long press at the 4th clicking. Then you will hear a long “beep” sound. Your Locator Tag is successfully restored to the factory setting, and you can pair it again. (If failure to pair and connect the Apple devices and Locator Tag within 2 minutes, you need to restart to pair again.)
- ③ Re-pairing with the Find my App
- ④ Restart phone

重要提示

设备与查找app配对时，需要链接苹果服务器，如出现无法配对的情况，一般是您使用的网络暂时无法链接苹果服务器，建议如下操作：

- ① 更换手机网络，如:WIFI和手机网络之间切换；
- ② 对设备恢复出厂设置：连续单击3次+第4次长按，听到一个长“嘀”指示音(约1秒)，即成功恢复出厂状态,并进入配对模式【2分钟未配对绑定,即为超时】
- ③ 与查找APP重新配对；
- ④ 重启手机

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Regulatory Safety Information

WARNING: KEEP BATTERIES OUT OF REACH OF CHILDREN Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.

If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poison Information Centre for fast expert advice.

KEEP BATTERIES OUT OF REACH OF CHILDREN

- Keep in original package until ready to use
- Call a local poison control center for treatment information.

Australia: 13 11 26 Canada: 1-800-268-9017(Ontario), 1-800-567-8911(BC), 1-800-463-5060 (Quebec) US: 800-498-8666. Verify suitable. emergency call numbers for your country.

- Do not use if the compartment is not secure.
- Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous.
- Risk of fire and burns.
- Do not recharge, disassemble, heat (~20°C +70°C) or incinerate.

Rated voltage: 3V
Capacity : 225mAh

产品使用手册
Product User Manual

POWER SENIOR

Works with
Apple Find My