

Doorbell/Pager Instruction Manual

I. Product Parameters

Wireless Distance: Approximately 1200 meters in open, interference-free areas

Ringtone Tracks: 38 chordal music tracks

Controllable Volume: 4 volume levels + mute flashing light

Host Rated Voltage: AC100-240V/50-60Hz

Relative Humidity: ≤95%RH, non-condensing

Remote Control Voltage: 12V 23A alkaline battery

Receiver Plug: Standard EU plug

Receiver Standby Current: <2.0mA

Remote Control Power: ≤14dBm

Wireless Frequency: 434.6MHz

Operating Temperature: -10℃~+60℃

Host Dimensions: 85*80*20mm

Sub-host Dimensions: 73*39*17mm

II. Operating Instructions

Code Learning

1. Press the () button to select the doorbell music you like; short press the () button , and after hearing the selected music, short press the () button again. After hearing the "ding-dong" sound, trigger the transmitter. After hearing the "ding-dong" sound again, it means that the learning was successful.
2. The code learning state lasts for 15 seconds, after which it will automatically exit the code learning state.

This product has a power-off memory function, so there is no need to reset the ringtone and volume after power-on. It can support up to 20 remote controls and the host to freely learn and pair codes.

Clear code

1. Unplug the power cord of the host, press and hold the () Code Learning button while powering on for more than 3 seconds. After hearing the "ding-dong" sound again, the code clearing is successful. Release the Code Learning button then. If want to use the device again, you need to relearn the code.

Music Selection Button: Short press the music selection button () to select different music tracks.

Volume Button: Short press the volume button () to adjust the volume from high to low and then to mute.

III. Doorbell Remote Control Installation Methods

Doorbell Remote Control Installation Method 1 (With Double-sided tape)

1. Open the remote's back cover, insert the battery, and stick double-sided tape to its bottom.
2. Clean the area thoroughly before attaching the tape, pressing it firmly to secure it.

Doorbell Remote Control Installation Method 2 (With Screw Locking)

1. Open the remote's back cover and drill a hole at the mounting point.
2. Tighten the included screws, insert the batteries, and close the remote control faceplate.

IV. Precautions

1. Test the appropriate location before installation.
2. After applying the double-sided Tape, hold it down for 30 seconds before releasing for a stronger bond.
3. Do not install the product on metal doors or keep it as far away from metal doors as possible.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.