



FHD
1080P

Wireless Vehicle Backup Cameras with Touch Screen

User Manual



Model No. : _____

Please read the manual carefully
before operating the equipment.

Content

1.Introduction.....	2
2.Packing List.....	3
3.Product Function.....	4
4.TF Card.....	5
5.Monitor Install.....	6
6.Camera Install.....	7
7.System Setting.....	8
A.Pairing.....	9
B.System.....	10
C.Image.....	11
D.Camera.....	12
E.Mirror.....	13
F.Record.....	14
G.Mode.....	15
H.Play.....	16
8.Trouble Shooting.....	17
9.Product Parameter.....	19
10.Product Warranty	20
11.Label and FCC Statement	21

1.Introduction

Notice! Please read all instructions carefully before installing the product. Improper installation will void the warranty.

Thank you for purchasing our wireless vehicle backup cameras with touch screen! With the manual, you will be able to install and operate the product correctly. The camera system is installed as an aid to assist in video recording of your driving rearview and driving records. The camera system should not be used to replace standard rearview mirrors or other rearview mirrors built into the vehicle.

In some jurisdictions, it is illegal for a person to drive a car that is equipped with a television viewer or screen that is located behind the driver's seat or anywhere that is directly or indirectly visible while operating the vehicle.

Please read the entire manual and follow the instructions and warnings carefully. Failure to do so may result in serious damage and injury, including life. Be sure to comply with all applicable local traffic and motor vehicle regulations regarding this product.

Usage:

1. The wireless vehicle backup cameras with touch screen is designed to help drivers safely detect people and auxiliary items that help avoid losses. It must be used correctly. Using the product is not a substitute for driving a safe, legal vehicle.
2. When driving a vehicle in reverse, you should always check the situation around the vehicle while reversing, just as if the vehicle did not have wireless backup cameras system. If you only look at the monitor for driving operations, unnecessary injuries and losses may occur.
3. The wireless vehicle backup cameras with touch screen can perform long-term cycle recording, record all situations of the vehicle moving forward, reversing, entering the intersection or on the sidewalk, and display the driving picture in real time to assist the driver in driving the vehicle safely.
4. Always remember that the area displayed by a car wireless video recordings system is limited and it will not display the entire panoramic image behind your vehicle.



2.Packing List

Model Number Packing	Picture	X1036AWT-1 ☐	X1036AWT-2 ☐	X1036AWT-3 ☐	X1036AWT-4 ☐
		X1026AWT-1 ☐	X1026AWT-2 ☐	X1026AWT-3 ☐	X1026AWT-4 ☐
		X686AWT-1 ☐	X686AWT-2 ☐	X686AWT-3 ☐	X686AWT-4 ☐
10.36inch Screen					
10.26inch Screen					
6.86inch Screen					
TF Memory Card		1	1	1	1
User Manual		1	1	1	1
Car Cigarette Lighter and Cable		1	1	1	1
TYPE-C ACC Cable		1	1	1	1
Screen Stand		1	1	1	1
Stand Screws 2pcs		1	1	1	1
Stand Locking Screws 1pc		1	1	1	1
Screwdriver		1	1	1	1
Screen Stand Rubber Pad		1	1	1	1
Adapter		1	2	3	4
Wireless HD Camera		1	2	3	4
Camera Power Cord 2.5 m		1	2	3	4
Small Allen Wrench		1	2	3	4
Camera Mounting Screws 4pcs		1	2	3	4
Camera Antenna		1	2	3	4

3.Product Function


Item	Function	Specifications
Pairing	Pairing	Supports Screen pairing with single or multiple cameras
System	Languages	Simplified Chinese/Traditional Chinese/English/Korean/Japanese
	Operation	Capacitive Touch Operation
	Interface	Graphical Menu
	Time	Year/Month/Day
	Reverse Delay	Set different reversing delays for multiple cameras respectively
	Reverse Line	Set multiple cameras with different reversing lines respectively
Image	Brightness	Set the value from 0 to 100
	Contrast	Set the value from 0 to 100
	Color	Set the value from 0 to 100
	DIM	Turn On or Turn Off DIM
	Volume	Set the value from 0 to 9
	Reset	Turn On or Turn Off (reset the image parameter)
Mirror	Normal Screen	 Display Normal Screen
	Mirror Screen	 Display Mirror Screen
	Vertical Normal Screen	 Display Vertical Normal Screen
	Vertical Mirror Screen	 Display Vertical Mirror Screen
Mode	Display Mode	Display different split screens from multiple cameras respectively

Camera	Camera 1	Turn On or Turn Off Camera 1 Screen
	Camera 2	Turn On or Turn Off Camera 2 Screen
	Camera 3	Turn On or Turn Off Camera 3 Screen
	Camera 4	Turn On or Turn Off Camera 4 Screen
	Cycle Time	Set Cycle time from 1 to 50
	Automatic Cycle	Turn On or Turn Off Automatic Cycle
Record	Video Record	Turn On or Turn Off Video Record
	Sound Record	Turn On or Turn Off Sound Record
	Video Cycle Record	Turn On or Turn Off Video Cycle Record
	Format	Formatting TF Memory Card
Play	Playback	Manage or Playback the Recorded Video

4.TF Card

The quality of TF memory card has a great impact on the stability of video recording. To record videos safely, please use SanDisk, Kingston, Toshiba, TF cards from major brands such as Samsung. Speed certification must be at least Class10. It's recommended to use a TF card with a memory of 32GB-256GB.


Warm Reminds: When replacing a new TF card, it needs to be formatted before recording video.



5. Monitor Installation

First Way to Install Monitor

Car Cigarette Lighter Installation



Second Way to Install Monitor

Car ACC Installation





6.Camera Installation

Camera installation: Find the appropriate installation location in the license plate accessory, and mark it with a pen, and drill screw holes of appropriate size. Use screws to fix the camera to the rear of the car.


The reversing trigger wire (red wire) needs to be connected to the positive pole of the reversing light. Finally, use the camera extension wire to connect to the monitor.

Warm Reminds:

The camera power cable is connected to the cable of ACC and GND of car light.



7. System Setting



Screen OFF: Turn off the screen of monitor.

Pairing: Pairing the monitor with the camera.

System: Set time, reversing delay, reversing line and language.

Image: Set brightness, contrast, DIM, volume, auto-brightness or reset.

Camera: Turn on or off cameras 1,2,3,4 and automatic cycle & cycle time.

Mirror: Set up 4 different mirror images as needed.


Record: Turn on or off video recording, audio recording, loop recording and TF memory card formatting.

Mode: Select the display mode according to your needs. There are 6 different display modes for option.

Play: Manage or playback the recorded video.

Return: Return to menu interface or return to previous level interface.

A.Pairing





Touch & Light up screen and select "Pairing" to enter the 20 second countdown interface for camera pairing. Then need to power on the camera and pair with the monitor. The system will automatically complete the pairing of the current camera and channel, and a clear picture of the camera will appear on the monitor after that. If pairing is unsuccessful within 20 seconds, need to power on camera and pair again. Click the "Return" in the lower right corner to return to the menu interface.

Warm Reminds:

1. Press the channel switching button and select the channel to be paired with the camera (Camera 1 2 3 4), then the system will configure Right operation.
2. It only takes 20 seconds to power on camera during pairing.
3. If the camera communication is not completed within 20 seconds after pressing the Pairing, you need to pairing again.
4. During the pairing operation, keep the monitor as close to the camera as possible.
5. In the quad-split screen, only the channel switching key and the power key are effective, the other buttons cannot be pressed.

B.System





Touch & light up screen and select "System" to enter settings:

1. Time: year, month, day, hour, minute, second.
2. Reverse delay: The reversing screen extends the display time.
3. Reverse line: Turn on or off the display of reversing line.
4. Language: Simplified Chinese, Traditional Chinese, English, Korean, Japanese.



Click "Return" in lower right corner to return to menu interface.

C.Image





Touch & light up the screen and select the "Image" to enter image settings. Click "-" or "+" to set screen brightness, contrast, color, volume, auto-brightness, and turn on or off the reset. Click the "Return" in the lower right corner to return to the menu interface.

D.Camera





Touch & light up the screen and select the "Camera", enter the camera settings, turn on or off cameras 1, 2, 3, 4, and turn on or off the automatic cycle, and set the cycle time. Click the "Return" in the lower right corner to return to the menu interface.

E.Mirror





Touch & light up the screen and select the "Mirror" to enter the mirror settings. 4 different mirror images can be set as your needed: Front Direction, Horizontal Flip, Vertical Horizontal Flip 180°, Flip vertically 180°. Click the "Return" in the lower right corner to return to the menu interface.

F.Record





Touch & light up the screen and select the "Record" to enter recording settings. Click the plus and minus keys to turn on or off the recording, loop recording settings, or the format. Click on the lower right corner "Return" to return to menu interface.

G.Mode



Touch & light up the screen and select the "Mode" to enter the display mode required by the picture mode setting. The monitor has 6 different split screen display modes. Click the "Return" in the lower right corner to return to the menu interface.

H.Play



Touch & light up the screen and select the "Play", enter FOLDER, and press the play button to playback the video. Click the "Return" in the lower right corner to return to the menu interface.

Note 1: If you need to play back the video on the computer, please remove the TF memory card and insert it into the computer.

Note 2: When the TF card is full, the monitor will delete the earliest manual/timed recording files one by one and continue recording.

Note 3: Once the TF memory card is formatted, all files in the TF card will be lost, so please operate with caution.

8.Trouble Shooting

No.	Problem	Trouble Shooting
1	Moniator No Power	-The car engine does not start, start the car engine -Incorrect wiring. Check wiring -The monitor is powered off by default, press the power button to turn it on
2	Camera No Power	-The car engine does not start, start the car engine -Incorrect wiring. Check wiring
3	Monitor No Signal	-Check if there is power to the camera (make sure the power supply voltage is stable), pair the monitor and camera again.
4	Monitor Shadow	- Check whether the brightness and contrast are adjusted correctly

5	No Loop Recording	-Enter the recording settings and turn on loop recording.
6	Unstable Connection	- Check if there is any interference and make sure the camera antenna is tight to the camera.
7	TF card cannot be written into	-Use CLASS10 TF card. Please make sure the TF card with 32GB-256GB. When replacing a new TF memory card, you need to format the TF card, and return to video recording, and start to recording video again.

Aftersale Service

Any problem about product, please contact us:

Working Time: Monday - Friday, 8AM - 6PM

Email Address: andyzq19910818@gmail.com

9.Product Parameter

Name	Wireless Vehicle Backup Cameras with Touch Screen
Brand	CAIVIDEO
Monitor	IPS full viewing angle 1600*600 resolution
Camera	Standard CAA13-1 wireless AHD camera
WiFi	2.4G WiFi, 2400~2483.5MHZ, Support 802.11b/g/n wireless protocol
Module	MARS
Operation	Capacitive touch operation
light Sensitive	Support
Brightness	400cd/m2
Record Mode	Support multi-channel simultaneous recording
Material	ABS
Video format	H.265
Language	Simplified Chinese, Traditional Chinese, English, Korean, Japanese.
Speaker	Monitor with built-in speaker
Storage	Class10 TF memory card≤256G
Power supply	Car charger DC9-36V power supply (TYPE-C interface)
USB Cable	3 meters long DC5.5MM straight cable with thread
Wire	Car charger cable 4m with indicator + TYPE-C
Work Temp.	-20℃ — 70℃
Product Size	245*100*13MM
Weight	Net weight: 1.32lb Gross weight: 3.3lb

10.Product Warranty

Product Warranty: One Year Manufacturer

Our company guarantees the product for one year from the date of purchase. We reserve the right, at our sole discretion, to repair or replace defective equipment. Our company is not responsible for damage caused by misuse, improper installation or improper handling of electronic components, and it is not our responsible for any form of consequential damages. If the product has the following defects, it is not covered by the warranty:

1. Damage to product appearance or functionality caused by unauthorized modification;
2. Damage caused by disassembly or attempted disassembly or use of substandard or unauthorized accessories;
3. Abnormal wear and tear caused by abuse;
4. Failure or damage due to negligence or improper maintenance;
5. System failure caused by using unsuitable or unauthorized accessories;

Warm Reminds:

During the warranty period, if there is a quality problem with wireless vehicle backup cameras with touch screen, it will be sent back after prepaying the freight. If the returned product has complete accessories, complete packaging, and the appearance does not affect the secondary sales of the product, we will process it after receiving the return. Refund prepaid freight and return and exchange processing.

Product Warranty Card

Buyer Name: _____

Cellphone: _____

Email: _____

Address: _____

Order Date: _____

Order No.: _____

Product: _____

Model No.: _____

11. Label and FCC Statement

1. Label

FCC ID: 2BS3F-X1026AWT1

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

(This label will also be reflected on the product packaging box)

2. FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.ct.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.