




Professionally Test And Recommend Each Toy For You!

- 1 * WARRANTY & AUTHENTICATION
- 2 * BRAND STORY
- 3 * AFTER SALES SERVICE
- 4 * HOW TO USE



WARRANTY & AUTHENTICATION

① Vitality, Act Now!

The default warranty period for the product is 6 months.

Scan the QR code below to

Extend the warranty period to 2 years

Verify the authenticity of the product

Exclusive customer service



* Or visit the "Warranty" menu on the official website to complete your product registration.

* Note: Warranty service is valid only under normal use of the product.

-1-



BRAND STORY

UTIMI

Professional testing and recommendation of each toy

All self-developed products are selected through online screening. Also, tested and recommended by professional players, and judged by the platform as excellent products before they hit the shelves.

Choose Utimi, no longer bad mood by buying inferior products.

Evolution

In 2014, UTIMI was founded.

In 2016, UTIMI became the largest seller in the Sexual Wellness category on Amazon.

In 2018, UTIMI has 100+ patents for adult products.

Over the years, we found a large number of problems with adult products such as short life span, poor use, no privacy packaging, and use of materials that are harmful to the body. To solve these problems, we carried out a comprehensive strategic upgrade and determined to allow users to easily find the right and reassuring products.

Pleasure Products

Utimi provides "high-quality, safe, creative, effective, cost-effective" erotic products, as well as one-on-one expert customer service.

-2-

Each product is selected and developed from the real needs of users, careful analysis and research on the pain points of similar products. We focus on product rationality and how to use it longer and safer.

Each product is tested by professional players around the world, and receives their unanimous recommendation, and then is judged by the platform to be excellent before it goes on sale.

For each order, we invite users to participate in a satisfaction survey. The number of participants reaches more than 50.

Products with a rating or a recommendation ratio separately lower than 4.3 or 80% will be permanently banned from sale. It's our priority to collect users' experience.

Interactions

Freedom, equality, respect, sharing, tolerance!

Sex is a fundamental human need, one that transcends gender, age, color, class, and culture, shameless and unyielding one with no obscurity and no relocation, a spiritual life that humans enjoy equally!

Utimi unites a group of certified professional sex educators, sexology experts, sex toy connoisseurs, and also brings together a group of men and women, LGBTQ, SM players who seek excitement and love to explore and share. You can easily communicate and share with us, and together we can create a very inclusive spiritual paradise.



OUR SLOGAN:

Professionally Test And Recommend Each Toy For You!

-3-



AFTER-SALES SERVICE

If you are not satisfied with the product please contact us first, we will try our best to solve your problem as soon as possible.

Other questions, such as: warranty and authentication, instructions for use, product advice, product representation, etc.

Please contact us through the following ways.



support@utimi.com

+1 5323758507

(GMT+8:00 am-06:00 pm Workday)

http://www.facebook.com/Utimitoys

+1 5323758507

http://www.utimi.com



support@utimi.com

+1 5323758507

(GMT+8: 9:00 pm - 06:00 am Workday)

https://www.facebook.com/Utimitoys

+1 5323758507

https://www.utimi.com/



-4-



EN EN

SPECIFICATION

Name: APP Remote Lesbian Strap-On Dildo Set OEM Custom
| Double-ended Wearable Vibrator Panties | Female Personal
Massager with Bullet Vibrator | PU Pants + Rose Red Dildo
Origin: China
Material: Silicone + ABS + PU + Zinc Alloy
Dildo Overall Size: 198mm * φ38mm
Dildo Diameter: 3.8cm
Insertable Length: 15cm
Bullet Part Max Diameter: 3.8cm
Waist Circumference: 68-115cm (Dual adjustable belts: short
belt 30cm, long belt 60cm)
Thigh Circumference: 74-90cm (Adjustable range: 16cm)
Net Weight: 500g
Battery Capacity: 600mAh
Charging Method: Magnetic Charging
Charging Time: 120 Minutes
Working Time: 60 Minutes
Maximum Noise: < 50db
Waterproof Level: IPX6
Function: Vibration
Function Description: 8 vibration modes for G-spot + 8
vibration modes for C-spot stimulation
Accessories List: 1 x Main Product 1 x Wearable PU Leather
Pants 1 x User Manual 1 x Magnetic Charging Cable 1 x
Remote Control 1 x APP Instruction Card

-5-

INSTRUCTION OF BUTTON

Charging Time: About 2 hours
Working Time: About 1 hour
Power off while charging; cannot power on during charging.
Working status: LED light flashes with vibration frequency.
Charging: Power indicator flashes white slowly.
Fully charged: White light stays steady on.
Country of Origin: China
Battery Capacity: 600mAh
Rated Working Voltage: 3.7V
Charging Cable: Magnetic Charging Cable

Power Button:

Press and hold for 2 seconds to power on into standby
mode.
Short press to switch among 8 vibration modes.
Press and hold for 2 seconds to power off.

Remote Control Instruction: Under standby mode, short
press to switch 8 vibration modes; press and hold for 2
seconds to pause.

-6-

HOW TO USE

Open the package, read the user manual for operating
instructions, and fully charge the product before first use.

1. Take out the wearable accessory and
leather pants.



2. Unbutton the crotch of the leather pants,
place the main product into the reserved
mounting hole, then fasten the buttons.



3. Assemble and adjust the belts according
to your waist circumference and put it on;



4. The thigh part can be adjusted to fit your
actual thigh size.



5. Remove the product step by step after
use, then clean it thoroughly.



-7-

MATTERS NEEDING ATTENTION

Insert the USB charging cable into the charging port of the
product.

Plug the USB charging cable into an available USB port of a
PC or an AC power adapter.

When connected properly, the indicator light will flash once
every few seconds.

When the device is fully charged, the indicator light will stay
on steadily.

Before connection, please confirm the USB port of the
computer is properly matched with the product. Please fully
charge the product before first use or after a long period of
inactivity. To maintain battery performance, fully charge the
device at least once every six months. Do not use any USB
charging cable that is not included with the product. The
original USB charging cable is not waterproof. Please keep it
away from water to avoid electric shock, burns or other
safety accidents.

-8-

CLEANING & STORAGE

Clean the product immediately after use. After cleaning, pat
it dry gently with a clean, dry lint-free cloth or towel.
If there is lube or dirt on the product surface, wipe it with a
soft cloth first, then clean it with mild soap or neutral
detergent.

The main body is washable and can be rinsed directly under
running water.

Do not rinse with hot water or boil the product. Never clean
it with chemical solvents such as benzene or alcohol, to
avoid deformation, discoloration and material damage.
Storage

To prolong the service life, it is recommended to apply a
proper amount of talcum powder on the TPE part for
maintenance. When not in use for a long time, store it in a
dry and ventilated place, keep away from direct sunlight
and out of the reach of children.

⚠ Warning Never immerse the product in water while
charging, otherwise it may cause electric shock, short
circuit, fire and other safety hazards.

⚠ Warning Do not store the product in places exposed to
direct sunlight, high temperature or high humidity. It may
cause discoloration, cracking, overheating and even fire risk.

-9-

EN EN

TROUBLESHOOTING

The product does not work normally / the telescopic or
rotating function is relatively weak.
After pressing the power button, did you press and hold it
for 2-3 seconds?
Is the device fully charged?
Please release the power button until the device cannot be
turned on, then fully charge it. If it still doesn't work after
several attempts, the battery may be damaged.

This product cannot be charged. (The indicator light does
not flash.)
Is the charging cable disconnected from the user or the
charging port? When using a computer USB port, if your
computer enters standby mode, the product will not charge.
Please check if your computer is in standby mode. There may
be dust and stains on the charging port. Before charging
again, please wipe it with a dry cloth or cotton swab. Is the
product fully charged? When the product is fully charged,
the indicator light will stay on continuously.

The charging process cannot be completed (the indicator
light does not turn off).
Dust and dirt may adhere to the charging port. Please wipe
it with a dry cloth or cotton swab first before charging. If the
indicator light is still on after 180 minutes of charging, it may
be caused by poor contact of the charging contacts.

-10-

EN EN

SAFETY AND WARNINGS

If you are using medical devices, receiving treatment or
pregnant, please consult a doctor before using this product.
If you feel any discomfort during use, please stop using it
immediately and consult a doctor or pharmacist.
When you find any abnormal operation of the product,
please stop using it and turn off the power immediately to
avoid personal injury or accidents.
Please keep this product out of the reach of children to
prevent them from accidentally swallowing product parts or
accessories.

Please use the provided USB charging cable for charging
and ensure correct connection, otherwise it may cause
overheating or damage to the device.
To avoid electric shock or burns, keep your hands dry when
unplugging the charging cable.
Please turn off the power before charging, otherwise it may
cause malfunctions, overheating or even fire.
Please turn off the power before cleaning the product,
otherwise it may cause malfunctions, overheating or
damage.

When unplugging the attached USB charging cable, hold
the connection part and do not pull the cable, otherwise it
may accelerate cable aging and cause electric shock, short
circuit or even fire.

-11-

SAFETY AND WARNINGS

When charging is not needed, please unplug the USB
charging cable, otherwise it may cause short circuit due to
dust and moisture, leading to electric leakage or fire
accidents.
Please regularly clean the connector of the USB charging
cable to avoid short circuit or fire caused by dust
accumulation.
Do not use or trample the product violently.
If you feel uncomfortable during use, please stop using it
immediately.
Do not use the product when extremely tired or drunk to
avoid other discomfort.
Do not charge, use or store the product in extreme
temperatures, otherwise it may cause burns or damage to
the product.
Do not pull or peel off the silicone on the surface of the
product forcefully to avoid damaging the product.
Do not bend or pull the attached USB charging cable
excessively, and do not wrap the charging cable around the
product for storage, as this may damage the charging cable.
Do not use the attached USB charging cable if it is damaged,
as it may cause electric shock, short circuit or fire.
Do not share this product with multiple people to avoid the
spread of sexually transmitted diseases.

-12-

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.