TWS无线蓝牙耳机
使用说明书

在使用本产品时请仔细宣读说明书

TWS Wireless Bluetooth Headphone
Usage Manual

Please read the instructions carefully when using this product

---

熟悉您的蓝牙耳机

规格及特征

状态	操作	LED灯	声音/语音提示	备注
开机	长按功能键2秒	绿灯闪亮	语音提示	
关机	长按功能键4秒	白灯闪亮	语音提示	
左右耳机配对	耳机从充电仓取出，耳机白绿灯交替闪烁，（主耳机白绿灯交替闪烁，副耳机指示灯熄灭）打开手机蓝牙搜索到耳机点击配对，配对成功后语音提示“已连接”。	主耳机白绿灯交替，副耳机指示灯熄灭。	语音提示	
对耳配对完成			语音提示	
来电			来电报号	
接听电话	短按一下功能键			
挂断电话	短按一下功能键			
拒接电话	长按功能键2秒			
语音控制功能	长按功能键			手机支持此功能
音乐播放	短按一下功能键			
音乐暂停	短按一下功能键			
上下一曲	双击右耳功能鍵下一曲，双击左耳功能鍵上一曲			
音量调整	三击右耳功能键加 三击左耳功能键减		最大音量提示音	

Specifications and Features:
Bluetooth Version: V5.0 + EDR
Bluetooth Protocol: A2DP, AVRCP, Headset, Handsfree
Frequency Range: 2400.0-2483.5 MHz
Working Scope: 10 meters
Charging Time: about 2 hours

Specification:

Status	Operation	LED light	Prompt voice reminding	Remarks
Turn on	Keep press homekey 2 Sec	Green light flash	Voice prompt	
Turn off	Keep press homekey 4 Sec	White light flash	Voice prompt	
TWS pairing	Earbuds white-green light flash alternately when pick up from charging case(Main earbud white-green alterna tely flash, the indicator light of the auxiliary earphone is off)Open mobile and search,then click. will hear “connected” voice prompt	Main earbud white-green alternately flash, the indicator light of the auxiliary earphone	Voice prompt	
TWS paired			Voice prompt	
Call inco ming			Phone number reminding	
Answer Call	Short press homekey			
End call	Short press homekey			
Refuse call	2 sec press homekey			
Voice control	Long press homekey			Mobile compatible
Music play	Short press homekey			
Music pause	Short press home key			
Music track	Double-click R earbuds to next song, double click L earbuds for previous song			
Volume control	Three-click R to plus volume,Three-clieck L to reduce volume		Max volume prompt voice	

疑难排解

若您未能将耳机与移动电话连接上，请尝试以下步骤：
确保耳机已[illegible]范围。
---确保耳机已与移动电话配接。
确保移动电话的蓝牙功能已被启动。
---确保耳机在移动并没有障碍物阻挡。
●若以上步骤不能解决问题，请将耳机充电，或将您的移动电话再次重新开机。

如您发现耳机声音小或无法调节音量，是因为部分安卓系统手机不支持同步控制蓝牙设备音量功能，请如下操作：音量调大/调小：手机音量按钮和耳机音量按钮，都需独立操作调大/调小；

保养及维修

将耳机放进口袋或袋子时，先关掉耳机，避免意外按下耳机功能键。
---切勿将耳机暴露在液体或潮湿的地方。
---切勿使用研磨性溶剂清洁耳机。
切勿将耳机放置在温度极高或极低的地方，最佳存放环境为-10℃到+60℃，否则会影响耳机的使用寿命。
---切勿将耳机弃置在火焰之中，避免爆炸危险。
切勿将耳机与尖锐的对象，会导致刮痕或损坏。
---切勿将任何物件插入耳机内，会损坏内部组件。
-切勿尝试拆卸耳机。
●如果长时间不使用耳机，请将耳机放置在干燥的地方，并每隔超过一个月要及时给耳机充电，以保证电池及耳机的可靠性能，远离温度变化很大及多尘的地方。

给耳机充电时，请使用不超过5V 1A输出的充电器。禁止使用快充，以免对耳机电池造成损伤。

合格证
Q.C.Passed

产品保修卡

该卡为产品保修凭证，请妥善保管

产品名称:	产品型号:
购买日期:	客户名称:
联系方式:	

产品维修记录

日期	不良现象	解决方案

保修卡

产品型号：______ 购买日期：______

用户姓名：______ 联系电话：______

退换货原因：______

保修条款：
1、保修服务只限于正常使用情况下的有效保修期内，由于产品本身质量问题引起的非人为损坏的故障；
2、自购买日起30天内，如果有发生性能故障（非人为损坏），免费退换货；
3、产品主体自该购买日起，一年内给予保修；
4、超过保修期或不在保修范围内仍需要本公司维修的，我方酌情收取维修费；

注意：当您将保修卡撕毁或丢失时，您将失去保修机会，我司拥有资料的最终解释权。

Troubleshooting

If you are unable to connect your headset with mobilr phone, please try following steps:
Ensure your headset is turned on and fully charged.
Ensure the headset has paired with your mobile phone.
Ensure your mobile phone’s Bluetooth is activated.
Ensure the headset is moving without any barrier.
If all above steps can’t solve the problems, please charge the headset, or restart your mobile phone.
If the volume is low or can’t be adjusted, it is because some parts of Android mobile phones can’t control the volume of Bluetooth device.
Please do as following: Turn up/Turn down, the of volume of mobile phone and earphone are required to operate +/- indepentently.

Maintenance and Repair

Turing off your headset before placing it in your pocket or bag,if the MBF is accidentally activated, your mobile phone may place an unintended call.
Do not expose the headset to liquid, moisture or hmidity as it is not waterproof.
Do not use abrasive cleaning solvenets to clean the headset.
Do not expose the headset to extreme termperature conditions, the best store temperature range is from - 10 to +60C, otherwise the life of the headset will be influenced.
Do not dispose of the headset in a fire as it may result in an explosion.
Do not bring your headset with a sharp objects as this will cause scratched and damage.
Do not plug any objects into the headset, which cause the internal components.
Do not attempt to disassemble the headset.
If you dont use the headset for a long time, please place it a dry place.
Charge the headset on time if not use it over 1 month, which make sure the stablity of battery and performance.
Stay away the big change of temperature and dusty place.
Please don’t use the adaptor over 5V 1A ouput when changing for headset.
Don’t use the fast charger in case of the damage for headset battery.

Certificate of conformity
Q.C.Passed

Product Warranty Card

This card is the product warranty certificate, please take good care of it

Product name:	Model:
Date of purchase:	Customer name:
Contact:	

Product maintenance record

Date	Undesirable phenomenon	Solutions

Warranty Card

Product model：______ Purchase date：______

User name：______ Contact number：______

Changing or Refunding：______

Warranty clause:
1、warranty service is limited to the normal use of the effective warranty period, due to the quality of the product itself caused by non-human damage to the fault;
2、since the purchase date within 30 days, if there is a performance fault (non-human damage), free return;
3、the main product since the purchase date, within one year warranty;
4、more than the warranty period or not within the scope of warranty still need our company to repair, we accept the maintenance fee as appropriate;

Note: when you tear or lose the warranty card, you will lose the chance of warranty, and we have the final right to interpret the data

---

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.