

Welcome to REC-NOTE!




请先下载 APP，REC-NOTE 需要经过 APP 绑定操作才能继续为您提供更优质的服务。

Please download the APP first. REC-NOTE needs to go through the APP binding operation to continue providing you with better service.

ZH

使用说明

1. 部件说明



① 录音模式切换开关

⑤ MagSafe 皮套

- ② REC-NOTE 状态显示屏
- ③ 开机/录音按钮
- ④ 磁力充电端口
- ⑥ MagSafe 铁环
- ⑦ 磁力充电线


2.REC-NOTE 状态



- ① 设备等待绑定
- ② 设备固件正在升级中
- ③ 设备 WiFi 模式已打开
- ④ 设备蓝牙模式已打开
- ⑤ 设备正在进行录音
- ⑥ 设备正在充电
- ⑦ 设备电量不足
- ⑧ 设备当前电量
- ⑨ 设备已充满电
- ⑩ USB 连接中


3.简易操作说明

3.1 开关机



- 开机/一般唤醒：点按(0.5s) Power 键，如上图。

3.2 绑定设备



注意：绑定操作需要经过 APP，下载 APP，可以通过首页的二维码或者 App Store 上搜索设备。

- 完成账号注册并登录，进入 APP 主界面；
- 点按 Power 键唤醒设备屏幕图标；
- 点击 APP 左上角搜索图标，然后点击“下一步”按钮对设备进行绑定操作；
- 绑定成功后，设备屏幕将显示上图蓝牙图标。

3.3 开始/结束录音

录音模式分为两种, 语音高清录音模式和人声高清录音模式


- 语音高清录音模式:



当开关向上开启时, 如上图, 设备处于语音高清录音模式。在这种模式下, 设备可以捕捉手机的振动, 然后输出准确的记录。


注意:为了更有效地使用此模式, 请将设备放在 **Magsafe** 皮套中并将其紧贴在手机背面。

- 人声高清录音模式:



当开关向下关闭时, 如上图, 设备处于人声高清录音模式。在这种模式下, 您可以把设备拿在手里, 或者把它放在桌子上开始录音。

- 开始/结束录制:



长按 Power 键 2 秒, 设备震动一次后, 将开始录音, 屏幕将显示录音图标, 如上图。
在录制状态下, 长按 Power 键 2 秒, 设备将振动两次, 表示录制结束。

3.4 文件同步到 APP




- 点击 APP 右上角的图标。进入录音同步界面，可以看到设备存储的录音文件。
- 同步方式有两种，蓝牙传输和 WiFi 传输

蓝牙传输：




当文件比较小时，可以选择蓝牙传输方式，方便快捷。

WiFi 传输：



当文件比较大时，录音同步界面会提示选择 WiFi 传输方式。

3.5 文件转写，生成总结和思维脑图




Audio Name: Note Saturday, August 17 at 22:40

Language: English ▾

Submit


- APP 主界面，显示已经同步成功的录音文件。
- 点击文件卡上的“转写”按钮，如上图。底部出现弹窗选择要转写的语言，提交后，稍等片刻，文件卡上的内容会显示转写后的内容。
- 转写成功后点击文件卡，进入到详情页。
- 详情页里可以看到转写后的转录列表、总结和思维脑图等。

3.6 在 APP 上聆听您的录音



- 当您在线结束录制后，您的录制文件将很快显示在 APP 上，单击播放按钮来聆听您的录制。
- 注意：**如文件未出现，请刷新或者检查“同步”。

3.7 录音文件重命名和删除




- 您可以向左滑动文件卡，来重命名和删除文件。

备注：获取更多详细操作说明，请进入 **APP** 的操作指南页面。

邮箱： service@storycloud.ltd

Instructions

1. Component Description



- ① Recording mode switch
- ② REC-NOTE Status Display Screen
- ③ Power on/recording button
- ④ Magnetic Charging Port
- ⑤ MagSafe leather case
- ⑥ MagSafe Iron Ring
- ⑦ Magnetic Charging Cable

2. Equipment status



- ① Device Waiting for Binding
- ② Device Firmware Updating
- ③ Device Wi-Fi Mode Activated
- ④ Device Bluetooth Mode Activated
- ⑤ Device Recording in Progress
- ⑥ Device Charging
- ⑦ Device Low Battery
- ⑧ Current Battery Level
- ⑨ Device Fully Charged
- ⑩ USB Connected


3. Easy operation instructions

3.1 Power on/off



- Power on/general wake-up: Press and hold the (0.5s) Power button, as shown in the figure above.

3.2 Bind Device



- The binding operation requires going through the APP. Download the APP and search for REC-NOTE through the QR code on the homepage or on the App Store.
- Complete account registration and login to enter the main interface of the APP.
- Press the Power button to wake up REC-NOTE.
- Click on the search icon in the upper left corner of the app to enter the binding process.
- After successful binding, REC-NOTE will display the Bluetooth icon shown in the figure above.

3.3 start recording

There are two recording modes: high-definition voice recording mode and high-definition human voice recording mode


- High-definition voice recording mode:



When the switch is turned on upwards, as shown in the above figure, REC-NOTE is in high-definition voice recording mode. In this mode, REC-NOTE can capture the vibration of the phone and output accurate records.


Attention: To use this mode more effectively, please place the REC-NOTE in the Magsafe case and press it tightly against the back of the phone.

- High-definition human voice recording mode:



When the switch is turned down, as shown in the above figure, REC-NOTE is in high-definition human voice recording mode. In this mode, you can hold the REC-NOTE in your hand or place it on the table to start recording.

- Start/End Recording:



Press and hold the Power button for 2 seconds. After REC-NOTE vibrates once, recording will begin and the screen will display the recording icon, as shown in the picture above.

In recording mode, long press the Power button for 2 seconds, and REC-NOTE will vibrate twice, indicating the end of recording.

3.4 File synchronization to App




- Click on the icon in the upper right corner of the App. Entering the recording synchronization interface, you can see the recording files stored in REC-NOTE.
- There are two synchronization methods, Bluetooth transmission and WiFi transmission.

Bluetooth transmission:




When the file size is small, Bluetooth transmission can be chosen for convenience and speed.

WiFi transmission:



When the file size is relatively large, the recording synchronization interface will prompt to select WiFi transmission method.


3.5 Document transcription, generating summaries and mind maps




- The main interface of the APP displays the successfully synchronized audio files.
- Click on the 'Copy' button on the file card, as shown in the figure above. A pop-up window appears at the bottom to select the language to be transcribed. After submitting, wait for a moment, and the content on the file card will display the transcribed content.
- Click on the file card to enter the details page.
- In the details page, you can see the transcribed transcription list, summary, and mind map after transcription.

3.6 Listen to your recording in the APP

- After you finish recording online, your recording file will soon appear in the APP. Tap the play button to listen to your recording.
- Note: If the file does not appear, please refresh or check "Sync".



3.7 Renaming and Deleting Recording Files



- You can swipe left on the file card to rename or delete the file.

Note: For more detailed operation instructions, please go to the operation guide page of the APP.

Email: service@storycloud.ltd

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.