

CHILDREN VIDEO WALKIE-TALKIE

Product User Manual



3+ Ages

●1. Product Appearance and Function Description



1-Screen Switching/Sound Changing Key

2-Antenna

3-Camera

4-Display Screen

5-Volume up

6-Volume Reduction

7-Power Switch

8-MIC Port

9-Intercom Button

10-Type-C Interface


11-Charging Indicator

●2. Power On/Off

2.1. When the product leaves the factory, the power toggle switch is in the "OFF" position.

2.2. When you turn the power switch to "ON", the product will automatically boot up. As shown in Figure A, the display area shows the image captured by the built-in camera. The image of the other device will only appear in display area B when the paired device is turned on.

2.3. For the first use of this product, please charge the battery fully before use.



The Device is Powered off

Power On/Standby Mode

●3.Charge Indicator light

3.1. Use the charging cable provided with the device, connect it to the charger, and the power indicator "red light" will turn on. When fully charged, the charging indicator will automatically turn off.



3.2. Charger specifications: 5V/1A.

4.Functional Description

4.1. Turn the power switch to "ON" position, the device will automatically boot up and display the local camera view. When the counterpart's intercom is powered on, both sides will automatically connect and display each other's images.

4.2. Press and hold the "intercom" key to talk. The voice transmission is one-way. Only when the speaking party releases the intercom key can the other party press and hold the key to send voice.

4.3. Press the top mode key to switch display modes: This device has four screen display modes.



●5. Volume Adjustment:

Press the "+" key briefly to increase the volume.

Press the "-" key briefly to decrease the volume.

●6. Voice Changing Function:

Long press the "Mode" button for 2 seconds and release it to switch between voice modes.

After shutdown, the voice changing mode will revert to the original sound mode.



●7. Product Power on/off and Automatic Shutdown Function

This product enters working state after being turned on; it will always be in working state regardless of whether it is being used or not. When the product is in a low battery state, it will automatically shut down. If you stop using it, please turn the toggle switch to the "OFF" state.

If you need to restart the product, simply toggle the power switch to "OFF" and then to "ON" to start it normally.

●9. Product Pairing and Connection Methods:

This product uses **WIFI2.4G** transmission and connection mode; each package contains two interphones, which have been paired. These two interphones cannot be connected to other machines for use. If multiple sets of products are purchased, they can only be connected one-to-one in sets, and cannot be connected to multiple products simultaneously for use.

10. Precautions:

- a. This product is suitable for outdoor use.
- b. This machine is not waterproof
- c. The indoor distance of the product should be based on the principle of no image stuttering.

●11. Product Specifications

Display screen	2.0 Inch IPS
Battery	3.7V 650mAh
Language	English
Charging port	Type-C
Usage environment	-20°C ~ 60°C
Storage environment	-30°C ~ 70°C
Power supply	5V/1.0A
Product dimensions	100mm*51 mm*29mm



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.