This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

TWS-PW40

使　用　说　明　书

耳机功能操作指南

双耳配对（未配对情况下）
打开充电仓上盖，放置充电盒内关盖，三秒后打开充电仓即可配对，（开仓自动开机）

蓝牙配对
打开充电仓（开仓自动开机），从蓝牙列表中找到"PW40",点击连接，连接成功后播报（连接成功）放回充电仓自动关机充电，产品默认有过连接记录的会自动默认回连手机。（主副耳机可以无缝自动主从切换）

触控操作指南

音乐控制
播放/暂停：触碰左或右耳1下
切上/下曲：触碰左或右耳2下

通话控制
接听/挂断：触碰左或右耳1下
拒接/电话：单电时长按左耳/右耳3秒

模式控制
siri 模 式：连续触碰左耳/右耳三下切换进入siri模式

音量调节
音量减：长按左耳减小音量
音量加：长按右耳加大音量

充电说明

电仓充电
当充电仓指示灯闪烁时请及时充电，将USB充电线一端连接到充电仓Type-c充电输入接口，另一端连接到电源适配器的USB端口。
耳机充电
左右耳电量不足时，会报低电量提示音。请将耳机放入充电盒 合盖充电，充电时指示灯长亮。充电完成之后指示灯熄灭。

注意事项
本产品不带适配器销售，消费者若使用电源适配器充电，则应购买配套使用获得CCC认证，并满足标准要求的电源适配器。

当耳机充电接口有异物且接触不良时，请用棉签沾酒精轻轻 擦拭清洁耳机充电接口。

产品技术规格参数

机　　型：　P W4 0
产品名称：TWS 蓝牙耳机
蓝牙芯片：中科蓝讯AB5636A
蓝牙规格：蓝牙5.3
耳机形态：开机闪连/入耳式/双路传输/双耳通话
音效选择：DeepX立体声效/入耳定制音效
蓝牙距离：直线无障碍10米/无线技术/双路传输/AI动态低延迟
防尘防水：耳机支持IPX4级防尘防水
外观材质：ABS
充电接口：Type-C输入5V-0.7A/输出5V-0.3A
充电方式：充电盒仓TYPE-C接口进口充电，耳机磁吸充电
电仓容量：300mAh/待机180H/整机充电约1.5H/给耳机充电约3-4次
耳机容量：30mAh/工作时间4-5H/耳机充电约1H
控制方式：触控操作/双击/长按/Siri语音/来电播报
频响范围：20HZ—20KHZ
发声单元：10mm±0.2mm动圈单元
蓝牙协议：CAP/AVRCP/HFP/A2DP
包装清单：耳机/充电仓/使用说明书/包装盒/Type-C充电线

疑难问题解答

取出耳机不自动开机检查充电仓是否电量低，请及时充电检查耳机和充电仓的充电触点是否有脏赃或脏物，请用工业酒精/抹机布清洁。

搜索不到耳机请认手机在合理的蓝牙使用范围内，在无遮挡环境下，蓝牙的最大连接距离是10米，当本设备与其它蓝牙设备连接上时，其它手机无法连接本设关闭其它蓝牙设备或者手机里其它蓝牙名删除重新搜索蓝牙名进入配对。

通讯中断或信号不稳定本机与蓝牙设备之间有金属或墙壁等障碍物，本机则近有WIFI设备/无线电话或波炉等使用2.4GHZ频率的设备使用，蓝牙设备和WIFI使用相同频率，如在附近使用则可能产生微波干扰，从而可能会遇导中断或出现噪音或音频信号丢失，应远离干扰信号至少10米处使用本机。

注意事项

请勿在极热极冷、多尘和潮湿的环境中使用本机。耳机内含电池，不得暴露在日照、火烤，高温环境中以免发生危险。

TWS-PW40

aninstructionmanual

Headphone function operation guide

Binaural pairing (without pairing)
Open the upper cover of the charging compartment, place the inner cover of the charging compartment, and after three seconds, open the charging compartment to pair. (Automatic start of warehouse opening)

Bluetooth pairing
Open the charging compartment (automatic power on when opening the compartment), find "PW40" from the Bluetooth list, click Connect, and after successful connection, broadcast (successful connection) and put it back into the charging compartment to automatically shut down and charge. If the product has a connection record, it will automatically connect back to the phone by default. (The main and auxiliary headphones can seamlessly and automatically switch between master and slave)

Touch operation guide

Music control
Play/pause: Touch the left or right ear once
Cut up/down by: Touch the left or right ear twice

Call control
Answer/end: Touch the left or right ear once
Reject/call: Press the left right ear for 3 seconds when calling

Mode control
Siri mode: Continuously touch the left/right ear three times to switch to Siri mode

modulation
Volume decrease: Long press the left ear to decrease the volume
Volume up: Long press the right ear to increase the volume

Charging instructions

Electric bin charging
When the indicator light of the charging bin flashes, please charge in time. Connect one end of the USB charging cable to the Type-c charging input interface of the charging bin, and the other end to the USB port of the power adapter.

Headphone charging
When the power of the left and right ears is low, a low power warning tone will sound. Please put the headset into the charging box and close the cover to charge. The indicator light will be on for a long time when charging. The indicator light will be off after charging.

Matters needing attention
This product is sold without an adapter. If consumers use a power adapter to charge, they should purchase a power adapter that has obtained CCC certification and meets the standard requirements.
When there is foreign matter in the headset charging interface and the contact is poor, please wipe and clean the headset charging interface gently with a cotton swab dipped in alcohol.

Product technical specifications

Model: PW40
Product name: TWS Bluetooth headphones
Bluetooth chip: Zhongke Lanxun AB5636A
Bluetooth specification: Bluetooth 5.3
Headphone form: flash on/in ear/dual transmission/dual ear call
Sound effect selection: DeepX stereo effect/human ear customized sound effect
Bluetooth distance: Straight-line barrier-free 10m/wireless technology/two-way transmission/AI dynamic low delay
Dust and water proof: The headset supports IP44 dust and water proof
Appearance material: ABS
Charging interface: Type-C/input 5V-0.7A/output 5V-0.3A
Charging method: Charging through the TYPE-C interface socket in the charging box, and charging through the headset magnetic suction.Battery capacity: 300mAh/standby 180H/whole machine charging about 1.5H/headset charging about 3-4 times
Headphone capacity: 30mAh/working time 4-5H/headphone charging about 1H
Control method: Touch operation/double click/long press/Siri voice/call announcement
Frequency response range: 20HZ-20KHZ
Sound generating unit: 10mm ± 0.2mm dynamic coil unit
Bluetooth protocol: CAP/AVRCP/HFP/A2DP
Package list: Headset/charging bin/instruction manual/packaging box/Type-C charging cable

Troubleshooting

Take out the headset and do not automatically turn it on to check whether the charge chamber is low. Please charge it in time to check whether the charging contact of the headset and the charge chamber is blocked or dirty. Please clean it with industrial alcohol/wiping cloth.
The headset cannot be searched to confirm that the mobile phone is within the reasonable range of Bluetooth use. In an unobstructed environment, the maximum connection distance of Bluetooth is 10 meters. When this device is connected to other Bluetooth devices, other mobile phones cannot connect to this device. Turn off other Bluetooth devices or delete other Bluetooth names in the mobile phone and search the Bluetooth name again to enter pairing.
Communication is interrupted or the signal is unstable. There are metal or wall obstacles between the machine and the Bluetooth device. WIFI equipment/wireless telephone or wave oven and other equipment using 2.4GHZ frequency are used near the machine. Bluetooth device and WIFI use the same frequency. If used nearby, it may cause microwave interference, which may cause communication interruption or noise or audio signal loss. Use this device at least 10 meters away from the interference signal.

matters needing attention

Do not use this machine in extremely hot, cold, dusty and humid environment. The earphones contain batteries. They should not be exposed to sunlight, fire or high temperature to avoid danger.