

Speaker manual



M10


TWS mode:

Initial Pairing: Turn on the two speakers, without connecting the cell phone, short press the M button of one machine, wait for pairing after hearing the ding sound, when you hear the ding sound again, the pairing is successful. And then add the cell phone can enjoy stereo music.

The next time you turn on the phone again, the two speakers will be automatically paired with TWS function.

Bluetooth Pairing:

Open the phone settings and connect the Bluetooth device. Select "M10" in the phone Bluetooth connection to complete the connection.



Kindly Reminder:

- Before use, please make sure that the plug cover is tightly covered to prevent falling into the water and damaging the loudspeaker.
- Put the product out of reach of children.
- Please use a soft cloth to dean the product instead of chemicals with strong irritation. Be sure to disconnect the power supply before cleaning.
- Do not puncture or disassemble the outer surface of the product in any way.
- Do not insert any metal objects into the equipment to prevent electric shock to the equipment.

Operation of Key Functions

-  : On/off key

- 1、Power on: Long press the on/off button for 3 seconds to power on, beep: bluetooth mode.
- 2、Shut down: Long press the on/off button to shut down.
- 3、Auto-shut down: Auto shut down after 5 minutes when not connected to bluetooth.

-  : Previous/Next song

- 1、Long press “+”: next song
- 2、Long press “-”: previous song

-  : Increase/decrease volume

- 1、Short press “+”: volume plus
- 2、Short press “-”: volume down

-  : M Key

Short press M to switch time mode
Long press Play to enter clock setting, clock blinks, short press Volume Up/Down to adjust clock
Short press Play to confirm clock and enter minute adjustment, short press Volume Up/Down to adjust minute
Short press Play again to confirm

-  : Display Screen

1. Display clock
2. Display the power, the normal state of the power mark is always on, when the power is low the power mark begins to flash, prompting the speaker needs to be charged.
3. Display the charging status, the lightning sign flashes when charging, and it is always on after charging.

-  : RGB Lighting

Short press the on/off button to adjust

-  : Pause/Play

Pause/Play music: Short press the play button

Call mode

Short press the play button: answer & hang up the call
Long press the play button: reject the call
Double-click the play button to call the most recent contact.

Speaker parameters

Model: M10
Bluetooth: 5.3
Transmission Distance : 10m
Microphone: Built in
Rated Power: 5W
SNR: 85+dB
Charging Voltage : DC 5V
Battery Capacity: 1000mAh
Cgarging Time: 1.5H
Playback Time: 7-8Hours(about 50% sound level)
Supported Profiles: A2DP/HFP/HSP/AVRCP
Speaker Size: 95mm*95mm*53mm
Frequency Range : 100Hz-20KHz
Wireless Transmit Power: 0-8dbm
Input: DC 5V/500MA

Wireless pairing

Charge the speaker for 2hours before initial use.

1. In Bluetooth mode, hold down the power button for 3 seconds to enter pairing mode, if the has not been connected for about 5 minutes, blue will automatically close.
2. Activate wireless capabilities on media player devices and search for

"M10" to pair from the list. If the media device prompts for a password, enter "0000".
3.If pairing fails, refer to the user manual of the media player device for wireless settings. Remove all redundant unused models from the pairing device list and start again from step 1.

Charging equipm

Wireless speakers are powered by built-in rechargeable lithium batteries.

- 1.Open the DC 5V charging port cover.
- 2.Connect the charging cable from the USB socket on M10 to the standard USB charging port, such as computer or USB charger.

FCCCaution :
Thisdevicecomplieswithpart15oftheFCCRules.Operationissubjecttothe followingtwoconditions:(1)Thisdevicemaynotcauseharmfulinterference,and(2) thisdevicemustacceptanyinterferencereceived,includinginterferencethatmay cause undesired operation.
AnyChangesormodificationsnotexpresslyapprovedbythepartyresponsiblefor compliancecould void the user's authorityto operatetheequipment.
Note:Thisequipmenthasbeentestedandfoundto complywiththelimitsforaClass Bdigitaldevice,pursuanttopart15oftheFCCRules.Theselimitsaredesignedto providereasonableprotectionagainstharmfulinterferenceinaresidentialinstallation. Thisequipmentgeneratesusesandcanradiate radiofrequencyenergyand,ifnot installedandusedinaccordancewiththeinstructions,maycauseharmfulinterference toradiocommunications.However,thereisnoguaranteethatinterferencewillnot occurinaparticularinstallation.Ifthisequipmentdoescauseharmfulinterferenceto radioortelevisionreception,whichcanbedeterminedbyturningtheequipmentoff andon,theuserisencouragedtotrytocorrecttheinterferencebyoneormoreofthe followingmeasures:
-Reorient orrelocatethereceivingantenna.
-Increasetheseparationbetweentheequipmentand receiver.
-Connecttheequipmentintoanoutletonacircuitdifferentfromthattowhichthe receiveris connected.
-Consultthe dealer oranexperienced radio/TVtechnician for help.
The devicehas been evaluated to meetgeneral RFexposurerequirement.The device can be used in portableexposurecondition withoutrestriction.