

Bluetooth Holographic Audio
H10_3D



using this product and follow this manual strictly.

I. List of products

No.	Item	Qty
1	Bluetooth Holographic Audio H10_3D	1
2	Data & Charging Cable	1
3	User Manual	1

* Please confirm that your package is complete. If any item is not in the package or damaged, please contact your original purchasing dealer for assistance.

Note:

- 1.To avoid injury, please install the product in a position that can not be touched by the hand, or you can choose a protective cover to ensure personal safety.
- 2.This product is an electronic product, please pay attention to waterproof and dustproof. For outdoor use, please provide protective cover.
3. 3. Non-professionals, please do not disassemble this product, so as not to damage or cause personal injury.
- 4.The normal operating temperature of the 4. advertising machine is -20 ℃ -60 ℃ , if the ambient temperature is too low or too large, please use the machine carefully.
- 5.Please do not use or store the machine in high temperature, high pressure, strong magnetic field, big dust and damp environment.



2-1.Use the supporting handicap device to plug in power; you can also use a 5V power bank to connect to the Type-C interface of the machine and power it on;



Power Switch / Mode Switch Button
1.Press and hold the power switch for 3 seconds to turn on the device, accompanied by a voice prompt "POWER ON". The device will default to Hologram Mode, with a voice prompt "Hologram Mode".
2. When the device is powered on, a short press of the power switch toggles between modes. The device has three operating modes:
2. 1 Hologram Mode (Voice prompt: "Hologram Mode"): The holographic screen displays visuals, and the speaker connects via Bluetooth. The Bluetooth name of the device is H10_3D. After connecting your phone to this Bluetooth device, you can play Bluetooth music.
2. 2 Bluetooth Mode (Voice prompt: "Bluetooth Mode"): The holographic screen displays visuals, and the speaker connects via Bluetooth. The Bluetooth name of the device is H10_3D. After connecting your phone to this Bluetooth device, you can play Bluetooth music.
2. 3 Music Only Mode (Voice prompt: "Hologram OFF"): The holographic screen is disabled, and the speaker only plays music from your connected Bluetooth device.
3.Press and hold the power switch for 3 seconds to turn off the device, accompanied by a voice prompt "POWER OFF".

III. Software Instructions

Dear Customer:
Thank you for using our holographic advertising machine. Please prepare your content materials before use. For a better experience, we recommend your materials follow these guidelines:

- 1.Black background is preferred for better 3D effect.
- 2.Supported video formats: MP4, AVI, RMVB, GIF.
- 3.Resolution: 800×800 pixels or higher.
- 4.Video duration: 10–120 seconds.
- 5.Supported image formats: JPG, PNG (black background is recommended).

3D Video/Image Examples (Black Background)



Cell phone app operation

Step 1: Download app




Step 2: Go to your phone's settings and connect to the 3D WIFI connection

Step 3: Whether the current WIFI is not available after about 3-5 seconds, whether to continue using this WIFI" and choose to use it


Step 4:After about 3-5 seconds, when prompted "Current WIFI is unavailable for internet access. Continue using this WIFI?", select "Use".




Step 5:Click" +" to upload a video or file



Step 6:Often press the file name does not put, you can delete unnecessary files



Step 7:DIY independent humanized design 3D video



Product warranty card

User association		
User name:		Product Model:
User address:		Date of purchase:
Maintenance Federation		
Maintenance date	Fault description and handling	Maintenance personnel

* During the warranty period, if failure occurs in accordance with the instructions for normal use, you repair may be obtained. When repairing, please fill in this card and hold this card to the purchase store or designated store for maintenance.
*Maintenance not caused by the company's quality reasons, such as improper use, improper custody, unauthorized disassembly of machines, after purchase fall, movement or transportation and other non-product quality problems caused by failure or damage, beyond the warranty period, does not belong to the scope of free warranty.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.