




Walkie-Talkie Kit



Product name: Walkie Talkie Kit
Model No.: eUTSAK

1. Power On/Off

- Turn On: Press and hold the ON/OFF button (top left) for 5-10 seconds until the prompt sound is heard, then release. The default channel indicator 1 and volume indicator H will light up.
- Turn Off: Press and hold the ON/OFF button for 5-10 seconds until the indicator flashes, then release.

2. Adjust Volume

- Press the ON/OFF button (top left) once.
- H is the maximum volume, M is the medium volume, and L is the minimum volume.

3. Talk

- Press and hold the TALK button (right side) and speak close to the microphone.

4. Switch Channels

- Press and hold the ON/OFF button while quickly pressing the TALK button.
- There are three channels (1/2/3). Ensure all walkie-talkies are on the same channel to communicate.



5. Charging

- When the battery is low, the red light will turn on and an alarm will sound.
- Charge using a USB 5V Type-C cable. The red light will turn on while charging.
- The red light will turn off when fully charged in about 4-6 hours. Walkie Talkie talk time is about 1 hour and stand by time is about 24 hours.

Notes

- When using at close range, set the volume to the minimum (L indicator) to avoid noise.
- The walkie-talkie group can be expanded to 10 units.
- Maximum communication distance is 1 mile (open area).

Thank you for purchasing the eUda+ Walkie Talkie Kit. This document is the user manual and contains all the information for correct, efficient and safe use of the product. Read this information carefully before using the product.

Intended use:

The product is not intended for professional use.

Consult the local laws and regulations for this product before installing and using.

Specifications:

Product: Walkie Talkie Kit

Transmission Distance: Up to 1 mile (depends on the operation environment, open area)

Frequency Channels: 3

Volume levels: 3

Automatic Channel Scan: Yes

Push-to-Talk (PTT): Yes

Waterproof: No

Battery Life: Up to 1 hour

Standby Time: Up to 24 hours

Frequently Asked Questions (FAQ)

Unable to turn on walkie-talkie	- If the rechargeable battery hasn't been used for a long time, it may be low; charge it fully before use. - If it still won't turn on with a full battery, press and hold the power ON button to restart 1-2 times. - If the power ON button cap is too tight, remove it and reposition it to a suitable position.
I can't hear or talk to another walkie-talkie	Make sure both of you are on the same channel, i.e. Channel 1, 2, or 3. Different frequency channel cannot communicate to each other.
Low or no sound during calls	- Ensure the speaker is set to the "H" (High) volume level. - Speak as close to the microphone as possible.
Volume or Channel light not turning on	- If the channel light doesn't turn on, go through the channel-switching process to activate it. - If the volume light doesn't turn on, press the power button 2-3 times to activate it.
Loud noise or no clear signal	This may be due to excessive distance, electromagnetic interference, or obstacles blocking the signal. Move closer or go to an open area to improve the signal quality.

WARNING:

- Read the manual carefully before use. Keep the manual for future reference.
- Only use the product as described in this manual.
- Do not use the product if a part is damaged or defective. Replace a damaged or defective product immediately.
- The product cannot be used to contact the emergency services.
- Do not expose the product to water or moisture.
- Battery usage by children should be supervised.
- Seek medical advice immediately if a cell or a battery has been swallowed.
- Use only the battery in the application for which it was intended as described in this manual.

Maintenance:

Clean the product regularly with a soft, clean, dry cloth. Avoid abrasives that can damage the surface.

Do not clean the inside of the product.

Warranty:

Any changes and/or modifications to the product will void the warranty. We accept no liability for damage caused by improper use of the product.

Safety Symbols On the Product:

Icon	Description
	Electronic equipment needs to bear the CE mark in order to be marketed in the EU. CE marking shows that a product is assessed before being placed on the market and that it meets EU safety, health and environmental protection requirements. CE marking is also sometimes accepted as a means of compliance with type-approval requirements, for example, electronic components that require type-approval and also CE marking for electromagnetic compatibility (EMC) or low-voltage equipment.
	Indication to explain that the product needs to be collected separately when disposed. Do not throw in the trash bin.

Disclaimer:

Designs and specifications are subject to change without notice. All logos, brands and product names are trademarks or registered trademarks of their respective owners and are hereby recognized as such.

Disposal:

	This symbol indicates that this product should not be thrown away with other household waste throughout the EU. To prevent possible harm to the environment or human health by uncontrolled waste disposal, you are responsible for recycling it so that it can promote the sustainable reuse of raw materials. To return your used product, you can use the regular return and collection systems or contact the store where the product was purchased. They can recycle this product for the environment.
--	---

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to

SAR statement

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The SAR limit set by the FCC is 1.6W/Kg. For body-worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and positions the device a minimum of 0mm from the Back touch and 25mm from the Face up. RF exposure compliance with any body-worn accessory that contains metal was not tested and certified. and use of such body-worn accessory should be avoided.

Declaration of Conformity:

We, eUda Plus Inc. declare as manufacturer of this product from our brand

eUda+®, produced in China, has been tested according to all relevant CE standards and

regulations and that all tests have been passed successfully.

For additional information regarding this product, contact the customer service:

Web: www.eudaplus.com

E-mail: info@fractioni.com

Phone: 1-669-228-1285

Address: 84 W Santa Clara Street Suite 700

San Jose, CA 95113

USA

Bill Of Materials

- PCB Board X 2
- Front Panel X 2
- Top Panel X 2
- Bottom Panel X 2
- Left Panel X 2
- Right Panel X 2
- Back Panel X 2
- Lining Panel X 2
- Button Switch X 4
- Long Header X 2
- Short Header X 2
- Square Nut X 8
- Large Hexagonal Post X 8
- Small Hexagonal Post X 8
- Flat Head Screw X 32
- Washer X 8
- Blue Button Cap X 2
- Black Button Cap X 2
- White Button Cap X 2
- Transparent Button Cap X 2
- Ring X 2
- Antenna X 2
- Speaker X 2
- Round Double-Sided Foam Adhesive Tape X 6
- Lanyard X 2
- Battery X 2
- Type-C Cable X 1
- Cross Screwdriver X 1
- Needle Nose Plier X 1
- Scraper X 1
- Tweezer X 1
- Large Hexagonal Post Extra X 2
- Small Hexagonal Post Extra X 2
- Flat Head Screw Extra X 2
- Washer Extra X 2
- Square Nut X 1
- USB Electric Soldering Gun 5-Piece Set X 1
- PCB Soldering Practice Board and Components X 1
- Components X 10
- Magnifier X 1
- Surprise Gift X 1