

【English】 Central console recorder.
Finished size: 82X105MM.
Expanded size: 328X105MM.





Center console recorder

(Head Up Display)

Note: Please read this document carefully before installing and using the product, and please keep it properly.

Machine interface/operating instructions




Notes:

- ① This product requires a high-speed TF card (Class 10). Non-high-speed cards may cause the machine to malfunction
- ② No card insertion/removal allowed when the device is powered on! This may damage the TF card.
- ③ Please use the original accessories in the product packaging box. If not, it may be incompatible or not start up (if you have any questions, please consult store's customer service first).

Product reminder: This manual document contains (all versions) please use the package purchased by you.

Product key function description

- Plug the Type C plug of the power line into the interface on the main unit.
- Plug the USB connector into the power interface in the electric car.
- Wiring, can walk the power cord from the side under the steering wheel hidden installation
- After installation, place the device on the steering wheel dashboard. As shown in the picture.



Product key function description


Special attention and reminder: the machine will automatically record as soon as it is turned on. If you need to operate the menu M key, you must pause the first and then perform the operation (otherwise the operation will not respond and is invalid). Press the OK key briefly to stop recording, and you can operate normally after stopping the recording

The M key on the menu has two functions, short press to open mode switch, long press to open the menu.

Mode switching is divided into 3 functions switching: photo mode, playback mode, video mode;


Camera mode:

- Press the menu M key briefly, when the screen shows in the top left corner  Enter photo mode;Short press the OK key to take a photo, press the up key to view the photo. The down key does not have any function for the time being, no operation is required.
- Long press the menu M key to enter the menu mode, as shown in the following figure.



Replay mode:

- Press the menu M key briefly, when the screen shows in the top left corner  Enter playback mode, press the up key or down key to switch the displayed file. Select the video file you want to view, and press the OK key to play it back. (Only videos can play, images cannot be played) When playing a video, long press the up and down keys to fast forward or rewind, and short press the up and down keys to fast forward or rewind second.
- Long press the menu M key to enter the menu mode, as shown in the figure below



Video mode:

- Press the menu M key briefly, when the screen shows in the top left corner  Enter video mode, press the OK key again briefly, you can start normal recording.
- Long press the up key to turn on WIFI, long press the up key again to turn off WIFI, short press the up key to switch the view front, back, front and back; (Note: Switching is only possible with a rear camera, if there is no rear camera, the picture switching remains unchanged)
- Long press the key to turn off the sound, long press the key again to turn on the sound, and short press the key to switch between the recorder and the HUD screen. As shown in the figure below.



Dashcam APP download and connection

APP download

Scan the QR code below to download, or search for 【Viidure】 to download.



WIFIWIFI Connection

 Long press the up key for 3 seconds, the machine screen will display the WIFI name and password, proving that the wifi is on, (The WIFI must remain on to connect, and the mobile app cannot be connected if the WIFI is turned off) Hold the up key for 3 seconds again and the wifi will be turned off.

- Open phone settings - Wi-Fi or Wireless Local Area Network - select the WiFi of the recorder - enter password: 1234567 to connect. (Note: The record player WIFI name starts with HUD1);

- Open the APP - Add the dashcam - Dashcam - It will then connect automatically.
- After the connection is successful, you can view video playback and playback of the trip trajectory.



Disclaimer:

The information provided in the instruction manual for the car black box is for reference only. Users should refer to the actual product when using it. If a fine or traffic accident occurs due to the use of this product, our company shall not be liable for any responsibility. The car black box records video in a loop, please to save important data in time. This product does not rule out the possibility of unexpected situations occurring during use, and our company shall not be liable for any responsibility if video or image is not recorded due to this. By purchasing this product, you are deemed to have complied with this declaration.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.