


Intelligent Projector
USER'S GUIDE
用户说明书



智能投影仪



重要事项

在使用投影机前，请仔细阅读本用户手册并保管备用。

Microsoft 及 Windows 是 Microsoft Corporation (美国及其他国家)的注册商标。
苹果是 Apple Computer Inc. (U.S.A.)的商标。

注意纵使在没有注释的情况下，各公司的商标及产品商标均获得严正对待。

注意事项

- 1.务必使用设备标配电源适配器，如使用电源不当会对设备造成严重损坏；
- 2.长时间不使用设备，请保证关闭电源开关；
- 3.风扇口请避免有异物进入或遮挡出风口，以免影响风扇工作；
- 4.设备工作状态，请勿直接断电关机；
- 5.外接功耗较大的外置设备时,请确认功耗能否支持；
- 6.设备内置电源,请勿放置于高温或潮湿处,以免发生危险；
- 7.适用于海拔2000米及以下、非热带气候条件下安全使用；

注意

为预防触电，请勿打开机壳。机内无顾客能够进行修理的部件。
维修事宜请委托有资格的专业维修人员进行。

警告

本标识警告用户机组内有未进行绝缘处理的电压，有可能引起表面磁场造成触电。因此，接触机组内部的任何部件均非常危险。

警告

为预防失火或触电，切勿将本机暴露于雨水或潮气之中。

警告

此为A级产品,在生活环境中,该产品可能会造成无线电干扰。
在这种情况下,可能需要用户对其干扰采取切实可行的措施。

包装内容

开箱后, 请先检查包装内容物是否完整。如有缺失, 请联系经销商进行调换。



主机



遥控器



电源线



说明书

安装图示

下列安全指示确保本机能维持长久的使用寿命，以及防止失火或触电。
务请细心阅读它们并留心下列全部警告。



不要安装在通风不良的场所



不要安装在热和潮湿的场所



不要堵塞通风孔（进气或排气）




不要安装在多尘、多烟雾的场所



不要安装在受空调的冷暖风直接吹拂的场所，否则可能会由于水气凝结或温度升高而导致机体故障


注意散热

为了维护投影机的性能和可靠性，请在投影机和周围物体之间留出至少30厘米的空间。




注意眼睛

投影机亮度很高，请勿直视或避免用投影机照射人的眼睛，以免造成视力损害。



开始使用

为了达到更好的观影效果，我们建议您选择以下安装方式安装好投影机。



水平放置


安装简便,调节简单

! 注意事项

当投影机悬挂在天花板上,或者处于背投系统中时,请更改投影模式。

调节焦距

当画面成像模糊时，建议通过遥控器的一键对焦功能，以提升画面清晰度，如果无法获得满意的清晰度，也可以通过F+/F-微调再次调整。或者请将产品向前或向后酌量移动。



成像模糊




成像清晰

遥控器按键功能

※语音版：蓝牙语音遥控器

(仅语音版本配备)



- 1、工作指示灯
- 2、电源键
- 3、一键对焦
- 4、输入信号源
- 5、方向选择键-向上
- 6、方向选择键-向左
- 7、方向选择键-向右
- 8、方向选择键-向下
- 9、确定/播放/暂停
- 10、菜单键
- 11、返回键
- 12、主页键
- 13、手动对焦
- 14、音量加
- 15、音量减
- 16、语音键

首次使用请按此方法配对:

自动配对:

- 1.按遥控器语音键 进入配对页面;
- 2.同时按住遥控器左键与右键 ;
- 3.直到遥控器指示灯闪烁后松开;
- 4.等待自动配对成功后退出配对页。

手动配对:

- 1.按遥控器语音键 进入配对页面;
- 2.再按ok键进入设置页的蓝牙设置;
- 3.同时按住遥控器左键与右键 ;
- 4.至遥控器指示灯闪烁后松开;
- 5.找到“语音助手”点击连接。

附录：投影机产品保修卡

- 1、本产品实行“三包”，自购买之日起（以购买记录为准），主机一年内保修（非人为损坏原因）。
- 2、保修期内，凡属产品技术原因引起的故障，本公司将为您提供保修服务。
- 3、下列情形不属保修范围：
 - ①主机以外其它附件。
 - ②未经本公司同意，私自进行拆装、维修的产品。
 - ③外力损坏及其它自然灾害造成的损坏。
- 4、产品出现故障时，请及时联系经销商或网络服务人员，把产品及**本保修卡填妥后**一并寄到我公司，我们将尽快维修并寄回。
- 5、本保修责任仅限于保修期间产品的故障维修，不承担其它责任。

客户名称：_____ 购买店铺：_____

客户ID：_____ 客户电话：_____

寄回地址：_____


故障描述（为了便于快速维修处理，请详细描述故障）：



USER'S GUIDE



Intelligent Projector



Caution

Before using the projector, please read this guidance carefully and keep it safely

Microsoft and Windows is the registered trademark of Microsoft Corporation(US and other country).

Apple is the trademark of Apple Computer Inc.(U.S.A)

Cautious: The trademarks and product trademarks of the above company will all get stern treatment even under the situation without annotation.

Caution

1. It is necessary to use the standard power adapter of the device. Improper use of the power adapter can cause serious damage to the device;
2. If the device is not used for a long time, please ensure to turn off the power switch;
3. Please avoid foreign objects entering or obstructing the fan outlet to avoid affecting the fan's operation;
4. The equipment is in working condition, please do not directly power off or shut down;
5. When connecting external devices with high power consumption, please confirm if the power consumption can be supported;
6. The device is equipped with a built-in power supply. Please do not place it in a high temperature or damp place to avoid danger;
7. Suitable for safe use in non tropical climate conditions with an altitude of 2000 meters and below;

Caution

To prevent electric shock, do not open the casing. There are no components inside the aircraft that customers can repair. Please entrust qualified professional maintenance personnel to carry out maintenance matters.

Warning

This label warns users that there is voltage inside the unit that has not been insulated, which may cause surface magnetic fields to cause electric shock. Therefore, it is very dangerous to come into contact with any components inside the unit.

Warning

To prevent fire or electric shock, do not expose this machine to rainwater or moisture.

Warning

This is an A-grade product that may cause radio interference in living environments. In this case, it may be necessary for users to take practical and feasible measures to interfere with it.

Packing

After opening the package, please check if the content inside is in good condition. If there's any missing parts, please contact the manufacturer for replacement.




Projector



Remote



Power cord



Instruction

Installing

The guidance below makes sure the long service life of the device. To prevent fire and electronic shock, please read the instruction carefully and be cautious about the warning below.



Do not install into places with poor ventilation



Do not install into places are hot and humid



Do not plugged the vent(Intake and exhaust)




Do not install in smoky and dusty environment



Do not install somewhere directly blown by the warm/cold wind of the A/C, or it may cause the breakdown because of the water vapor condensation


Note for Heat Dissipation

To maintain the projector's performance and reliability, please leave at least 30cm space between the projector and the objects around.




Note for eyes

The projector is with high brightness, please do not directly look into it or do not let the projector's light shine through the eyes, to avoid eyesight damage.



Start Using

For best projection effect, we suggest you to choose the following method to install the projector.



Horizontally

Easy to install and easy to adjust


! Precautions

When the projector is suspended from the ceiling or in a rear projection system, please change the projection mode.

Focus Adjustment

When the image is blurry, it is recommended to use the One Click Autofocus function of the remote control to improve the clarity of the image.

If satisfactory clarity cannot be achieved, it can also be adjusted again through F+/F fine tuning. Alternatively, please move the product forward or backward in moderation.




Fuzzy Image



Clear Image

Remote Control

Audio version: Bluetooth voice remote
(Only for audio version)



1. Work indicator light
2. Power button
3. One click autofocus
4. Input signal source
5. Direction selection key - up
6. Direction selection key - left
7. Direction selection key - right
8. Direction selection key - down
9. Confirm/Play/Pause
10. Menu key
11. Return key
12. Home key
13. Manual focusing
14. Volume increase
15. Volume decrease
16. Mouse

Appendix:Warranty Card

1. This product follows the "Three Guarantee" policy since the purchasing date(according to the record),the projector is within 1 year warranty(nonhuman damage).
2. During the warrant period, all faults caused by technical problem of the product, our company will offer warranty service.
3. The following conditions are not covered by the warranty.
 - ①The accessories apart from the mainframe machine.
 - ②The disassembled and repaired product without permission
 - ③ External force and other damage caused by natural distater.
4. When failures occur, please contact the dealer or online service staff, send the product and filled-in warrant card to us, we will repair and send back as soon as possible.
5. This warrant responsibility only limited to repairing for products within warrant period, not responsible for any other problem.

Client's name: _____ Shop for purchase: _____

Customer ID: _____ Customer Phone: _____

Return address: _____

Problem Description:(For quick repairing, please carefully discribe the problem):



FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.