
说明书[含封面] 尺寸：8*10cm[单页] 不含出血 顺序从左往右 折页 做双面 一面中文一面英文

MINI forklift

# USER MANUAL

Please read the instructions carefully before use and keep them properly



1:64 alloy model remote-controlled engineering vehicle, 2.4Ghz, Three-speed Switching alloy material, Type-C direct charging, lifting up/down, lighting and music

Thank you for using our company's toy products. In order to give you a better understanding of this product, please use them before use Reading the following instructions thoroughly will bring you a different operating experience.


**Attention: The remote control car product in this manual is for reference only. Please refer to the actual product for the product design!**

- Electronic control product:
  This product is assembled/charged by adults and then played by children. Adult supervision is always recommended.
- Warning: Please do not disassemble or modify this product without authorization,any changes may cause the product to malfunction frequently used.
  This manual is applicable to the introduction of a series of products in our company.Each product has a different configuration,please refer to the specific configuration check the configuration of the packaging box.

1.The product comes with a built-in 3.7V-200mAh rechargeable battery and an intelligent charging cable; The remote control uses one 3V button battery;
2.The removal and installation of remote control batteries should be carried out correctly according to the polarity and voltage indicated in the battery compartment.;
3.Adult supervision is required during the charging process to avoid accidents. When not in use for a long time, it also needs to be charged and maintained every two weeks;
4.This product is suitable for ages 6 and above;
5.Only batteries that are the same or equivalent to the recommended battery can be used;
6.The battery should be removed from the remote control when it is used up; if not used for a long time, please remove the battery from the remote control;
7.Press the lock on the battery compartment cover of the remote control with a tool, insert the battery according to the correct positive and negative polarity, and when using the frequency matching, first remove the remote control isolation plate;
8.The product should avoid contact with water and chemicals to prevent damage, and should not be used on soft surfaces such as blankets, sand, etc. Because it can affect speed and lifespan;
9.Maintenance and upkeep: This product is composed of plastic, hardware, and electronic components. It should not be immersed in water or placed or used in a humid environment for a long time. Regularly check whether the wires, plugs, shells, and other components are damaged. If any defects are found, they should be stopped from use until they are repaired completely;

## Detailed explanation of alloy model engineering vehicle


### 1.Product Configuration





## Remote Control Instructions

### 2.Battery installation


- Open the remote control battery cover, place the 3V CR2032 button battery with the negative pole facing downwards into the battery compartment, and cover the battery cover.




### 3.Remote control frequency matching





### 4.Model car charging





*Attention: When charging, it is necessary to first turn off the power of the model car before charging;
(When charging, the indicator light is green. When the indicator light is turned off, the charging is complete)

### 5.Remote control function





### 6.How to use mobile app(IOS&Android)




## How to play remote control car

### 1.basic operation





- The brightness of the remote control indicator light has decreased, and the remote control distance has become closer. Please replace the remote control battery CR2032, use a tool to press the battery cover switch, open the battery compartment, and replace the battery according to the same model and direction

### 2.Trim Function




If the remote-controlled car deviates left while driving straight, adjust the trim device at the bottom of the car to the right until it resumes straight motion.If it deviates right while driving straight, adjust the trim device at the bottom of the car to the left until it resumes straight motion.

### 3.Three-speed Switching




- **Operation Instructions**

The ideal driving environment for the remote-controlled car is a smooth, clean, and flat surface. If driven on uneven or uncleaned ground, foreign objects such as dust, debris, and hair adhering to the surface may obstruct the normal movement of the remote-controlled car, affecting its handling performance and driving stability.




- **Safety usage tips**

Regularly check toys, batteries, the wires of charging cables and plugs. If any of these components are damaged, stop using them until they are repaired or replaced.

- **Operation tips**

Please make sure that the power switch is in the "ON "position,when you operate,If the power switch is in"OFF",the remote control car is in the off state.When the power switch is in the "OFF"position, the remote control car is in the off state.
When the battery power is consumed, the left and right steering is not sensitive,and the forward and backward will be slow;Take off the battery and charge it.
The effective control range of the remote control is approximately 20 meters. The APP is approximately 10 meters.When the distance is exceeded, the remote -confrolled car may stop or become uncontrollable.

**Over-Discharge Protection Function**

If the remote-controlled car remains stationary for about 3-4 minutes, it will power off. To resume playing, you need to turn it on again and perform frequency pairing.If the remote control remains stationary for about 3-4 minutes,it will enter sleep mode. In sleep mode, theindicator light will turn off, and it can be awakened by any operation.

## General fault handling

| Fault symptoms | Reason for malfunction | Processing method |
| --- | --- | --- |
| The vehicle cannot be driven | 1.The remote control is not connected or remotely controlsthe car The switch is not turned on.<br>2.The remote control battery is not properly installed.<br>3.The built-in rechargeable battery pack has insufficient power. | 1.Turn on the remote control car switch and reconnect Connect the remote control.<br>2.Install the battery correctly in the remote control.<br>3.Charge the remote controlled car. |
| Uncontrolled vehicles Remote control distance is close | 1.The remote control battery or rechargeable battery pack has insufficient power.<br>2.There may be interference sources near the venue. | 1.Replace the remote control battery with a new one, or charge the remote-controlled car.<br>2.Change the venue. |
| Abnormal protection | 1.When the remote control car function is obstructed by external forces When unable to complete all functional actions,Or when the circuit battery is short circuited. | 1.Turn on the power switch again for the power-off protection of the remote controlled car. |

- **To consumers**

1.When playing with remote control cars indoors, please be careful not to cause damage to furniture or glass.
2.Please play outdoors in a safe place and do not play with remote controlled cars on roads or in crowds to avoid danger.
3.When playing with a remote-controlled car outdoors and hearing thunder,stop playing immediately.
4.Do not drive the remote control car towards people.
5.Do not litter or collide the remote control car.
6.When placing the remote control car, please stay away from sources of fire and high temperatures.
7.This car adopts complex electronic circuits and a large number of components.Please do not disassemble or modify the circuit board at will.
8.When the remote control car is covered with soil and dust after playing, it should be gently wiped with a damp cloth.
9.Do not put toys in water, as it can damage electronic components.
10.The packaging box and instructions contain important information, please keep them properly.

- **Maintenance matters**

1.Keep away from fire sources, avoid direct sunlight, high temperature and humidity, or keep in the car for a long time to avoid short circuits in the circuit to catch fire.
2.When not in use, remove the batteries from the remote control and store the remote-controlled car and remote control back in their colorul box packaging to avoid damage or deformation during transportation or storage.
3.The remote control car should be gently wiped with a damp cloth.
4.When not in use, please remove the batteries from the remote control to prevent reducing battery life.

- **Reminder**



*Do not play on the roadside or in dangerous places to prevent accidents.

*Do not play with remote-controlled cars in sewage pits.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different  from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction