

Voxnoos G01 AI Glasses

user's manual

FCC Warning

Note: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.


Product Overview



Cautions

- Ensure your device and charging port are completely dry before charging. Never charge in a damp or wet environment.
- For optimal safety and performance, always use the original charging cable that came with your product.
- This product contains flexible materials; handle with care. Do not drop, squeeze, or bend it.
- If the product is damaged or cracked, stop using it immediately to avoid injury from sharp edges.
- This product is not waterproof. To prevent damage, do not expose it to rain, moisture, or immerse it in any liquid.
- **This product has photo and video recording capabilities. Please strictly adhere to local laws and regulations and use this product responsibly. Do not use it for any illegal activities that infringe upon others' privacy, such as surreptitious filming.**

Control



Right Button ①

1. Take Photo: Short press once when the device is on.
2. Record Video: Long press for 1 second to start recording when the device is on. Short press again during recording to stop.

⚠ Note: Photos and videos are saved directly on the device. You can connect to the app anytime to import them to your phone.

Left Button ②

1. Power On: Long press for 2 seconds when the device is off.
2. Power Off: Long press for 3 seconds when the device is on.
3. Object Recognition: Short press once when the device is on to identify and describe objects in front of you.

Touch Area ③

1. Music Control
 - Play/Pause: Double-tap
 - Next Song: Triple-tap
 - Volume Up: Slide forward
 - Volume Down: Slide backward
2. Call Control
 - Answer Call: Double-tap when ringing
 - End Call: Double-tap during a call

Factory Reset (Buttons ① + ②)

To restore the device to factory settings, simultaneously **long press both the Left and Right buttons for 5 seconds** when the device is on.

✗ **Warning:** This action will erase all data on the device and cannot be undone. Please proceed with caution.

💡 "Hey Simi" Voice Wake-Up

When your device is powered on, simply say the wake-up phrase "Hey Simi" to activate your smart assistant.

You can try the following commands:

- "Hey Simi, what's this?"
- "Hey Simi, take a photo for me."
- "Hey Simi, start recording."

Getting Started

To unlock the full potential of your smart glasses, connect them to the mobile app first.

1. Download from App Stores:

- iPhone users: Search for "Voxnoos" in the App Store.
- Android users: Search for "Voxnoos" in Google Play.

2. Scan QR Code:

You can also directly scan the QR code below and select your phone's operating system to download the app.



Open the app and follow the prompts to complete registration and login.



Go to the "Device" > "Connect Device" page.



From the list of found devices, select your device "Voxnoos G01" and tap "Connect"



If the app automatically jumps to the device control interface, your connection was successful.

Helpful Tips

To ensure the stable operation of core functions, it's recommended to avoid long recording sessions or data transfers when the battery is low. This prevents interruptions that could lead to data loss.

This product supports Wi-Fi data transfer to your phone. To ensure this feature works correctly, please grant the necessary permissions to the app in your phone's system settings.