


Juicy Jams Instruction Manual




Product Specs

- Input: 5V/1A
- Output: 5V/2.4A
- Battery Capacity: 5000mAh & 25mAh*2

Product Overview

1. Earbuds charging port
2. Power button
3. Touch screen
4. LED indicator light
5. USB-A output
6. USB-C input



How to Use

- Press and hold the power button to turn on the power bank
- Remove the earbuds and place in your ear
- You will hear a voice prompt that will automatically go into pairing mode
- Open the wireless connection settings on your device and select "Juicy Jams"
- Your device is now connected to the earbuds
- Next, open the settings page on the power bank and scroll down to the "Connect mobile phone" tab
- A QR code will appear on the screen
- Open the camera on your phone and scan the QR code
- This will allow you to connect your phone to the power bank
- Now you can control things like your music or camera
- Enjoy many other apps in the device such as games, calendar, voice recordings, messages, and more.

How to Charge

- Place earbuds into the case, close the lid, and they will automatically begin to charge
- To charge your device, plug the provided charging cable into the USB-A port and the other end into your device
- To charge the power bank, plug the provided charging cable into the USB-C port and the other end into a proper power source

IMPORTANT SAFETY INSTRUCTIONS

WARNING: When using this product, basic precautions should always be followed. Read instructions before use.

Never store product in temperatures below 32°F (0°C) or above 104°F (40°C).

Do not over charge your device with the power bank. The power bank may become hot with excessive use.

Do not expose the power bank to moisture or extreme heat.

When charging, the power bank may feel warm, this is a normal operating condition and should not be cause for concern.

To avoid risk of fire or injury, only use the charging cable provided to charge the power bank.

Do not use the power bank if damaged or modified.

Do not disassemble the power bank.

Do not use the power bank in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury to persons.

Switch off the power bank when not in use.

Do not dispose of power bank in heat or fire.

To reduce the risk of injury, close supervision is necessary when power bank is used near or by children.

DISPOSAL INFORMATION FOR USER:

Recycle according to local recycling and environmental regulations.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.