


Bamboom Wireless Speaker

Instruction Manual



Product Specs

Input: 5V/1A

Output: 10W


Battery Capacity: 1800mAh

Up to 6 hour playtime

2-3 hour charge time

Product Overview

1. USB-C Charging port
2. Aux port
3. TF Card Slot
4. USB-A port
5. Volume Down/Previous Song
6. Play/Pause
7. Volume Up/Next Song
8. Wireless mode Button
9. Power Button



Getting Started:

- Turn on the device by pressing and holding the power button for 3 seconds
- Press the "M" button to activate wireless connection
- Open your phone wireless settings and find the device called "Bamboom"
- To turn the volume up/down press and hold the button with the "+" or "-" icon
- To change the song quickly press the back or forward button

Charging the Speaker:

- Plug the included USB-C charging cable into the charging port on the top of the speaker
- The LED indicator light will show red when charging
- It is recommended to fully charge the battery before use
- Do not over charge the battery and always use a proper power source

DO NOT DISSASSEMBLE. BATTERY NOT REPLACEABLE.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

BEST Promo USA
201 Clay Rd, Suite 200
Sunnyvale, TX 75182
+1(972) 552-3636
www.hpgbrands.com