


ANC Headphones Instruction Manual




Product Specs:

Input: 5V/0.35
Output: 10mW *2
Battery Capacity: 350mAh
Up to 30 hours of playing time
2 hour charge time

Product Overview:

1. Volume nob
2. Power button
3. AUX port
4. Battery indicator
5. USB-C port



Getting Started:

- Turn on the device by pressing and holding the power button for 3 seconds
- Your headphones will automatically go into pairing mode
- Open your phone wireless settings and find the device called "LUXE ANC"
- To turn the volume up/down rotate the nob left and right
- Press the power button once to cycle between active noise canceling, transparent mode on, and transparent mode off
- Quickly press the nob to pause/play your music

Charging the Headphones:

- Plug the included USB-C charging cable into the charging port on the bottom of the headphones
- The LED indicator light will show between 1 and 3 lights
- It is recommended to fully charge the battery
- Do not over charge the battery and always use a proper power source

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

BEST Promo USA
201 Clay Rd. Suite 200
Sunnyvale, TX 75182
+1(972) 552-3636
www.hpgbrands.com