wall light
Assembly Instructions
YJ-25-055

CAUTION


- Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have resulted during shipping. If there is a defect in the wire, do not attempt installation.
- Before starting the installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.


TOOLS REQUIRED


Ladder



Safety glasses


Electrical tape



Phillips screwdriver



Flat blade screwdriver



Pliers



Wire strippers



Silicone




Mounting plate


Mounting Screws


Wire Nuts


Cap Nuts



Washers

***PARTS SHOWN MAY DIFFER SLIGHTLY PER LIGHT FIXTURE**

INSTALLATION

Important to know

1. This fixture requires a 110-120 VAC, 60 Hz power source.
2. Make sure the power is switched OFF before installation.



STEP 1:
Uninstall mounting plate (A) by rotating cap nuts (DD) counterclockwise. Install the mounting plate (A) to your junction box with the mounting screws (CC).

STEP 2:
If the house ground wire is copper (option A) fix the copper (ground) wire from the junction box to the mounting plate (A) by wrapping it around the green (ground) bolt (BB), then connect it to the fixture copper (ground) wire with a provided wire nut (AA). Alternatively, you can connect both copper (ground) wires together directly with a provided wire nut (AA). If the house ground wire is green (option B) splice the green (ground) wire (1/2in strip) to expose the copper wire within, then loop the exposed wire to the green (ground) bolt (BB) on the mounting plate (A). Then attach it to the copper (ground) wire from the fixture using a provided wire nut (AA). Then, pass all wires through mounting plate (A). Connect the fixture neutral (white) wire to house neutral (white) wire and the fixture black (live) wire to the house black (live) wire. Use provided wire nuts (AA) to make all connections.

STEP 3:
Install the backplate (B) to the mounting plate (A) by inserting the bolts from the mounting plate (A) through the holes on the backplate (B), then use the washers (EE) and cap nuts (DD) to tighten the back plate (B). Ensure that cap nuts (DD) are securely tightened.

STEP 4:
Apply a clear silicone sealant (not supplied) around the outside perimeter of the back plate (B).

CONNECTING INSTRUCTIONS

1 Download the "Tuya Smart" app

Make sure your mobile device is runing
ios 9.0/watchOS 2.0/Android™ 4.4 or higher.

- Download the "Tuya Smart" app from the iOS or Android store.You can also directly scan the QR code on the right to download.
- Use your email to create an account and log in.

2 Set your fixture in pairing mode

- Once the fixture is installed correctly and is powered on, the light should be pulsing, indicating it is in pairing mode.
- If the light is not pulsing, toggle the power switch off and on five times in this pattern: Off / On / Off / On / Off / On / Off / On / Off / On.Ensure the device is completely powered off for a second between each power cycle.

3 Connect to the "Tuya Smart" app

On your mobile device, please ensure all requested permissions are enabled: Wi-Fi, Bluetooth, location Services.

Ensure you are connected to a 2.4 GHz Wi-Fi network, If you are unsure, check your router settings or ask your internet provider.

- Select the "+" icon in the top right of the "Tuya Smart" app home screen,and then select "Add Device."
- If the light is pulsing.the app will start scanning to find your fixture. When the fixture is found by the app, an icon "Outdoor Sconce" of the fixture will be displayed on the interface and you can select your fixture icon.
- Enter your Wi-Fi credentials correctly. If the Wi-Fi connection is unstable, use the alternate connection method available on this screen.
- Once your device has been successfully added, tap "Done" to finish the set up.
- You can now control your fixture directly from the "Tuya Smart" app.

4 Remove your fixture device from the "Tuya Smart" app

The same fixture device can only be connected through one mobile device. If you need to use another mobile device to connect, you must delete the fixture device in the "Tuya Smart" app of the previous mobile device.

- Select the "Edit" icon in the middle of the main screen of the "Tuya Smart" application, and then choose the "-" icon in the upper left corner of the fixture device icon you want to delete.

For more functional operations, please complete them in the "Tuya Smart" app.

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body.