



08

08

MON 10/18

English instruction manual



Telescopic
camera

Press and hold
to select
Shutdown,
restart, and SOS



SIM card

© When the watch cannot be turned on due to battery sleep, long press the power button for 20 seconds to reset the watch. After the reset, please charge the watch for 30 minutes before turning it on.

© After loading the card, please completely seal and plug the card cover, not completely plug may have the risk of water.

Charge and boot

① Please charge the product for more than two hours before use.

② After full charge, long press the power button for 3 seconds to start. After the card is installed, it can be switched off in the watch Settings.

© Please use the special charging cable in the package to charge. Please dry the charging port before charging. The charging time should not exceed 4 hours.

© Do not use the power adapter with an output of more than 5V 1A to charge, otherwise it may burn out the circuit and cause no charging.

Installing a SIM Card

SIM Card Size: Nano SIM card (Please turn off the watch before installing Nano card)

Insert card direction: Follow the insert card directions into the machine

Package requirements: Open caller ID, open GPRS Internet access function (watch support 4G traffic)

APP download and login



APP download: Scan the QR code on the right side with your mobile phone or go to the APP Store or App Store to download and install SeTracker or SeTracker2

APP login: In the login interface, find the registration option, use email to register an account, and then enter the registered account and password to log in to the APP

Binding watch

① Open the APP and bind the watch in the Add device function. Install the SIM card and connect the watch to the network for 3 minutes before the registration code appears. Find the registration code binding on the watch interface and check whether the registration code is correct when binding.

Note: After replacing the SIM card, please re-bind the watch's registration code, which will change every time you change the card.

② After the binding is successful, the number can be located and saved after the watch is connected to the network. Please enable the notification permission of the APP to receive the message notification of the watch.

Function introduction

Watch supports full-screen touch, slide up, slide down, left slide, right slide, long press and other operations, swipe the screen to switch to view various functions; You can also tap and hold down the screen for related operations. The watch supports functions such as phone call, micro chat, location, video call, and alarm clock.

Note: To manage the watch through the APP, all operations on the watch need to be pushed to the watch by the network, subject to the network situation, sometimes there will be a delay, the length of the received time is related to the network condition.

Q&A

① Why does the watch always show offline status?

- A: 1. Check whether the SIM card is correctly installed, whether the network signal displayed in the status bar is normal, whether the fee is overdue, and whether the data traffic is enabled.
2. Disconnect the network when the network environment of the watch is poor. After a few minutes, the watch will reconnect to the server.
3. Use the mobile phone to edit the SMS pw,123456,ts# to send the phone card number of the watch, you can inform your distributor of the SMS content replied by the watch, and check whether the parameters are correct.
- ② Can other family members tie a watch?

A: Yes, please register an account first and then bind the watch. A maximum of 10 accounts are allowed to bind the watch. The deputy administrator needs to contact the primary administrator for authorization.

③ Can't charge the watch?

- A: 1. The battery is too low, please charge for at least 30 minutes.
2. Replace the charger and try charging again.
3. If there is dirt and rust in the charging place, please clean it first. The USB interface and charging head need to be fully contacted to charge successfully.

Care and maintenance

Do not expose the watch to high moisture, high temperature or low place for a long time.

It can prevent dust conditions such as living rooms, offices, laboratories, light industry studios, storage rooms, etc., and is not suitable for special dust environments.

③ If the watch crashes and restarts, long press the power button for 20 seconds to reset the watch. After the reset, please charge the watch for 30 minutes and then turn it on.

"The Company reserves the right to modify the contents of this manual without prior notice.

Some features are different in specific software versions, as is normal.

Manual de instrucciones en español



Cámara telescópica

La prensa larga
puede seleccionar
apagado, reinicio,
SOS.



La tarjeta SIM

© cuando el reloj no puede encenderse y mostrarse debido a la suspensión de la batería, puede mantener presionado el botón de encendido durante 20 segundos para restablecer el reloj. Después de reiniciar, cargue primero 30 minutos antes de encenderlo.

© después de cargar la tarjeta, por favor, cierre completamente la tapa de la tarjeta y taparla firmemente. Si no está completamente tapada, puede haber un riesgo de agua.

Carga y arranque

① por favor, cargue el producto por más de dos horas antes de usarlo.

② después de cargar completamente, mantenga presionado el botón de encendido durante 3 segundos para encender. Después de cargar la tarjeta, se puede operar en el ajuste del reloj para apagar.

© use el cable de carga especial incluido en el paquete para cargarlo. Por favor, seque el puerto de carga antes de cargarlo. El tiempo de carga no debe exceder 4 horas.

© tenga en cuenta que no use el adaptador de corriente con salida superior a 5V 1A para cargar, de lo contrario, el circuito puede quemarse y no cargar.

Instalar una tarjeta SIM

Tamaño de la tarjeta SIM: Nano SIM (apague su reloj antes de instalar la tarjeta Nano)

Dirección de inserción de la tarjeta: cargue en la máquina de acuerdo con la dirección de inserción de la tarjeta

Requisitos del paquete: abra la identificación de llamadas, abra la función de internet GPRS (el reloj apoya el tráfico 4G)

Descarga de APP y login



Descarga de la aplicación: escanee el código qr a la derecha con su teléfono o vaya a APP Store, APP mall para descargar e instalar SeTracker o SeTracker2

Inicio de sesión en la aplicación: en la pantalla de inicio de sesión, encuentre la opción de registro, utilice el correo electrónico para registrar la cuenta, luego ingrese la cuenta registrada y la contraseña para iniciar sesión en la aplicación

Ató el reloj

① abra la aplicación y conecte el reloj en la función de agregar dispositivo.

Después de instalar la tarjeta SIM y conectar el reloj a la red durante 3 minutos, el código de registro aparecerá. Encuentre el enlace del código de registro en la interfaz del reloj. Al enlazar, asegúrese de que el código de registro sea correcto.

Nota: después de cambiar la tarjeta SIM, vuelva a vincular el código de registro del reloj. El código de registro cambiará cada vez que cambie la tarjeta.

② después de la vinculación exitosa, puede localizar y guardar el número después de que el reloj esté conectado a la red. Por favor, habilite el permiso de notificación de la aplicación para recibir la notificación del mensaje del reloj.

Introducción a funciones

El reloj admite el toque de pantalla completa, deslizamiento hacia arriba, deslizamiento, deslizamiento a la izquierda, deslizamiento a la derecha, presione largo y otras operaciones, deslice la pantalla para cambiar para ver todas las funciones; También puede hacer clic y mantener pulsado en la pantalla para realizar operaciones relacionadas.

El reloj soporta llamadas telefónicas, microchat, localización, videollamadas, alarma y otras funciones.

Nota: administrar el reloj a través de la aplicación, todas las operaciones en el reloj, necesita la red para empujar al reloj, limitado a la situación de la red, a

veces hay un retraso, el tiempo de recepción está relacionado con la condición de la red.

PREGUNTAS FRECUENTES

① ¿Por qué el reloj sigue mostrando fuera de línea?

R: 1. Compruebe si la tarjeta SIM está instalada correctamente, si la señal de red de la barra de estado muestra normal, si debe cargos y si abre tráfico de datos.

2. El reloj se desconecta cuando el entorno de red es pobre. El reloj volverá a conectarse al servidor después de unos minutos.

3. Edite el mensaje de texto pw,123456,ts# con su teléfono móvil para enviar el número de la tarjeta de teléfono del reloj. Puede informar el contenido de los mensajes de texto que el reloj responde a su distribuidor y comprobar si los parámetros son correctos.

② ¿Otros miembros de la familia pueden vincular el reloj?

R: sí, por favor, registre su cuenta antes de vincular el reloj. Se permiten hasta 10 cuentas para vincular el reloj. El administrador adjunto debe ponerse en contacto con el administrador principal para la autorización.

③ ¿El reloj no se puede cargar?

A: 1. La batería es demasiado baja. Por favor, cargue por lo menos más de 30 minutos.

2. Cambie el cargador e intente cargar nuevamente.

3. Hay moho sucio y otras condiciones en el lugar de carga? Limpie primero. El puerto USB y el cabezal de carga deben tocar completamente para cargar con éxito.

Mantenimiento y cuidado

- ① no exponga el reloj a una humedad más alta, temperatura más alta o más baja durante mucho tiempo.
- ② puede evitar condiciones de polvo como sala de estar, oficina, laboratorio, estudio industrial ligero, sala de almacenamiento, etc., no es adecuado para ambientes especiales de elevación de polvo.
- ③ el reloj aparece muerto reiniciar fenómeno, puede mantener presionado el botón de encendido durante 20 segundos para restablecer el reloj. Después de reiniciar, por favor, cargue primero 30 minutos antes de encender.

"Nos reservamos el derecho de hacer cambios de contenido a esta instrucción sin previo aviso.

Algunas funciones difieren en versiones específicas del software, como es el caso normal ".

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harm full interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Specific Absorption Rate (SAR) information:

This Device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Device has also been tested against this SAR limit. This device was tested for 0 mm for body-worn and 5mm for face up position respectively between the unit and the body of the user. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0 mm for body-worn and 5mm for face up position respectively between the user's body and the back of the Device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.