


Product Instructions

Mobile power supply usage



- ▶ LED display for residual power
- 25 When residual power is lower than 25%
 - 50 Residual power is between 25% -50%
 - 75 Residual power is between 50% -75%
 - 100 Residual power is between 75% -100%

- ▶ Switch of power supply
- Connect it with mobile phone and press this button. It will charge to the mobile phone.

How to use usb flash disk




Push in the direction of the arrow


1. Open the buckle of the notebook
2. Pull out the usb flash disk hidden in the buckle
3. Insert the U disk into the reading device for use

* pay attention to the pros and cons when connecting the usb flash drive to the computer

Instructions for Using the Bracket



Wireless charging for the watch



Wireless charging for the mobile phone

The wireless charging stand can be used to charge the watch when it is placed flat, and it can charge the mobile phone when it is set upright. The mobile phone needs to have a magnetic suction function.


Kindly reminder:
Put the product close to fire is strictly prohibited!
Children need to use it under accompanied by adults.
Non-professionals is not allow to take apart the power bank.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

Product Instructions

Mobile power supply usage



- ▶ LED display for residual power
- 25 When residual power is lower than 25%
 - 50 Residual power is between 25% -50%
 - 75 Residual power is between 50% -75%
 - 100 Residual power is between 75% -100%

- ▶ Switch of power supply
- Connect it with mobile phone and press this button. It will charge to the mobile phone.

How to use usb flash disk




Push in the direction of the arrow


1. Open the buckle of the notebook
2. Pull out the usb flash disk hidden in the buckle
3. Insert the U disk into the reading device for use

* pay attention to the pros and cons when connecting the usb flash drive to the computer

Instructions for Using the Bracket



Wireless charging for the watch



Wireless charging for the mobile phone

The wireless charging stand can be used to charge the watch when it is placed flat, and it can charge the mobile phone when it is set upright. The mobile phone needs to have a magnetic suction function.

Kindly reminder:
Put the product close to fire is strictly prohibited!
Children need to use it under accompanied by adults.
Non-professionals is not allow to take apart the power bank.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction