


MU-A01说明书 65*85mm

MUCW

MU-MP06

Instructions & Warranty



Package Contents

● Speaker *2

● Charging cable *1

● Organizer bag *1

● User manual *1

Basic Specifications

Product name	MUCW Palm of Your Hand Wireless Speaker
Product model	MP06
version	V6.0
Output Power	2*5W
Signal-to-Noise Ratio	≥86dB
Product Weight	≈150g
Speaker	33MM(4Ω 5W*2
Battery Capacity	400mAh*2
Audio Input	Bluetooth
Power Input	DC 5V≐1A
Frequency Range	50Hz-20KHz
Product Dimensions	≈42MM*42MM
Executive Standard	GB 4943.1-2022

Installation and Setup

Charging Pogo Pin



Power On/OFF Control Button

LED Indicator Light

Power On: Press and hold for 1 seconds
Power Off: Press and hold for 5 seconds
Play / Pause / Answer Call: Press once
Reject Call: Press and hold for 2 seconds
iNext Track: Press twice
Activate Voice Assistant: Press and hold for 2 seconds

Operation Instructions

● Bluetooth Audio Connection:
Connect the speaker to a Bluetooth-enabled tablet or smartphone. Press and hold the power button for 1 second to power on the speaker. After the prompt tone ends, if others pairing inside. The red and blue indicator lights flash alternately rapidly, indicating the device is ready for pairing. On your device, go to Settings -> Bluetooth, search for device, select "MUCW MP06" and tap to connect. A successful connection will be confirmed.

● TWS Mode Playback:
The speakers support TWS pairing, allowing any two units to connect wirelessly for stereo sound.

● TLED Indicator Status:
● Charging Mode:the indicator stays solid, it glows ice-blue during charging.
● Pairing Mode:led and ice blue lights flash alternately.
● Low Power Mode:the indicator flashes red, with one cycle of 3 flashes every 3 minutes.

Safety Precautions

• Do not disassemble or replace internal parts unless otherwise specified in the manual.

• This product is not waterproof. Do not expose it to water or any other liquids.

• If liquid accidentally enters the device, immediately disconnect the power supply and clean it.

• Ensure your hands are dry when installing or removing the product to avoid electric shock.

• Do not place the product near heat sources, open flames, or strong

Troubleshooting

Fault	Solution
Pairing Failure	Turn the speaker off and on again, or disable and re-enable Bluetooth on your mobile phone.
Stuttering or Intermittent Audio	Check if the connection distance exceeds the Bluetooth range, or if there are obstacles between the speaker and your phone.
No Sound	Check if the volume of the speaker is set to the minimum.
Failure to Power On	Check if the speaker's built-in battery is charged.
Power Indicator Not Lighting Up	Check if the charging port is properly connected.
Low or Distorted Sound	The output current of the charger is insufficient. Please replace it with a charger that meets the specifications.
Low Volume	Adjust the volume on your audio source device to an appropriate level.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.
Note:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

This device has been evaluated to meet general RF exposure requirements. This device can be used in portable exposure conditions without restriction. This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Return & Warranty Policy


30-Day Money-Back Guarantee
We stand behind the quality of our products. For any reason you are not completely satisfied, you may return your purchase within 30 days for a full refund--no questions asked.
3-Month Limited Warranty
Your purchase is covered by a 3-month warranty. During this period, if the product is found to have defects in materials or workmanship, we will provide a free replacement or repair.
Customer Support
Our customer support team is ready to assist with returns, exchanges, or any questions you may have.
Email: mucw.official@gmail.com

Manufactured in Shenzhen Weishida Technology Co., Ltd.
Address: Room 1606, Building 1, Qianhai Kexing Science and Technology Park, Laosheng Community, Xixiang Subdistrict, Bao'an District, Shenzhen, China
Company Email:mucw.official@gmail.com
Made in China

MUCW

MU-MP06

使用说明和保修条款



包装清单

● 音箱*2

● 充电线*1

● 收纳包*1

● 使用说明书*1

基本参数

产品名称	MUCW掌心创意无线音箱
产品型号	MP06
版本	V6.0
输出功率	2*5W
信噪比	≥86dB
产品重量	≈150g
扬声器	33MM(4Ω 5W*2
电池容量	400mAh*2
音频输入	蓝牙
电源输入	DC 5V≐1A
频率范围	50Hz-20KHz
产品尺寸	≈42MM*42MM
执行标准	GB 4943.1-2022

按键和说明

充电桩接触点



开机/功能按钮

LED指示灯

开机：长按1秒
关机：长按5秒
播放、暂停、接听电话：按按键1次
拒接电话：长按2秒
下一曲：按按键2次
启动语音助手：长按2秒

操作说明

1. 蓝牙连接步骤：将音箱与具有蓝牙功能的平板电脑或智能手机连接。长按下开机按钮1秒，语音提示后进入为蓝牙配对状态，红色和冰蓝灯闪烁，此时音箱等待配对状态。在您的设备上转到设置，打开蓝牙功能并搜索蓝牙设备，找到 "MUCW MP06" 并点击连接，连接成功。

2. TWS模式播放：TWS自由配对，任意两台机器可互配。

3. LED指示灯状态：
• 充电模式：充电指示灯常亮状态，充电状态指示灯为冰蓝色。
• 配对状态：红色和冰蓝色指示灯交替闪烁。
• 低电模式：红灯闪烁，每3秒钟闪烁一轮，每轮闪烁5次。

安全预防措施

1. 原非手册中另有规定，否则不得拆卸或更换内部零件。

2. 本产品不防水，不要接触水或其他液体。

3. 如果液体意外进入设备，请立即断开电源并清洁。

4. 安装或拆卸新产品时，确保手干燥，以免触电。

5. 请勿将产品放置在热源、光源或电磁环境附近，否则可能会造成损坏。

常见问题及解决方法

故障	解决办法
配对失败	关闭扬声器并再次打开，或关闭手机上的蓝牙并打开
卡顿断音	播放距离是否超出范围，或者扬声器和手机之间是否有障碍物
静音	检查扬声器音量是否调到最小
无法启动	扬声器内电池是否充电
电源灯不亮	检查充电口是否插好
声音低或失真	充电器输出电流不足，请更换符合规格的充电器
音量低	将扬声器音量调整到合适的音量。

FCC声明

该设备符合FCC规则第15部分。操作受以下两个条件的约束：
(1) 此设备可能不会造成有害干扰。
(2) 此设备必须接受任何接收到的干扰，包括可能导致意外操作行为的干扰。
未经充分验证的一方明确能消除的任何更改或修改都可能使用户操作设备的权限无效。注：根据FCC规则第15部分，该设备经过测试，符合B类数字设备的限制。这些限制旨在为住宅安装提供合理的保护，防止有害干扰。该设备产生、使用并可以辐射射频能量。如果干扰照明的安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰，鼓励用户尝试通过以下一种或多种措施来纠正干扰：
•重新定向或重新定位接收天线。
•增加设备和接收器之间的间距。
•将设备连接到与接收器连接的电路不同的插座上。
该设备已被评估为符合一般射频暴露要求。
该设备可以在提供射频暴露条件下使用，不受限制。
本设备符合FCC针对未对环境设定的射频辐射暴露限值。
本设备及其天线不得与其他天线或发射器共同放置或配合使用。

退货保修政策

7天无理由退货
我们保证产品的质量，如果出于任何原因您不完全满意，您可以在7天内退还您的购买，并获得全额退款--无需理由。
12个月有限保修
您的购买享有12个月保修。在此期间，如果在材料或工艺上有任何缺陷，我们将提供免费更换或维修。
客服支持
我们的客服团队随时为您提供退货、换货或任何问题的帮助。
电子邮件: mucw.official@gmail.com

制造商：深圳市世纪时代科技有限公司
制造商地址：深圳市宝安区西乡街道劳动社区前海科兴科技园1号楼1606室
公司邮箱: mucw.official@gmail.com

合格证
请检查
中国制造