


MU-A01说明书 65*85mm

MUCW

MU-A01
Instructions & Warranty



Packing list

1 Speaker *1

2 Power cable *1


3 Audio cable *1

4 User manual *1

Basic parameter

Product name	Desktop wireless speaker
Product model	MU-A01
verition	V6.0
Functions	Wireless, TF, TWS, USB Disk, AUX, RGB Lighting
Speaker	57MM/4Ω 10W*2
Power input	DC 5V=1A
Output power	20W
Battery Capacity	4000mAh
Frequency response	20Hz-22KHz
Distortion rate	<3%
SNR	≥85dB
Wireless Name	MU-A01
Product size	Approx. 235*105*80mm
Product weight	Approx 1058g

Installation and Setup



🔊/⏸️: Long press to turn on/off; Short press 'pause/play'; Double click TWS connection/disconnection;Triple tap - Force disconnect/connect to Wireless.

M/⌂: Short press to switch modes; Long press to switch light effects; Double click to turn on/off the light effect

⏮️: Short press the previous song

⏭️: Short press a song

🔊: Short press to decrease volume; Press and hold to continuously decrease volume

➕: Short press to increase volume; Long press and hold to increase volume

Shutdown: In standby mode, it will automatically shut down after 5 minutes when the speaker is not running or in use; Long press the 🔊 key to shut down, prevent power failure, low battery alarm, and automatic shutdown function: when the battery level is low When it is below 10%, the speaker will emit a buzzing sound. At this point, the speaker should be charged promptly. When the battery level is low When it drops below 3%, the machine will automatically shut down.

Operation Instruction

- 1. Wireless audio connection: Connect the speaker to a Wireless enabled tablet or smartphone Turn on the speaker, the voice prompt indicates Wireless playback status, the blue light flashes rapidly, and the speaker is waiting for pairing.Go to Settings on your device, turn on Wireless function and tap to search for Wireless devices, find MU-A01 And click on the connection. After successful connection, the blue light will flash slowly and there will be a prompt sound.
- 2. TF card playback When connected to the "TF card" in the power on state, music can be automatically played.
- 3. USB playback: When the device is turned on and connected to a USB drive, the music inside the drive will automatically play.
- 4. AUX playback: Connect the 3.5mm audio cable to both the phone and computer to play music normally.
- 5. TWS playback: Before connecting the two speakers to Wireless, double-click the 🔊 button on both the main and auxiliary devices to bring in the audio to TWS Pairing mode, 3-5 seconds of successful voice pairing, with the blue indicator light constantly on. At this time, you can connect using a mobile phone Wireless. Press the 🔊 key again to disconnect TWS. When the TWS is not disconnected, turn off the sound box and then turn it back on to automatically reconnect the TWS.
- 6. LED indicator light status;Wireless mode: Connected status, blue light stays on, slow flashing blue light when playing music.Pairing status: The blue indicator light flashes rapidly

Charging indicator: The charging red light is on and the fully charged red light is off.

Safety Precautions

- Do not disassemble or replace internal parts unless specified in the manual.
- This product is not waterproof. Do not expose to water or other liquids.
- If liquid accidentally enters the device, disconnect power immediately and clean it.
- Ensure hands are dry when installing or removing the product to avoid electric shock.
- Do not place the product near heat sources, fire, or strong electromagnetic environments, otherwise damage may occur.

Common problems and solutions

Malfunction	Solution
Unsuccessful pairing	Turn off the speaker and turn it on again or turn off Bluetooth on the phone and turn it or
Staccato	Whether the connection distance is out of range or there is an obstacle between the speaker and the phone
Play silently	Check if the speaker is the smallest
Can not boot	Whether the built-in battery of the speaker is charged
Power light is not on	Check whether the charging port is plugged in
Low or distorted sound	The charger current is insufficient. Replace with another charger.
Low volume	Adjust the sound source device to a suitable level.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be u sed in portable exposure condition without restriction This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with anyother antenna or transmitter.

Return Warranty Policy

30-Day Money-Back Guarantee

We stand behind the quality of our products. If for any reason you are not completely satisfied, you may return your purchase within 30 days for a full refund — no questions asked.

3-Month Limited Warranty

Your purchase is covered by a 3-month warranty. During this period, if the product has any defects in material or workmanship , we will provide a free replacement or repair.

Customer Support

Our customer service team is here to help with returns, replacements, or any questions you may have.

Email: mucw.official@gmail.com

Manufacturer: Shenzhen Weishidai Technology Co., Ltd.


Manufacturer Address: Room 1606, Building 1, Qianhai Kexing Science Park, Laodong Community, Xixiang Street, Bao'an District, Shenzhen City

Company Email: mucw.official@gmail.com

Made in China

MUCW

MU-A01
使用说明和保修条款



包装清单

1 音箱*1

2 电源线*1


3 音频线*1

4 使用说明书*1

基本参数

产品名称	桌面无线音箱
产品型号	MU-A01
版本	V6.0
功能	蓝牙、TF、TWS、U盘、AUX、RGB灯光
扬声器	57MM/4Ω 10W*2
电源输入	DC 5V=1A
输出功率	20W
电池容量	4000mAh
频率响应	20Hz-22KHz
失真率	<3%
信噪比	≥85dB
蓝牙型号	MU-A01
产品尺寸	约235*105*80MM
产品重量	约1058g

按键和说明



🔊/⏸️: 长按-开/关机; 短按 “暂停/播放”; 双击-TWS连接/断开; 三击-强制断开/连接到蓝牙。

M/⌂: 短按切换模式; 长按切换灯效; 双击开/关灯效

⏮️: 短按上一首歌

⏭️: 短按下一首歌

🔊: 短按 音量减; 长按 持续音量减

➕: 短按 音量加; 长按 持续音量加

关机: 在待机状态下, 5分钟后自动关机, 不运行扬声器不使用时; 长按 🔊 键关机, 防止断电, 低电量报警和自动关机功能: 当电池电量低于10%时, 扬声器会发出蜂鸣声。此时, 扬声器应及时充电。当电池电量降至3%以下时, 机器会自动关机。

操作说明

1. 蓝牙连接音频: 将音箱与具有蓝牙功能的平板电脑或智能手机连接 将音箱开机, 语音提示为蓝牙播放状态, 蓝灯快闪, 此时音箱等待配对。 在您的设备上转到设置, 打开蓝牙功能并轻点搜索蓝牙设备, 找到 MU-A01” 并点击连接, 连接成功后蓝灯慢闪并有提示音。

2. TF卡播放: 开机状态接入 “TF卡” 将可自动播放音乐。

3. U盘播放: 开机状态下接入 “U盘” 将自动播放U盘内音乐。

4. AUX播放: 连接3.5mm端子音频线接入手机跟电脑均可正常播放音乐。

5. TWS播放: 两台音箱未连接蓝牙前, 主、副机双击 “🔊” 键语音提示进入TWS 配对模式, 3-5秒语音提示配对成功, 蓝色指示灯变常亮, 此时可以用手机连接 蓝牙。再次双击 “🔊” 键断开TWS。TWS未断开时关机音箱再开机自动回连TWS。

6. LED指示灯状态; 蓝牙模式:已连接状态,蓝色灯长亮,播放音乐时蓝灯慢闪。 配对状态:蓝色指示灯快闪。 充电指示, 充电红灯亮起,充满红灯灭。

安全预防措施

- 除非手册中另有规定, 否则不要拆卸或更换内部零件。
- 本产品不防水。不要接触水或其他液体。
- 如果液体意外进入设备, 请立即断开电源并清洁。
- 安装或拆卸产品时, 确保手干燥, 以避免触电。
- 请勿将产品放置在热源、火源或强电磁环境附近, 否则可能会造成损坏。

常见问题及解决方法

故障	解决办法
配对失败	关闭扬声器并再次打开, 或关闭手机上的蓝牙并打开
卡顿静音	连接距离是否超出范围, 或者扬声器和手机之间是否有障碍物
静音	检查扬声器是否最小
无法启动	扬声器内置电池是否充电
电源灯不亮	检查充电口是否插好
声音低或失真	充电器电流不足, 更换另一个充电器。
音量低	将声源设备调整到合适的音量。

FCC声明

该设备符合FCC规则第15部分。操作受以下两个条件的约束:

- (1) 此设备可能不会造成有害干扰,
- (2) 此设备必须接受任何接收到的干扰, 包括可能导致意外操作的干扰。

未经负责合规的一方明确批准的任何更改或修改都可能使用户操作设备的 权限无效。注: 根据FCC规则第15部分, 该设备经过测试, 符合B类数字设备 的限制。这些限制旨在为住宅安装提供合理的保护, 防止有害干扰。该设备产生、 使用并可以辐射射频能量, 如果不按照说明安装和使用, 可能会对无线电通信造 成有害干扰。但是, 不能保证在特定安装中不会发生干扰。

如果该设备确实对无线电或电视接收造成有害干扰, 鼓励用户尝试通过以下一种或多种措施来纠正干扰:

- 重新定向或重新定位接收天线。
- 增加设备和接收器之间的间距。
- 将设备连接到与接收器连接的电路不同的插座上。
- 请咨询经销商或经验丰富的无线电/电视技术人员以获取帮助。

该设备已被评估为符合一般射频暴露要求。

该设备可以在便携式暴露条件下使用, 不受限制

本设备符合FCC针对未控环境设定的射频辐射暴露限值。

本设备及其天线不得与其他天线或发射器共同放置或配合使用。

退货保修政策

7天退款保证

我们保证产品的质量。如果出于任何原因您不完全满意, 您可以在7天内退还 您的购买, 并获得全额退款-无需提问。

12个月有限保修

您的购买享有12个月保修。在此期间, 如果产品在材料或工艺上有任何缺陷, 我们将提供免费更换或维修。

客服支持

我们的客服团队随时为您提供退货、换货或任何问题的帮助。

电子邮件: mucw.official@gmail.com

制造商: 深圳市威时代科技有限公司

制造商地址: 深圳市宝安区西乡街道劳动社区前海科兴科技园1号楼1606室

公司邮箱: mucw.official@gmail.com

合格证
检验员: 

中国制造