


MU-C13说明书 65*85mm

MUCW

MU-C13
Instructions & Warranty



Packing list



① Desktop Computer Case *1

② Instruction Manual*1

Basic parameter

Product Name	MUCW wired abyss lighting and sound system
Product Model	MU-C13
Wireless version	V 5.4
Effective Distance	≤10m
Input Voltage	DC 5V≐1A
Audio Power	3W*2
Speaker Unit	4Q 3W*2
Frequency Response Range	100Hz - 20KHz
Input Sensitivity	700mvs50
Signal-to-Noise Ratio	≥85dB
Functions	USB Wired Connection / Wireless
Product Dimensions	Approx. 420 (L) * 77.5 (W) * 78 (H) mm
Product Weight	Approx. 830g

Installation and Setup



Operation Instruction

1.Sound Card Input

Insert the sound card's USB cable into the computer's USB port, After powering on the speaker, it will automatically enter sound card mode. Open the computer's sound settings and select " MU-C13 " as the device to use.

2.Wireless input

(1) In powered - on state, short - press the power on/off button "  " to switch to Wireless mode. Search for and select " MU-C13 " on the Wireless device. A voice prompt will indicate successful connection.

(2). To disconnect Wireless, long - press the play/pause button "  ", and the connection between the speaker and the current device will be cut off.

3.Answering/Ending/Rejecting Calls

When the mobile phone is Wireless - connected to the speaker and a call comes in: Short - press the "  " button to answer or end the call. Long - press the "  " button to reject the call.

Safety Precautions

1.Do not disassemble or modify the device for any reason, otherwise it may cause the speaker to malfunction or burn out.

2.Do not let the device come into contact with liquids and get wet, otherwise it will cause serious damage to the device.

3.Do not place the device in an environment with too low or too high temperature (below 0 ° or above 45 °).

4.Do not use the device in thunderstorm weather, Thunderstorms may cause the device to work abnormally, signal interruption and other phenomena.

Danger Warnings:

When children use this product, an adult must supervise from the side.

Do not place this product in an environment with corrosive substances or strong magnetic fields.

Do not impact, throw, or pierce the product. Avoid dropping, squeezing, or bending the product.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation configurations of the transmitter and its antenna(s).

Return Warranty Policy

30-Day Money-Back Guarantee

We stand behind the quality of our products. If for any reason you are not completely satisfied, you may return your purchase within 30 days for a full refund — no questions asked.

3-Month Limited Warranty

Your purchase is covered by a 3-month warranty. During this period, if the product has any defects in material or workmanship , we will provide a free replacement or repair.

Customer Support

Our customer service team is here to help with returns, replacements, or any questions you may have.

Email: mucw.official@gmail.com

Manufacturer: Shenzhen Weishidai Technology Co., Ltd.


Manufacturer Address: Room 1606, Building 1, Qianhai Kexing Science Park, Laodong Community, Xixiang Street, Bao'an District, Shenzhen City

Company Email: mucw.official@gmail.com

Made in China

MUCW

MU-C13
使用说明和保修条款



包装清单



① 桌面电脑音箱 *1

② 说明书及保修卡 *1

基本参数

产品名称	MUCW有线深渊灯光音响
产品型号	MU-C13
无线版本	V 5.4
有效距离	≤10米
输入电压	DC 5V≐1A
音箱功率	3W*2
扬声器单元	4Q 3W*2
频响范围	100Hz-20KHz
输入灵敏度	700mv±50
信噪比	≥85dB
功能	USB有线连接/蓝牙连接
产品尺寸	约420(长)*77.5(宽)*78(高)mm
产品重量	约830g

按键和说明



操作说明

声卡输入

将音箱USB线接入电脑USB端口，音箱开机后，自动进入声卡模式，打开电脑的声音设置，选择设备为“ MU-C13 ”,即可使用

无线输入

1.开机状态下，短按开机/关机按键“  ”切换至无线模式，打开无线设备搜索并选择“ MU-C13 ”，语音提示后，代表连接成功。

2.如需断开无线，可长按播放/暂停按键“  ”，即可断开音响和当前设备的连接。

接听/挂断/拒接电话

手机和音响无线连接，有电话接入时: 短按“  ”按键，接听/挂断电话 长按“  ”按键，拒接电话

安全预防措施

1.请勿以任何理由拆卸或改装设备，否则可能导致音箱发生故障或烧毁；

2.请勿让设备接触液体弄湿,否则会导致设备严重损坏;

3.请勿将设备置于温度过低或过高(0°以下或者45°以上)的环境中;

4.请勿在雷暴天气下使用设备,雷暴可以导致设备工作不正常,信号中断等现象

⚠ 危险警告：

儿童使用本产品时,必须有成人从旁边监督。

请勿将本产品放置于有腐蚀性物品、强磁场的环境。

请勿撞击、扔掷、针刺产品，避免跌落、挤压、弯折产品。

FCC声明

此设备符合美国联邦通信委员会规则第 15 部分的规定。该操作需满足以下两个条件： (1) 此设备不得产生有害干扰； (2) 此设备必须能够接收任何收到的干扰，包括可能导致不正常运行的干扰。

注意：此设备已通过测试,符合 FCC 规则第 15 部分中关于 B 类数字设备的限值要求。这些限值旨在为住宅环境中的有害干扰提供合理防护。本设备会产生、使用并可能辐射无线电频率能量。若未按照说明正确安装和使用，可能会对无线电通信造成有害干扰。然而，无法保证在特定安装环境中不会出现干扰情况。如果本设备确实对无线电或电视接收造成了有害干扰 (可通过关闭和开启设备来判断)，建议用户尝试通过以下一种或多种方法来解决干扰问题：

—重新调整或移动接收天线的位置。

—增大设备与接收器之间的距离。

—将设备接入与接收器所连接线路不同的电源插座上。

—向经销商或有经验的无线电/电视技术人员寻求帮助。

注：未经合规责任方明确批准的任何变更或修改，受让人概不负责。这样的修改可能会使用户操作设备的权限无效。

该设备已被评估为符合一般射频暴露要求。为了遵守 FCC 的射频暴露指南，距离必须至少为 20 厘米在散热器和身体之间，且操作和安装完全支撑发射机及其天线的配置。

常见问题及解决方法

故障	解决办法
配对失败	关闭扬声器并再次打开，或关闭手机上的无线并打开
卡顿静音	连接距离是否超出范围，或者扬声器和手机之间是否有障碍物
静音	检查扬声器是否最小
无法启动	扬声器内置电池是否充电
电源灯不亮	检查充电口是否插好
声音低或失真	充电器电流不足，更换另一个充电器。
音量低	将声源设备调整到合适的音量。

合格证
检验员: 