

PRODUCT INFORMATION

Model: HK072

Input: AC100-120V 50/60Hz

Maximum Load: 120lb

Material: PC+ABS

Maximum Tree Height: 9 ft

Maximum Power: 800W


Accessories:

A



Instructions

B



Tree base x1

C




Legs*4

D




Remote-control unit

E



E1 0.8-1.25 Sleeve E2 0.8-1.25 Adapter

F




F1 1.25-1.5 Sleeve F2 1.25-1.5 Adapter


1

INSTALLATION

1



- Install the four stand legs into the base until secure and make sure they are in perfect contact with the ground




2



Christmas Tree's Metal Pole Adapter E2 (0.8-1.25)
+Christmas Tree's Metal Pole Sleeve E1 (0.8-1.25)




Christmas Tree's Metal Pole Adapter F2 (1.25-1.5)
+Christmas Tree's Metal Pole Sleeve F1 (1.25-1.5)




- Choose the right adapter E2 (0.8-1.25) or F2 (1.25-1.5) fit into the center shaft of the base.
- Pass the Christmas Tree's Metal Pole Adapter Sleeve E1 (0.8-1.25) or F1 (1.25-1.5) through the bottom of the Christmas tree trunk and insert the trunk into the base.

2


3



- After placing the metal pole with the Christmas tree's metal pole adapter sleeve into the base, rotate the adapter sleeve until it locks into place, securing the metal pole to the product.




- After the metal pole is fixed, install the remaining Christmas tree metal poles by one



- Plug the Christmas tree lights into the outlet receiver at the base of the Christmas tree stand (keep the cord away from the ground to prevent fraying when the tree is rotated)

4




- Plug in and turn on the power cord switch (Turn on the power cord switch to power on, you can use the remote control or the switch on the base to control the product rotation and tree lights)

3


FUNCTION

SWITCH 1:

This switch can only control the base to power on or off, you can control the light and rotation through SWITCH 2




SWITCH2:



SWITCH 3: Remote-Control Unit

Six keys are independently controlled without interfering with each other



Power-Off Memory Function

This device is equipped with a power-off memory function. In the event of a power interruption, the system will automatically restore the previous settings (including lighting mode and rotation) once power is resumed. There is no need to manually reconfigure the settings after each use.

4

TO PAIR WITH A BLUETOOTH DEVICE

When the Christmas tree stand is powered on, the speaker will remain in discoverable mode.

- 1 Ensure your Bluetooth device is set to discoverable so it can detect the Christmas tree stand speaker in your device's user interface, locate the list of available Bluetooth devices.

Tips:

Bluetooth

←Settings

Bluetooth ☒

MY DEVICES

Musical Christmas Tree Stand Connected

OTHER DEVICES

Musical Christmas Tree Stand

① Open the settings menu on your phone. Select the Bluetooth option and turn it on.

② Locate 'Musical Christmas Tree Stand' at the bottom of the list of devices, then click on it to pair.

- 2 From the Bluetooth device list, select the device named 'Musical Christmas Tree Stand'.
- 3 If your Bluetooth device prompts you for a passcode, enter digits 0000 (four zeros) and press OK, some devices also ask you to accept the connection.

Your Bluetooth device indicates when pairing is completed.

5

CONNECTING A PAIRED DEVICE

To reconnect to a previously paired device, turn on the device and wait briefly, it will automatically connect to the Christmas tree stand speaker. Once connected, the speaker will emit a notification sound.

Note: If the speaker's Bluetooth is off, press the base button for 2 seconds or use the remote control's Bluetooth button to turn it on.

CLEARING MEMORY

To clear the speaker memory of all devices, press and hold the button on the base (about 5 seconds) until you hear a tone.

All Bluetooth devices are cleared from the speaker, and the speaker becomes discoverable.

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



Manufacturer: Shenzhen Lantingxu Technology Co., Ltd.

Address: Room 107, Building A, Chuangye No.1 Building,
No. 43, Yanshan Road, Yanshan Community, Merchants
Street, Nanshan District, Shenzhen, China
Production Date: July 18, 2025

- a) The product contains replaceable batteries
- b) Battery type CR2025
- c) Nominal voltage 3V*1 Battery



MADE IN CHINA

6

Important Safety Instructions

1. For indoor use only. Use only with an artificial tree.
2. Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar heat sources.
3. Do not secure the product wiring with staples or nails, or place it on sharp hooks or nails.
4. To avoid the risk of fire, burns, personal injury and electric shock, it should not be placed where small children can reach it.
5. Do not hang ornaments or other objects from the cord, wire, or light string.
6. Do not cover the product with cloth, paper, or any material not part of the product when in use.

*Read and follow all instructions on the product or provided with it.

*If any parts are missing, please contact us through Support@coolwufan.com or scan the QR code below.



SCAN THE QR CODE TO ACTIVATE YOUR WARRANTY

ROTATING TREE STAND ASSEMBLY INSTRUCTIONS



- Please follow the installation instructions carefully to quickly and easily set up your stand.
- This rotating tree stand is designed for 9-foot artificial trees and can support a maximum weight of 120lb including tree decorations.
- Only suitable for artificial tree center rod diameters 0.8-1.5 inch.
- If your tree does not meet these requirements, please do not use a rotating tree stand.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.