

产品介绍 耳机耳挂勾 耳机指示灯 耳机话筒口 耳机充电盒指示灯 气传导发声单元 · 充电口（充电仓背面） 连接设备 蓝牙 5B 连接 首款OWS耳夹式可更换配饰耳机	❶ 打开充电仓取出耳机 ❷ 手机连接蓝牙名即可 连接不成功/快速解决方法: · 检查耳机是否断电 · 检查上台连接的设备，是否还连接着该耳机，先断开上—台设备的连接，避免断线连接到上一台设备。 操作方法 · 产品连接手机后，播放、暂停，接听、挂断电话，上下曲等操作，都是由手机上操作完成，产品自身不设置操作功能。 耳机连接方式 ❶ 打开充电仓，取出耳机自动连接，耳机放进充电仓断开连接。❷耳机在无与手机连接的状态下，5分钟自动关机。 产品功能特点一 · 产品支持一拖二手机功能，能同时连接2台手机，操作方法，先用产品连接1台手机后，将1号手机蓝牙关闭（或把1号手机与产品距离20米以上），再连接另一台手机，第2台手机与产品连接后，操作1号手机时，产品会与1号手机连接，当操作2号手机时，产品会自动与2号手机连接。	产品功能特点二 · 动态低频，产品能随着调节手机音量大小，自动调节音乐的低频状态。 佩戴 / 更换饰品方法 ❶ ❷ ❸ 左右戴：先选对 戴耳夹：向后戴 戴耳夹：戴更稳 · 耳机上有对位孔，将件上相对位性，将件要与耳机对位配戴。 耳机指示灯 · 配对状态:红色蓝色交替闪烁 · 设备连接成功:指示灯熄灭 · 充电中:红色长亮 · 充电完成:蓝灯亮5秒熄灭	充电仓指示灯 · 充电中:红灯长亮 · 充满电:蓝灯长亮 · 智能仓:常呼吸灯，耳机头进仓与取出仓，呼吸灯会闪烁一次。 充电方式 ❶ 请使用包装盒内置的Type-C充电线进行充电。充电10分钟即可使用1小时；耳机充满电后最长可使用5-7小时；充电仓额外为耳机提供30小时续航。 ❷ 数据来源于专业实验室，在ios手机设备中以音量播放SBC编码音频测试得出。具体续航时间受音量，连接设备，使用习惯的影响会有所不同，以实际使用情况为准； 耳机丢失补救 如果软件版本相同的情况下，一般两个耳机同时放回电池仓盖子就会自动配对。 如不能配对，详情咨询客服。	产品服务政策 *如果遇到有问题，请联系我们客服解决。 保修政策 售后严格依据《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》实行售后三包服务。服务内容如下: ❶ 自您签收次日起7日内，本产品出现性能故障的情况，经由我司售后服务中心检测确定，可免费享受退货或换货服务； ❷ 自您签收次日起8日-15日内，本产品出现性能故障的情况，经由我司售后服务中心检测确定，可免费享受换货或维修服务； ❸ 自您签收次日起12个月内，本产品出现性能故障的情况，经由我司售后服务中心检测确定，可免费享受维修服务； ❹ *注意：数据线为产品随机耗材，无保修期。 非保修案例 ❶ 未经授权的维修、误用、碰撞、疏忽、滥用、进水、事故、改动、不正当使用非产品配件，或篡改、涂改标识、防伪标记等人为损坏； ❷ 已超过三包有效期； ❸ 无保修卡及有效发票，但能够证明产品在保修期内的除外；	❶ 消费者因使用、维护、保管不当等人为原因造成损坏的； ❷ 保修卡与产品型号标识不符，或保修卡被涂改； ❸ 未按说明书要求使用、维护、保养而造成配件损坏； ❹ 因不可抗力拒力造成损坏的，如地震、火灾、洪水、台风等。 镀银金18K白 保养必看 用后擦拭 表面手印 避免与化 妆品接触 避免尖锐 物品划伤 务必使用（眼镜布）擦拭。 用后擦拭，减少污渍侵蚀白金，方可保持产品光泽。	❶ 本设备不得造成有害干扰； ❷ 本设备必须接受接收到的任何干扰，包括可能导致不正常操作的干扰。 注1：根据FCC规则第15部分，本设备已经过测试，符合B类数字设备的限制。这些限制是为了在住宅装置中提供合适的保护，防止有干扰。本设备产生、使用并能辐射射频能量，如果不按照说明书安装和使用，可能会对无线电信道造成有害干扰。但是，不能保证在特定的安装中不会发生干扰。如果本设备确实对无线电信道造成有害干扰，可以通过关闭和打开设备来确定。则鼓励用户尝试通过以下一种或多种措施来纠正干扰： ❶ 重新定位或重新安置接收天线。 ❷ 增加设备与接收机之间的距离。 ❸ 将设备连接到与接收器连接的电路不同的插座上。 ❹ 向经销商或有经验的广播/电视技术人员寻求帮助。 注2：未经合规责任方明确批准，对本设备的任何更改或修改都可能使用户失去操作设备的权力。 该装置已经过评估，可满足一般射频暴露要求。本装置可在便携式暴露条件下使用，不受任何限制。
--	--	---	--	---	--	--

Product introduction Earphone hook Headphone indicator Headphone mouthpiece Headphone charging bay indicator light Air conduction vocal unit · Charging port (back of charging bay) Connecting Device Bluetooth 5B join The first OWS ear clip interchangeable accessory headphones	❶ Open the charging case and take out the headphones ❷ The phone can connect to the Bluetooth name Problem solving method: · Check your headphones for power failure · Check whether the last connected device is still connected to the headset. Disconnect the previous device first to avoid default connection to the previous device. Operation method · After the product is connected to the mobile phone, the operation of playing, suspending, answering, hanging up and down the call, etc, is completed by the mobile phone operation, and the product itself does not set the operation function. Headphone connection mode ❶ Open the charging case, take out the earphones and they will connect automatically. Put the earphones back into the charging case and disconnect "Connect". ❷ The headphones will automatically shut down after 5 minutes when they are not connected to the mobile phone. Product feature one · The product supports the function of dragging two mobile phones and can connect two mobile phones at the same time. Operation method: First connect one mobile phone with the product, turn off the Bluetooth of the No. 1 mobile phone (or put the No. 1 mobile phone away from the product 20 meters away), and then connect another mobile phone. After the two mobile phones are connected with the product, the product will connect with the No. 1 mobile phone. The product will automatically	connect to the number 2 phone. Product function features two · Dynamic low frequency, the product can automatically adjust the low frequency state of music as the volume of the mobile phone is adjusted. How to wear/change accessories ❶ ❷ ❸ Left and right: Check first Ear tips: backpin Rotating bottom: Wear more stable · There is a alignment hole on the earphone, a alignment column on the trim, and the trim should be worn in alignment with the earphone. Headphone indicator · Pairing status: Alternating red and blue flashes · If the device is successfully connected, the indicator is off · Charging: Red long bright · Charging complete: Blue light 5 seconds off	Charging bay indicator light · Charging: The red light remains on · Fully charged: The blue light remains on · Smart bin: with breathing light, headphone head into and out of the bin, breathing light will blink once. Charging mode ❶ Please charge it using the Type-C charging cable built into the packaging box. It can be used for 1 hour after charging for 10 minutes. The headphones can be used for up to 5 to 7 hours after being fully charged. The charging case provides an additional 30 hours of battery life for the headphones. ❷ The data is sourced from a professional laboratory and was tested by playing SBC-encoded audio at volume on ios mobile devices. The specific battery life may vary due to volume, connected devices, and usage habits. Please refer to the actual usage situation. Headphones lost replacement If the software version is the same, generally the two headphones are put back into the battery compartment cover at the same time will automatically pair. If not, contact customer service for details.	Product service policy * If you have a problem, please contact our customer service. Warranty policy After-sales service strictly adheres to the "Consumer Rights and Interests Protection Law of the People's Republic of China" and the "Product Quality Law of the People's Republic of China" to implement the "three guarantees" service. The service contents are as follows: ❶ Within 7 days from the date of your signature for receipt, if any performance failure of this product occurs and is confirmed by our after-sales service center, you can enjoy free return or exchange services; ❷ Within 8 to 15 days from the date of your signature for receipt, if any performance failure of this product occurs and is confirmed by our after-sales service center, you can enjoy free exchange or repair services; ❸ Within 12 months from the date of your signature for receipt, if any performance failure of this product occurs and is confirmed by our after-sales service center, you can enjoy free repair services; ❹ * Note: The data cable is a product of random consumables, no warranty period. Non-warranty policy ❶ Unauthorized maintenance, misuse, touch, negligence, abuse, liquid injection, accidental alteration, incorrect use of non-product parts, or tear, alter labels, security marks and other human damage;	❶ Has exceeded the validity period of three packages; ❷ No warranty card and valid invoice, except those that can prove that the product is under warranty; ❸ Damaged by the consumer due to improper use, maintenance, storage and other human reasons; ❹ The warranty card does not match the product model mark, or the warranty card is altered; ❺ Failure to use, maintain and maintain the parts according to the instructions caused damage; ❻ Damage caused by irresistible force, such as earthquake, fire, flood, typhoon, etc. Palladium plated 18k white maintenance must see Wipe after use Surface handprint Avoidance and assimilation Cosmetic contact Avoid sharpness Object scratch Be sure to wipe with (glasses cloth). Wipe after use, reduce the stain erosion of platinum, in order to maintain the luster of the product. FCC Warning This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:	❶ This device may not cause harmful interference, and; ❷ This device must accept any interference received, including interference that may cause undesired operation. NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: ❶ Reorient or relocate the receiving antenna. ❷ Increase the separation between the equipment and receiver. ❸ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. ❹ Consult the dealer or an experienced radio/TV technician for help. NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
--	--	--	---	--	---	---