

# Trax Dot 2 User Manual

## Product Overview

Product Name: Trax Dot 2

Model Number: TRX-DT2-BLU

Product photo:



## Appearance and Components

1. **Power Button:** For turning on/off and triggering functions
2. **Horn:** Emits alert sounds
3. **Indicator Light:** Shows operational status

## Electrical Parameters

1. Power Source: User-replaceable CR2032 coin cell battery
2. Battery Life: Approximately 6 months (depending on usage)
3. Alert Type: Buzzer
4. Power On/Off Method: Long press the button

## Compatible Systems

The latest version of iOS, iPadOS, or macOS is recommended for use with the Apple Find My app.

## Instructions for Use

### 1. Power On / Off

- **Power On:** Briefly press the function button once. The horn will beep once and the indicator light will turn on, signaling the device is powered on.
- **Power Off:** Press and hold the function button for 3–5 seconds. Release after hearing beeps confirming successful power off.

### 2. Connecting to the Find My App

1. Open the Find My app on your iPhone or iPad.
2. Allow notifications from the app.
3. Power on your Trax Dot 2.
4. In the Find My app, select the "Items" tab → Tap "Add Item" → Tap "Other Supported Items".
5. Once your Trax Dot 2 is located, tap "Connect".
6. Choose a recognizable name and emoji for your Trax Dot 2 and tap 'Continue'.
7. Confirm adding your Trax Dot 2 to your Apple ID and complete the setup.

### 3. Finding a Nearby Item

- In the Find My app, tap on the corresponding item and select "Play Sound". Your Trax Dot 2 will emit a beeping sound.
- Tap "Stop Sound" once you find your item.

### 4. Viewing Last Known Location

In the Find My app, tap on the item. Its last known location will appear on the map with the chosen emoji. Tap 'Directions' to open the Maps app for navigation.

### 5. Enabling "Notify When Left Behind"

Enable the 'Notify When Left Behind' toggle in the item's settings. You will receive a notification if you leave your Trax Dot 2 behind and it is no longer in range of your device.

## 6. Enabling "Notify When Found"

Enable the 'Notify When Found' toggle. You will receive a notification with an updated location when your Trax Dot 2 is detected by another Find My-enabled device.

**Note:** This feature can only be activated when your item is out of range.

## 7. Enabling "Lost Mode"

1. Under the item's settings, tap "Enable" next to Lost Mode.
2. Enter a phone number or email address where you can be reached, and optionally, a message for the finder.
3. Tap "Activate".

**Note:**

- Enabling Lost Mode automatically enables 'Notify When Found'.
- Your Trax Dot 2 will be locked and cannot be paired to another device.

## 8. Removing an Item from the Find My App

1. Ensure "Lost Mode" is disabled.
2. Scroll to the bottom of the item's details screen in the Find My app and tap "Remove Item".
3. Confirm the removal.

## 9. Factory Reset

1. First, remove the item from the Find My app (as described above).
2. Quickly press the function button four times, then press and hold it a fifth time until you hear a ringing chime. The device is now reset and ready to be paired again.

## Battery Replacement Instructions

- Use a small screwdriver or coin to open the battery compartment cover.
- Remove the old battery and insert a new CR2032 coin cell battery (observe

the correct polarity).

- Close the compartment cover. The device is ready for use upon powering on.

### **Important Notes**

- Please use a coin cell battery that meets specifications.
- Dispose of used batteries according to local regulations.
- This product has been designed to work specifically with Apple Find My technology and certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

### **Products used at a distance of less than 20cm:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference,
- this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **NOTE:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful

interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

FCC ID: 2BSU5-TRX-DT2-BLU